

Tiny Love TO051

Tiny Love Gymini Deluxe Baby Play Mat Instruction Manual

Model: TO051

PRODUCT OVERVIEW

The Tiny Love Gymini Deluxe Baby Play Gym provides a dynamic environment for your little one's developmental exploration. Designed as a versatile baby play gym mat, it features multiple play modes and adjustable arches that can be tailored to suit your baby's growth stages. This baby playmat provides a space for tummy time with its soft, tactile surface. The play mat for babies is equipped with electronic toys that delivers lights and music feedback to captivate and entertain, whether mounted on the baby gym or taken along for fun on the go. This baby activity mat functions as a changing pad and is conveniently machine washable. Part of the essential baby stuff for any nursery, the Gymini also includes various baby tummy time toys that foster motor skill development and stimulate sensory experiences. The expansive, colorful baby floor play mat and its assortment of detachable toys encourage a broad range of developmental activities and continuous engagement. Let your baby explore self-recognition with the captivating mirror and boost their visual skills. This baby play mat activity gym is designed to make moments enriching, laying the foundation for essential developmental milestones.

Key Features:

- **Encourage Continuous Exploration:** Features adjustable arches, allowing customization to match your baby's developmental stages.
- **Build Essential Language Recognition:** Take-along toys with lights and music engage your infant, providing a dynamic environment for developmental exploration.
- **Tummy Time Fun:** Soft, machine-washable tummy time mat enhances comfort and can easily be used as a changing pad.
- **Visual Stimulation:** A captivating mirror fosters self-recognition and helps extend tummy time, keeping your little one engaged.
- **Multiple Developmental Activities:** From adorable infant toys to an easy grip teether, your baby learns crucial milestones through engaging play experiences.

WHAT'S IN THE BOX

- Playmat
- Take-along toys

SETUP INSTRUCTIONS

Follow these steps to assemble your Tiny Love Gymini Deluxe Play Mat:

1. Unfold the playmat on a clean, flat surface. Ensure there is enough space for the arches to be set up.
2. Locate the two flexible arches. Insert the ends of each arch into the designated slots on the playmat. You should hear

a click when they are securely in place.

3. Connect the two arches at the top using the central connector. This will form the activity gym structure.
4. Attach the various take-along toys to the loops on the arches. Distribute them evenly to encourage reaching and batting.
5. For electronic toys, ensure 3 AAA batteries (not included) are inserted correctly into the battery compartment, following polarity indicators.
6. Adjust the position of the arches as needed to suit your baby's developmental stage and activity. The arches are designed to be adjustable for different play modes, including tummy time.



Image: The Tiny Love Gymini Deluxe Play Mat with its colorful mat, adjustable arches, and various hanging toys, ready for play.

OPERATING INSTRUCTIONS

Using the Play Mat:

- **Back Play:** Lay your baby on their back under the arches. The hanging toys encourage reaching, batting, and visual tracking.
- **Tummy Time:** Place your baby on their tummy on the mat. Adjust the arches to bring toys closer for easier access

during tummy time. The mat's soft surface and integrated mirror support this activity.

- **Sit & Play:** As your baby grows and can sit independently, the mat provides a comfortable space for seated play with the various toys.

Electronic Toys:

- Activate electronic toys by pressing the designated buttons or through motion sensors, depending on the toy.
- The electronic toys provide lights and music feedback to engage and entertain your baby.
- These toys can be detached and used independently for on-the-go entertainment.



Image: A baby engaging in tummy time on the playmat, looking up at the hanging toys and mirror.



Image: A baby lying on their back under the play gym, with arms outstretched towards the hanging toys.

MAINTENANCE AND CARE

- **Cleaning the Mat:** The playmat is machine washable. Remove arches and toys before washing. Use a gentle cycle with cold water and mild detergent. Air dry or tumble dry on low heat.
- **Cleaning Toys:** Wipe plastic toys with a damp cloth and mild soap. Fabric toys can be spot cleaned or hand washed gently. Ensure all parts are completely dry before reattaching.
- **Battery Replacement:** For electronic toys, replace batteries (3 AAA) when sounds or lights become faint or stop working. Always use new batteries of the same type and dispose of old batteries responsibly.
- **Storage:** When not in use, the playmat can be easily folded for compact storage. Detach the arches and toys for easier folding.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Electronic toy not working.	Batteries are dead or incorrectly inserted.	Check battery polarity and replace with fresh 3 AAA batteries.
Arches are not stable.	Arches not fully inserted into slots or not connected at the top.	Ensure both ends of each arch are clicked into place and the central connector is secure.
Mat appears wrinkled after washing.	Improper drying or washing cycle.	Air dry flat or tumble dry on very low heat. Gentle ironing on a low setting may be possible, but check care label.

SPECIFICATIONS


Brand: Tiny Love
Model: TO051
Product Dimensions: 2.36 x 30.71 x 22.83 inches
Item Weight: 2.64 pounds
Material Type: Fabric
Batteries Required: Yes, 3 AAA batteries (for electronic toys)
Target Gender: Unisex
Style: Deluxe

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the manufacturer's website or contact Tiny Love customer service directly. Specific warranty details may vary by region and retailer.
Note: No specific warranty period or contact details were provided in the product data.

© 2025 Tiny Love. All rights reserved.

Documents - Tiny Love – TO051



[\[pdf\]](#) Instructions Guide

Untitled E2051IS658 0C Gymini Deluxe WEB tinylove 2025 01 |||
Into the Forest™ Gymini Deluxe Model Number: 120510E001, **TO051** Tiny Princess Tales™ Gymini Deluxe Model Number: 120550E001, TO052 OM English Into the Forest™ Gymini Deluxe Tiny Princess Tales™ Gymini Deluxe INSTRUCTION GUIDE READ ALL INSTRUCTIONS BEFORE USE. KEEP THESE INSTRUCTIONS FOR FUTURE ...
lang:en score:13 filesize: 1.08 M page_count: 2 document date: 2025-01-29