

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Exost](#) /
- › [EXOST Aquacyclone XS Remote Controlled Amphibious Car User Manual](#)

Exost Aquacyclone XS (Model 20203)

EXOST Aquacyclone XS Remote Controlled Amphibious Car User Manual

Model: Aquacyclone XS (20203) | Brand: Exost

INTRODUCTION

Thank you for choosing the EXOST Aquacyclone XS, a versatile remote-controlled amphibious car. This compact vehicle is designed to operate on both land and water, offering dynamic play experiences. This manual provides essential information for the safe and effective use of your Aquacyclone XS.



Image: The EXOST Aquacyclone XS in red, showcasing its compact design and robust wheels, ready for action on various terrains.

SAFETY INFORMATION

- **Adult Supervision:** Recommended for children aged 5 years and above. Adult supervision is advised during operation, especially near water.
- **Battery Safety:** Always follow battery installation instructions. Do not mix old and new batteries, or different types of batteries. Remove batteries if the toy will not be used for an extended period. Dispose of batteries responsibly.
- **Water Use:** Ensure all battery compartments are securely closed before operating the vehicle in water. Avoid salt water, as it can corrode internal components. After water use, thoroughly dry the vehicle.
- **Obstacles:** Avoid operating the vehicle near sharp objects, electrical outlets, or in areas with heavy pedestrian traffic.
- **Impact:** Do not intentionally crash the vehicle into hard surfaces or other objects, as this may cause damage.

PACKAGE CONTENTS

Verify that all components are present in the package:

- 1 x EXOST Aquacyclone XS Amphibious Car
- 1 x Remote Control Transmitter



Image: The EXOST Aquacyclone XS in its retail packaging, featuring a black version of the car and highlighting its amphibious capabilities.

SETUP

1. Battery Installation (Car)

1. Locate the battery compartment on the underside of the Aquacyclone XS car.
2. Using a small screwdriver (not included), open the battery compartment cover.
3. Insert 2 x AAA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Securely close the battery compartment cover and tighten the screw.

2. Battery Installation (Remote Control)

1. Locate the battery compartment on the back of the remote control.
2. Using a small screwdriver (not included), open the battery compartment cover.
3. Insert 2 x AAA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Securely close the battery compartment cover and tighten the screw.



Image: The remote control for the EXOST Aquacyclone XS, featuring two joysticks and blue accents, used to operate the vehicle.

OPERATING INSTRUCTIONS

1. Power On

- Turn on the car by sliding the power switch (usually located on the underside) to the 'ON' position.
- Turn on the remote control by sliding its power switch to the 'ON' position. The indicator light on the remote should illuminate.
- The car and remote should automatically pair. If not, turn both off and on again.

2. Basic Controls

The remote control features two joysticks for movement:

- **Left Joystick:** Controls forward and backward movement.
- **Right Joystick:** Controls turning left and right.
- Combine joystick movements for complex maneuvers.

3. Land Operation

The Aquacyclone XS is designed for smooth operation on various land surfaces. Practice controlling the vehicle in an open area to familiarize yourself with its handling.

4. Water Operation

The Aquacyclone XS is fully amphibious. Ensure the battery compartment is sealed before entering water. The unique wheel design allows it to propel itself through water. Control is similar to land operation.



Image: Two EXOST Aquacyclone XS cars, one red and one black, demonstrating their ability to operate on a wet surface, such as a water slide.



Image: Two EXOST Aquacyclone XS cars, one red and one black, actively splashing water as they move, highlighting their amphibious feature.

MAINTENANCE

1. Cleaning

- After each use, especially after water play, wipe the car thoroughly with a clean, dry cloth.
- Ensure no water remains in the battery compartment or other sensitive areas.
- Do not use harsh chemicals or abrasive cleaners.

2. Storage

- Store the Aquacyclone XS and its remote control in a cool, dry place away from direct sunlight.
- Remove batteries from both the car and the remote if storing for extended periods to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Car does not respond to remote.	Low batteries in car or remote; car/remote not powered on; out of range; pairing issue.	Replace batteries in both car and remote. Ensure both are switched 'ON'. Move closer to the car. Turn both off and on again to re-pair.
Car moves slowly or erratically.	Low batteries in car; obstruction in wheels; operating on unsuitable surface.	Replace car batteries. Check wheels for debris. Move to a smoother surface.
Remote control range is poor.	Low batteries in remote; environmental interference.	Replace remote batteries with fresh alkaline batteries (not rechargeable, as they may provide lower voltage). Avoid areas with strong electromagnetic interference.
Car stops working after water use.	Water entered battery compartment; internal components wet.	Immediately remove batteries. Dry the car thoroughly. Ensure battery compartment is sealed before water use. If issues persist, contact support.

SPECIFICATIONS

- **Model Name:** Aquacyclone XS
- **Model Number:** 20203
- **Brand:** Exost
- **Dimensions (L x W x H):** 11.5 x 9.5 x 6 cm (4.5 x 3.7 x 2.4 inches)
- **Weight:** 200 grams (0.44 lbs)
- **Scale:** 1:34
- **Material:** Plastic
- **Color:** Multicolore (Red/Black variants)
- **Recommended Age:** 5 - 10 years
- **Max Speed:** 8 km/h (5 mph)
- **Power Source:** Battery-powered
- **Car Batteries:** 2 x AAA (not included)
- **Remote Control Batteries:** 2 x AAA (not included)
- **Special Features:** Amphibious, Remote Control

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Exost website. Keep your purchase receipt as proof of purchase.

