

Dell PRM7520WYDRD

Dell Precision 7520 Mobile Workstation User Manual

Model: PRM7520WYDRD

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Dell Precision 7520 Mobile Workstation. Please read this guide thoroughly to ensure optimal performance and longevity of your device.

The Dell Precision 7520 is a high-performance mobile workstation designed for demanding professional applications, featuring an Intel i7-7820HQ processor, 16GB DDR4 RAM, and a 512GB NVMe SSD.

2. SETUP

2.1 Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that the following items are included:

- Dell Precision 7520 Mobile Workstation
- AC Adapter
- User Manual (this document)

Inspect the workstation for any physical damage. If any damage is found, contact Dell support immediately.

2.2 Connecting Power

1. Connect the AC adapter cable to the power connector on the workstation.
2. Plug the power cable into a grounded electrical outlet.
3. The battery will begin charging automatically.

2.3 Initial Boot and Operating System Setup

Press the power button to turn on the workstation. The system will guide you through the initial setup of Windows 10 Pro. Follow the on-screen instructions to configure your language, region, network settings, and user account.

2.4 Connecting Peripherals

Connect external devices such as a mouse, keyboard, external monitor, or USB drives to the available ports on your workstation. The Dell Precision 7520 features multiple USB 3.0 ports and a DisplayPort 1.4 for external displays.



Figure 2.4.1: Front-left view of the Dell Precision 7520 Mobile Workstation with the screen open, showing the keyboard and various ports on the left side.

3. OPERATING YOUR WORKSTATION

3.1 Power On/Off

- **Power On:** Press the power button located on the top-right of the keyboard deck.
- **Power Off:** Click the Start button in Windows, then select Power > Shut down.
- **Sleep Mode:** Close the lid or select Power > Sleep from the Start menu.

3.2 Keyboard and Touchpad

The workstation includes a full-sized keyboard and a precision touchpad. The touchpad supports multi-touch gestures for navigation and control within Windows 10 Pro.

3.3 Display Features

Your Dell Precision 7520 features a 15.6-inch display with a resolution of 1920 x 1080 pixels. This display supports high-definition content and provides ample screen real estate for professional tasks.



Figure 3.3.1: Front view of the Dell Precision 7520 Mobile Workstation with the screen open, showcasing the display and keyboard.

3.4 Connectivity

- **USB Ports:** Utilize the four USB 3.0 ports for connecting external devices.
- **Display Output:** The DisplayPort 1.4 supports high-resolution external monitors, including 8K resolution and HDR.
- **Wireless:** Integrated Bluetooth allows for wireless peripheral connections.



Figure 3.4.1: Left side view of the Dell Precision 7520 Mobile Workstation, highlighting the various ports and slots.

4. MAINTENANCE

4.1 Cleaning Instructions

- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a non-abrasive screen cleaner. Do not spray liquid directly onto the screen.
- **Keyboard and Chassis:** Use a soft cloth to wipe surfaces. A can of compressed air can remove dust from between keys.
- **Ports:** Ensure ports are free of dust and debris to maintain proper connectivity.

4.2 Battery Care

The workstation is powered by a Lithium Ion battery. To maximize battery life:

- Avoid extreme temperatures.
- Do not fully discharge the battery frequently.
- Store the workstation with a partial charge (around 50%) if not used for extended periods.

4.3 Software Updates

Regularly update your Windows 10 Pro operating system and Dell drivers to ensure optimal performance, security, and compatibility. Check for updates through Windows Update and Dell's official support website.

4.4 Storage Management

The 512GB NVMe SSD provides fast storage. Regularly manage your files and applications to prevent the drive from becoming full, which can impact performance. Consider using cloud storage for large files.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your Dell Precision 7520 Mobile Workstation.

5.1 Power Issues

- **Workstation does not turn on:** Ensure the AC adapter is securely connected to both the workstation and a working power outlet. Check the power indicator light on the adapter.
- **Battery not charging:** Verify the AC adapter connection. If the issue persists, the battery or adapter may require service.

5.2 Display Problems

- **No image on screen:** Ensure the workstation is powered on. If an external monitor is connected, try disconnecting it. Adjust display brightness using keyboard function keys.
- **External monitor not detected:** Verify the cable connection to the DisplayPort. Ensure the external monitor is powered on and set to the correct input source.

5.3 Performance Issues

- **Slow performance:** Close unnecessary applications. Check for background processes consuming high CPU or RAM. Ensure Windows and drivers are up to date.
- **Overheating:** Ensure ventilation vents are clear and not obstructed. Operate the workstation on a hard, flat surface.

For more complex issues or if troubleshooting steps do not resolve the problem, refer to the Dell support website or contact Dell technical support.

6. SPECIFICATIONS

Detailed technical specifications for the Dell Precision 7520 Mobile Workstation (Model PRM7520WYDRD).

Feature	Specification
Model Number	PRM7520WYDRD

Feature	Specification
Processor	Intel Core i7-7820HQ (2.9 GHz)
RAM	16 GB DDR4 (2400 MHz)
Storage	512 GB NVMe SSD
Graphics Coprocessor	NVIDIA Quadro (Dedicated, 8GB RAM)
Display Size	15.6 Inches
Max Screen Resolution	1920 x 1080 Pixels
Operating System	Windows 10 Pro
USB 3.0 Ports	4
Wireless Type	Bluetooth
Item Weight	6.1 pounds
Product Dimensions	14.8 x 10.3 x 1.09 inches
Battery	1 Lithium Ion battery required
Optical Drive Type	DVD-RW

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Your Dell Precision 7520 Mobile Workstation is covered by Dell's standard limited warranty. For specific warranty terms and conditions, please refer to the warranty documentation included with your purchase or visit the official Dell support website. Keep your proof of purchase for warranty claims.

7.2 Technical Support

For technical assistance, driver downloads, or service requests, please visit the official Dell Support website. You will need your service tag or express service code, typically found on a label on your workstation, to access personalized support resources.

Dell Support Website: www.dell.com/support