

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [allen + roth](#) /

› [allen + roth Winsbrell 5-Light Vanity Light User Manual](#)

allen + roth Winsbrell 5-Light

allen + roth Winsbrell 5-Light Vanity Light User Manual

Model: Winsbrell 5-Light

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your allen + roth Winsbrell 5-Light Vanity Light. Please read this manual thoroughly before beginning installation and retain it for future reference.

IMPORTANT SAFETY INFORMATION

WARNING: Risk of Electric Shock.

- Always disconnect power at the main circuit breaker or fuse box before installation or servicing.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections are made in accordance with local codes and ordinances, as well as the National Electric Code (NEC).
- Do not install this fixture in wet locations. It is damp rated for use in bathrooms.
- Use only the specified bulb type and wattage to avoid overheating.

PACKAGE CONTENTS

Carefully unpack the fixture and check that all parts are included. If any parts are missing or damaged, do not attempt to assemble or install the product. Contact customer service for assistance.

- Vanity Light Fixture (1)
- Glass Shades (5)
- Mounting Hardware (screws, wire nuts, etc.)
- Remote Control (1)
- Instruction Manual (this document)

Note: Five 60-watt A19 bulbs with E26 Medium base are required and sold separately.

SETUP AND INSTALLATION

1. Prepare for Installation:

Turn off power at the circuit breaker or fuse box. Ensure the power is off before proceeding. Clear the work area and gather necessary tools (screwdriver, wire strippers, etc.).

2. Mounting the Fixture:

Attach the mounting bracket to the junction box in the wall. This fixture can be installed with the lights facing up or down, depending on your preference. Secure the fixture base to the mounting bracket.



Image: The allen + roth Winsbrell 5-Light Vanity Light installed above a mirror, showcasing its brushed nickel finish and five clear bell-shaped glass shades. The lights are illuminated.

3. Electrical Connections:

Connect the fixture's wires to the corresponding household wires using wire nuts. Connect the black wire (live) to the black wire, the white wire (neutral) to the white wire, and the ground wire to the ground wire. Ensure all connections are secure.

4. Install Glass Shades:

Carefully attach each clear bell-shaped glass shade to the fixture. Ensure they are securely fastened but do not

overtighten to prevent damage.

5. Install Light Bulbs:

Screw in five 60-watt A19 bulbs with an E26 Medium base (sold separately) into each socket. Do not exceed the maximum wattage specified.

6. Restore Power:

Once installation is complete, restore power at the circuit breaker or fuse box.

OPERATING INSTRUCTIONS

- Turning On/Off:** Operate the vanity light using your standard wall switch.
- Dimming Function:** This light fixture is fully dimmable. To utilize the dimming feature, ensure you are using dimmable bulbs and have a compatible dimmer switch installed (sold separately).
- Remote Control:** The included remote control can be used to operate the light. Refer to the remote control's specific instructions for pairing and function details.

MAINTENANCE

- Cleaning:** To clean the fixture, turn off the power and wipe with a soft, dry or slightly damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or glass.
- Bulb Replacement:** To replace a bulb, ensure the power is off. Allow the bulb to cool before unscrewing it. Replace with a new 60-watt A19 bulb with an E26 Medium base. The design allows for easy access to switch out light bulbs.
- Glass Shade Care:** The glass shades are fragile. Handle them with care during cleaning or bulb replacement. Replacements for glass shades may not be readily available for purchase.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--------------------------------------|---|--|
| Light does not turn on. | Power is off at the circuit breaker. Loose wire connections. Faulty bulb. | Check the circuit breaker and ensure power is on. Verify all wire connections are secure (with power off). Replace the bulb. |
| Light flickers or dims unexpectedly. | Loose bulb. Incompatible dimmer switch or non-dimmable bulbs. Loose wiring. | Tighten the bulb. Ensure dimmable bulbs are used with a compatible dimmer. Check wiring connections (with power off). |

If you experience persistent issues, consult a qualified electrician.

SPECIFICATIONS

| | |
|--------------|---|
| Brand | allen + roth |
| Model Number | Winsbrell 5-Light (Part Number: B10115) |

| | |
|--------------------------------|----------------------------------|
| Product Dimensions | 6.87 x 9.24 x 38.24 inches |
| Item Weight | 8.9 pounds |
| Color/Finish | Brushed Nickel |
| Material | Nickel (Fixture), Glass (Shades) |
| Light Fixture Form | Vanity |
| Room Type | Bathroom |
| Indoor/Outdoor Usage | Indoor (Damp Rated) |
| Power Source | Corded Electric |
| Voltage | 120 Volts |
| Wattage | 60 watts (per bulb, max) |
| Number of Light Sources | 5 |
| Bulb Base | E26 Medium |
| Special Feature | Dimmable |
| Included Components | Remote Control |

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the manufacturer directly. Keep your proof of purchase for any warranty claims.

Manufacturer: allen + roth