

[manuals.plus](#) /› [Cogeco](#) /› [Cogeco URC 1056B03 Universal Remote Control User Manual](#)

## Cogeco URC 1056B03

# Cogeco URC 1056B03 Universal Remote Control User Manual

Model: URC 1056B03

## 1. OVERVIEW

---

This manual provides instructions for the Cogeco URC 1056B03 Universal Remote Control. This remote is designed to control various devices, including Cable/Satellite Boxes, DVRs, and Televisions, utilizing infrared technology for reliable operation.


### Key Features

- **Universal Compatibility:** Controls a wide range of devices including Cable/Satellite Boxes, DVRs, and Televisions.
- **32 Buttons for Easy Navigation:** Offers a comprehensive set of keys for seamless control of your cable TV experience.
- **Infrared Technology:** Utilizes reliable IR signals for accurate and responsive control.
- **Power Source:** Requires two AA batteries for operation.
- **Design:** Features a sleek, compact, and ergonomic black design.

# URC1056

## REMOTE CONTROL USER'S GUIDE

### MODE D'EMPLOI DE LA TÉLÉCOMMANDE



Functions may vary depending on service.  
Ces fonctions peuvent varier selon les appareils commandés.

For Additional Support and Model-Based Code Search go to:  
Pour obtenir de plus amples renseignements ou lancer une recherche du code de modèle, allez à l'adresse:

[www.urcsupport.com](http://www.urcsupport.com)

## 2. SETUP

---

### Battery Installation

The remote control requires two AA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open.
3. Insert two AA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover by sliding it upwards until it clicks into place.






Image: The open battery compartment of the remote control, illustrating where to insert two AA batteries according to their positive and negative terminals.

## Quick Remote Setup

This procedure allows for quick programming of the remote to control your device (TV, DVD, etc.).

1. Turn on the device you wish to control (e.g., TV, DVD player, cable box).
2. Press the corresponding device key (TV, DVD, AUD, CBL) on the remote.
3. Press and hold the **SETUP** button until the LED blinks twice.
4. Enter the code **9-9-1**. The LED will blink twice.
5. Press the **CH+** button repeatedly until the device turns off.
6. Press the **SETUP** button to save the setting when the device turns off.



Image: A detailed view of the back of the remote control, displaying the 'Quick Remote Setup' instructions directly printed on the surface.

### 3. OPERATING INSTRUCTIONS

---

This section details the functions of the buttons on your Cogeco URC 1056B03 remote control.





Image: The front face of the Cogeco URC 1056B03 remote control, clearly showing the layout and labels of all its buttons.

## Power and Mode Keys

- **POWER:** Turns the selected equipment (e.g., cable TV, TV) on or off.
- **SETUP:** Used for remote control programming.
- **MODE KEYS (TV, DVD, AUD, CBL):** Used to select the device the remote will control.

## Playback Controls

- **F1/F2:** Custom keys that may be assigned specific functions by your cable operator.
- **ON DEMAND:** Accesses the on-demand program library.
- **LIST:** Displays a list of recorded programs on DVR boxes.

- **LIVE:** Returns to live television.
- **FF (Fast Forward) / PAUSE / PLAY / REW (Rewind) / SKIP BACK / STOP** Controls playback of live, recorded, or On Demand programs.
- **RECORD:** Initiates recording of the selected program.

## Navigation Keys

- **GUIDE:** Displays the program guide.
- **EXIT:** Closes the current menu or guide.
- **INFO:** Displays information about the currently selected program.
- **MENU:** Displays the main cable menu.
- **SETTINGS:** Allows modification of cable box settings.
- **DAY +/-:** Jumps a day forward or backward in the program guide.
- **PAGE +/-:** Navigates through the program guide one page at a time.
- **A-D KEYS (Red, Green, Yellow, Blue):** Used for special functions displayed on your cable menus.
- **LAST:** Returns to the previously selected channel.
- **FAV:** Cycles through favorite channels configured on your cable box.

## Other Keys

- **PIP ON/OFF:** Activates or deactivates picture-in-picture on compatible cable boxes.
- **PIP MOVE:** Changes the location of the mini picture in PIP mode.
- **PIP +/-:** Changes the channel on the mini picture when PIP is active.
- **SWAP:** Swaps between tuners on DVR boxes or swaps pictures in PIP mode.
- **VIDEO SOURCE:** Cycles through video inputs on the TV or audio device.

## 4. TROUBLESHOOTING

---

If your remote control is not functioning as expected, consider the following common issues and solutions:

- **No Response from Device:**
  - Ensure the remote is pointed directly at the device's infrared sensor.
  - Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
  - Verify that the remote is set to the correct device mode (e.g., TV, CBL).
  - Re-attempt the Quick Remote Setup procedure.
- **Specific Buttons Not Working:**
  - Some buttons may have functions specific to certain cable box models or service providers. Refer to your cable provider's documentation for specific button functionalities.
  - If the remote was recently programmed, try re-programming it using the Quick Remote Setup.
- **Interference:**
  - Bright sunlight or certain types of lighting can interfere with infrared signals. Try operating the remote in different lighting conditions.

## 5. SPECIFICATIONS

---

Feature	Detail
---------	--------

Brand	Cogeco
Model	URC 1056B03
Compatible Devices	Motorola DCT, DCH, DVR, PVR Cable Box, Televisions
Connectivity Technology	Infrared
Power Source	2 x AA Batteries (not included)
Special Features	Pre-Programmed
Dimensions (Approx.)	23.4 x 6.2 x 4 cm
Weight (Approx.)	140 g

## 6. SUPPORT AND WARRANTY

For additional support, programming codes, or information on other models, please visit the manufacturer's support website.

**Online Support:** [www.urcsupport.com](http://www.urcsupport.com)

Information regarding product warranty, if applicable, is typically provided at the point of purchase or can be found on the manufacturer's official website.

### Related Documents - URC 1056B03

	<p><b><u><a href="#">Universal Remote Control Manuals and Code Lists</a></u></b></p> <p>A comprehensive list of links to manuals, code lists, and resources for a wide variety of universal remote control models from manufacturers like Universal Remote, Hama, Marmitek, Silvercrest, and more. Accessing these resources can help users set up and operate their devices.</p>
	<p><b><u><a href="#">Universal Electronics Millennium 4 Universal Remote Control - Features &amp; Specifications</a></u></b></p> <p>Explore the Universal Electronics Millennium 4 remote control, offering advanced features like patented upgradeability, world-class connectivity software, and control for up to 4 devices. Learn about its specifications, benefits, and company information.</p>
	<p><b><u><a href="#">CLIKR-5 UR5U-8820L Cable Remote Control Operating Instructions</a></u></b></p> <p>Comprehensive operating instructions for the CLIKR-5 UR5U-8820L cable remote control, covering setup, programming methods (3-digit code and auto-search), button functions, and extensive device code tables for various manufacturers.</p>
	<p><b><u><a href="#">Jumbo Universal Remote Control #1526 User's Guide</a></u></b></p> <p>Comprehensive user guide for the Jumbo Universal Remote Control #1526, detailing setup, operation, troubleshooting, and features for controlling TV, VCR, DVD, PVR, Cable, and Satellite receivers.</p>

	<p><a href="#"><u>UR4U-MDVR2 4-Function Cable Remote Control: Setup, Programming, and Code List</u></a></p> <p>Get detailed operating instructions for the Universal Remote Control UR4U-MDVR2. Learn how to program your remote using Quick Set-Up, 3-Digit Codes, or Auto-Search. Includes comprehensive brand setup code tables for TVs, DVDs, AUX devices, and cable boxes.</p>
	<p><a href="#"><u>URC UR3L-SR4 Easy Clicker Remote Control Manual: Setup and Programming Guide</u></a></p> <p>Comprehensive user manual for the URC UR3L-SR4 Easy Clicker remote control. Learn how to set up, program, and use your remote with detailed instructions and guidance on using extensive device code tables for Cable TV, TVs, and DVDs.</p>