

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [JOYOUNG](#) /

> [Joyoung Soy Milk Maker DJ13U-D988SG User Manual](#)

JOYOUNG DJ13U-D988SG

Joyoung Soy Milk Maker DJ13U-D988SG User Manual

Model: DJ13U-D988SG

INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your Joyoung DJ13U-D988SG Soy Milk Maker. Please read this manual thoroughly before using the appliance and retain it for future reference.

PRODUCT OVERVIEW

Package Contents

Verify that all items are present in the package:

- 1 x Joyoung DJ13U-D988SG Soy Milk Maker Body
- 1 x Measuring Cup
- 1 x Cleaning Cloth
- 1 x Cleaning Brush
- 1 x AC Power Cord
- 1 x User Manual (Chinese & English)



Image: Contents of the Joyoung DJ13U-D988SG Soy Milk Maker package.

Key Components and Features

The Joyoung DJ13U-D988SG Soy Milk Maker is designed for versatile use with features including:

- **Strong Grinder:** High-speed motor (20000 r/min) for efficient grinding.
- **No Filter Design:** Eliminates the need for straining, though some fine residue may remain.
- **Double Layer Coupler:** Provides enhanced safety during operation.
- **Food Grade Liner:** Ensures food safety and durability.
- **Non-slip Bottom:** For stability during use.
- **Delay Timer:** Allows for scheduled operation.
- **Warm Function:** Keeps beverages warm or reheats cooled drinks.

More details Safe to use

strong grinder



strong grinder



Double layer coupler - Safe protection



Food grade liner



Non-slip bottom



Image: Detailed view of the soy milk maker's internal and external components.



Image: Illustration of the strong grind system, highlighting the high-speed grinder.

SETUP

1. **Unpacking:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, clean the interior of the main unit, the grinding head, and all accessories (measuring cup, cleaning brush) with mild detergent and water. Rinse thoroughly and dry.
3. **Placement:** Place the soy milk maker on a stable, flat, and dry surface, away from heat sources and direct sunlight.
4. **Power Connection:** Ensure the appliance is switched off before plugging the AC power cord into a standard 120V-60Hz electrical outlet.

OPERATION

General Steps for Soy Milk Preparation

1. **Prepare Ingredients:** Measure the desired amount of soybeans (or other ingredients) using the provided measuring cup. For best results, pre-soak dry beans according to recipe recommendations.
2. **Add Ingredients and Water:** Place the prepared ingredients into the main unit. Add water, ensuring it is between the minimum and maximum fill lines indicated inside the unit. **Do not add hot or warm water.**
3. **Secure Lid:** Place the lid securely onto the main unit. Ensure it is properly aligned and locked into place.
4. **Select Function:** Plug in the power cord. The control panel will illuminate. Select the desired function (e.g., "Wet/Dry Beans" for soy milk) using the control buttons.
5. **Start Process:** Press the "Start" button to begin the selected program. The machine will automatically proceed through heating, grinding, and cooking cycles.

6. **Completion:** Once the program is complete, the machine will typically beep and/or display a completion indicator. Unplug the appliance.
7. **Serve:** Carefully pour the prepared beverage into a serving container. The contents will be hot.



Image: Illustration of the five-step process for making soy milk.

Delay Timer Function

The delay timer allows you to set a specific time for the machine to start its operation. This is useful for preparing fresh soy milk or other beverages at a desired time, such as in the morning.

1. Follow steps 1-3 of the "General Steps for Soy Milk Preparation".
2. After selecting your desired function, press the "Delay Timer" button.
3. Adjust the delay time using the appropriate buttons on the control panel.
4. Press "Start" to confirm the delay setting. The machine will begin operation after the set delay period.

FUNCTIONS

The Joyoung DJ13U-D988SG offers a variety of programs for different preparations:

- **Grains:** For preparing beverages from various grains.
- **Wet/Dry Beans:** Specifically designed for making soy milk from pre-soaked (wet) or unsoaked (dry) soybeans.
- **Baby Porridge:** For preparing smooth and nutritious porridge suitable for infants.
- **Tofu Pudding:** A program for making fresh tofu pudding.
- **Fruit Tea:** For brewing fruit-infused teas.
- **Cooked Material:** General cooking function for various ingredients.
- **Soup:** For preparing hot soups.
- **Juice:** For blending fresh juices.
- **Pudding:** For making other types of puddings.
- **Stir:** A blending-only function.
- **Warm Function:** To keep prepared beverages warm or to reheat cooled drinks.

- **Nuts Drink:** For preparing milk from various nuts.
- **Time & Temperature Presets:** Allows for customized cooking settings.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your soy milk maker.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Cool Down:** Allow the machine to cool completely after use before cleaning.
3. **Empty Contents:** Discard any remaining contents from the main unit.
4. **Rinse:** Rinse the interior of the main unit and the grinding head with water immediately after use to prevent food residue from drying and sticking.
5. **Clean Grinding Head:** Use the provided cleaning brush to thoroughly clean the grinding head and blades. Be cautious as blades are sharp.
6. **Clean Interior:** Use the cleaning cloth and mild detergent to wipe the interior of the main unit. For stubborn stains, a non-abrasive sponge can be used.
7. **Clean Exterior:** Wipe the exterior of the appliance with a damp cloth. Do not immerse the main body or electrical components in water.
8. **Dry:** Ensure all parts are thoroughly dried before reassembling or storing the appliance.

TROUBLESHOOTING

Refer to the following common issues and solutions:

- **Loud Sound During Operation:**

The machine produces a loud sound during the grinding phase due to the high-speed motor. This is normal operation. To minimize disturbance, consider using the delay timer function to schedule operation for a convenient time.

- **Machine Makes Sound but Does Not Appear to Grind:**

The soy milk maker operates in a five-step cycle, which includes intermittent grinding. If you hear sound, it is likely grinding. Periods of silence indicate other steps in the process (e.g., heating, soaking). Allow the full cycle to complete.

- **"E2" Error Displayed and Machine Stops:**

The "E2" error typically indicates an over-temperature condition, a safety protection mechanism. This can occur if hot or warm water/juice is added to the unit. To resolve:

- a. Unplug the machine.
- b. Remove the contents and allow the unit to cool down completely.
- c. Ensure only cold water and ingredients are used.
- d. Plug in and restart the operation.

- **Soy Milk Consistency:**

While the machine is designed for no-filter use, some fine bean residue or shell particles may remain. This is normal and does not indicate a malfunction. For a smoother consistency, ensure beans are properly soaked (if applicable) and consider adjusting the water-to-bean ratio.

SPECIFICATIONS

Product Model	DJ13U-D988SG
Capacity	900-1300ml
Input Voltage	120 V-60 Hz
Rated Power	1200 W
Motor Power	300 W
Motor Speed	20000 r/min
Suitable For	2-4 persons
Product Size	230 x 180 x 310 mm
Net Weight	2.6 KG (5.73 lbs)
Item Weight (Shipping)	8.38 pounds
Package Dimensions	15.9 x 11.1 x 9.9 inches
Manufacturer	Joyoung
Date First Available	November 3, 2017

WARRANTY AND SUPPORT

This Joyoung DJ13U-D988SG Soy Milk Maker comes with a **1-year warranty** in the United States. For warranty claims, technical support, or service inquiries, please contact Joyoung customer service. Refer to the contact information provided on the product packaging or the official Joyoung website for the most up-to-date support details.