

rock space EB10

# Rock Space EB10 True Wireless Stereo Earphone User Manual

Model: EB10 | Model Number: EBT10TW

## 1. PRODUCT OVERVIEW

The Rock Space EB10 True Wireless Stereo Earphones offer a cable-free audio experience with an ergonomic design for comfortable wear. This manual provides essential information for optimal use and maintenance of your device.



Image 1: The Rock Space EB10 True Wireless Stereo Earphones, with one earbud removed from its charging case, illustrating the compact design and charging contacts.

## 2. PACKAGE CONTENTS

---

Ensure all items are present in your product package:

- Rock Space EB10 True Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Multiple Sizes of Ear Cushions
- User Manual (this document)



Image 2: The complete retail package for the Rock Space EB10, showing the product box, charging case, earbuds, various ear tip sizes, and a USB charging cable.

## 3. SETUP AND FIRST USE

### 3.1 Charging the Earbuds and Case

1. Place both earbuds into the charging case. Ensure they are correctly seated; magnetic contacts will hold them in place.
2. Connect the provided USB charging cable to the charging port on the case and to a compatible USB power source.
3. The indicator lights on the charging case will illuminate to show charging status. A full charge provides approximately 12 hours of additional use time for the earbuds.

### 3.2 Pairing with Your Device

1. Ensure the earbuds are charged.
2. Remove both earbuds from the charging case. They will automatically power on and attempt to pair with each other.
3. On your smartphone, tablet, or other Bluetooth-enabled device, navigate to the Bluetooth settings.

4. Search for available devices and select "Rock Space EB10" from the list.
5. Once connected, a voice prompt will confirm successful pairing.

### 3.3 Adjusting Fit

For optimal sound quality and comfort, select the ear cushions that best fit your ears. Insert the earbuds and gently rotate them until you achieve a secure and comfortable fit. The ergonomic design is intended to provide stability during various activities.




Image 3: A person engaged in physical activity, wearing the Rock Space EB10 earbuds, demonstrating their secure fit during movement.

## 4. OPERATING INSTRUCTIONS

The Rock Space EB10 earphones feature touch controls for managing audio playback and calls.

### 4.1 Power On/Off

- **Power On:** Remove earbuds from the charging case. They will power on automatically.
- **Power Off:** Place earbuds back into the charging case. They will power off automatically and begin charging.

## 4.2 Music Playback

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.

## 4.3 Call Management

- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.




Image 4: A person relaxing on a couch, wearing the Rock Space EB10 earbuds, illustrating their suitability for casual listening.

## 5. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and performance of your Rock Space EB10 earphones.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Ear Tips:** Remove ear tips periodically and clean them with a mild soap solution, then rinse and dry



thoroughly before reattaching.

- **Charging Contacts:** Ensure the charging contacts on both the earbuds and the case are clean and free of debris to maintain proper charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Moisture:** Do not expose the earbuds or charging case to liquids or extreme humidity.

## 6. TROUBLESHOOTING

If you encounter issues with your Rock Space EB10 earphones, refer to the following common solutions:

- **Earbuds not pairing with each other:** Place both earbuds back into the charging case, then remove them simultaneously. They should automatically connect.
- **Earbuds not connecting to device:** Ensure Bluetooth is enabled on your device. Forget the "Rock Space EB10" from your device's Bluetooth list and attempt to pair again. Ensure earbuds are charged.
- **No sound from one earbud:** Check if both earbuds are charged. Try placing them back in the case and removing them again. If the issue persists, reset the earbuds (refer to manufacturer's website for specific reset instructions if not detailed here).
- **Charging issues:** Ensure the charging cable is securely connected and the power source is functional. Clean the charging contacts on both the earbuds and the case.
- **Low volume or poor sound quality:** Adjust the volume on your connected device. Ensure ear tips are clean and provide a proper seal in your ear canal.

## 7. SPECIFICATIONS

Feature	Specification
Model Name	EB10
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Included Components	Ear Cushions
Material	Plastic
Compatible Devices	Smartphones, Tablets, Laptops, Desktops
Cable Feature	Without Cable
Item Weight (Earbuds)	Approximately 5.5g each
Control Method	Touch
Earpiece Shape	Rounded Tips
Form Factor	Earbuds, In-ear
Manufacturer	Shenzhen Renqing technology co,ltd
Product Dimensions	16 x 20 x 20 cm (packaging)

Item Part Number	EBT10TW
Color	Black
Ear Placement	In Ear



## 8. WARRANTY AND SUPPORT


The Rock Space EB10 True Wireless Stereo Earphones come with a **6-month warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support or warranty inquiries, please contact your retailer or the manufacturer directly. Refer to the product packaging for contact information.

© 2023 rock space. All rights reserved.


### Related Documents - EB10

	<p><a href="#">rock space AC2100 Dual Band Gigabit WiFi Router Quick Installation Guide</a></p> <p>Concise guide for setting up the rock space AC2100 Dual Band Gigabit WiFi Router, covering basic installation and wireless network configuration.</p>
	<p><a href="#">Rock Space AX1800 Dual-Band Wi-Fi 6 Router Quick Installation Guide</a></p> <p>A quick installation guide for the Rock Space AX1800 Dual-Band Wi-Fi 6 Router (Model RSD0619), covering hardware connection, configuration via the RS Home App or web browser, and frequently asked questions.</p>
	<p><a href="#">rock space Photo Printer User Manual</a></p> <p>Comprehensive user manual for the rock space Photo Printer (Model IM001-15001). Provides detailed instructions on setup, connection, installation of consumables, operation, maintenance, and troubleshooting. Includes product specifications and contact information.</p>




### [Rock Space AC1200 Dual Band WiFi Repeater Quick Install Guide](#)

A quick install guide for the Rock Space AC1200 Dual Band WiFi Repeater, Model: RSD0608, detailing setup methods using Web UI and WPS, LED descriptions, and relocation tips.



### [Rock Space AC1200 Dual Band WiFi Repeater Quick Installation Guide](#)

Enhance your home or office wireless network coverage with the Rock Space AC1200 Dual Band WiFi Repeater (Model: RSD0608). This guide provides clear, step-by-step instructions for setup via Web UI or WPS, LED indicator explanations, and troubleshooting tips to improve your WiFi signal.



### [rock space AC750 WiFi Extender Quick Install Guide](#)

Quick Install Guide for the rock space AC750 Dual Band WiFi Repeater (Model: RSD0607). Learn setup methods, LED descriptions, relocation tips, and FAQs for extending your WiFi network.