



[Manuals.plus](#) /

› [TR Industrial](#) /

› TR Industrial High Performance Demolition Hammer Oil User Manual

TR Industrial TR89115

TR Industrial High Performance Demolition Hammer Oil User Manual

Model: TR89115

1. PRODUCT OVERVIEW

This manual provides essential information for the safe and effective use of TR Industrial High Performance Demolition Hammer Oil. This specialized lubricant is designed to ensure optimal performance and longevity for your TR-100 and TR-300 series Demolition Hammers.



Image of the TR Industrial High Performance Demolition Hammer Oil tube, a clear plastic tube containing amber-colored oil with a white screw cap. The label shows 'TR Industrial' logo and '15-40W DEMOLITION HAMMER OIL (2.82 OZ)'.
CAUTION: Oil is designed for use with TR-100 and TR-300 series demolition hammers only. Continuous contact with used oil has been shown to cause skin cancer in laboratory animals. In case of skin contact, wash thoroughly with soap and water immediately. Avoid ingestion and eye contact. If swallowed, do not induce vomiting; seek medical attention immediately. If oil gets into eyes, flush with water for several minutes and consult a physician. Protect the environment: Do not dispose of used oil in drains, on the ground, or in regular trash. Return used oil to designated collection centers or authorized recycling facilities.

2. SAFETY INFORMATION

WARNING:

- Oil is designed for use with TR-100 and TR-300 series demolition hammers only.
- Continuous contact with used oil has been shown to cause skin cancer in laboratory animals.
- Always use appropriate personal protective equipment, including **gloves**, when handling both new and used oil.
- In case of skin contact, wash thoroughly with soap and water immediately.
- Avoid ingestion and eye contact. If swallowed, do not induce vomiting; seek medical attention immediately. If oil gets into eyes, flush with water for several minutes and consult a physician.
- Protect the environment: Do not dispose of used oil in drains, on the ground, or in regular trash. Return used oil to designated collection centers or authorized recycling facilities.

3. SETUP AND PREPARATION

1. Ensure your demolition hammer is powered off and unplugged from its power source before beginning any maintenance.

2. Locate the oil fill port on your TR-100 or TR-300 series demolition hammer. Refer to your hammer's specific user manual for the exact location.
3. Clean the area around the oil fill port to prevent dirt or debris from entering the oil reservoir.
4. Prepare a clean, stable surface for the hammer during the oiling process.

4. OPERATING INSTRUCTIONS (OIL FILLING)

Each tube of TR Industrial Demolition Hammer Oil contains 2.82 oz, which is sufficient for a full refill of most compatible hammers.

- Carefully unscrew the cap from the TR Industrial Demolition Hammer Oil tube.
- Remove the oil reservoir cap from your demolition hammer.
- Slowly dispense the oil into the hammer's oil reservoir. Observe the fill level carefully.
- **Suggested Oil Fill Volumes:**
 - For TR-100 series hammers: Approximately 2.29 oz
 - For TR-300 series hammers: Approximately 1.94 oz
- Do not overfill the reservoir. Overfilling can lead to leaks or improper hammer operation.
- Once the appropriate volume of oil has been added, securely replace the oil reservoir cap on your hammer.
- Replace the screw cap on the oil tube for easy storage of any remaining oil.

5. MAINTENANCE

- Regularly check the oil level in your demolition hammer as part of routine maintenance to ensure continuous optimal lubrication.
- Replace the oil according to the maintenance schedule specified in your demolition hammer's user manual, or if you notice a decrease in performance that could be attributed to low or degraded oil.
- Always dispose of used oil responsibly at certified collection centers.

6. TROUBLESHOOTING

If your demolition hammer's performance does not improve after an oil change, consider the following:

- Verify that the correct oil volume was added according to the specifications for your hammer model.
- Ensure the oil reservoir cap is securely sealed to prevent leaks or contamination.
- Check for any other maintenance requirements or issues outlined in your demolition hammer's specific user manual.
- If issues persist, contact TR Industrial customer support or a qualified service technician.

7. SPECIFICATIONS

| Attribute | Detail |
|--------------|---------------|
| Brand | TR Industrial |
| Model Number | TR89115 |
| Item Form | Oil |

| Attribute | Detail |
|---------------------------|---|
| Liquid Volume (per tube) | 2.82 Fluid Ounces |
| Item Weight (per tube) | 0.25 Pounds (approx. 4 ounces) |
| Product Dimensions (tube) | 6 x 2 x 2 inches |
| Material (tube) | Plastic Tubing |
| UPC | 886352891158 |
| Specific Uses | TR-100 and TR-300 series Demolition Hammers |

8. WARRANTY INFORMATION

For specific warranty details regarding your TR Industrial High Performance Demolition Hammer Oil, please refer to the product packaging or the official TR Industrial website. It is recommended to retain your purchase receipt as proof of purchase for any warranty claims.

9. CUSTOMER SUPPORT

For further assistance, technical support, or any inquiries regarding TR Industrial products, please visit the official TR Industrial website or contact their customer service department.

You can also visit the TR Industrial store on Amazon: [TR Industrial Amazon Store](#)