



[Manuals.plus](#) /

› [HON](#) /

› HON Ignition 4-Leg Guest Chair User Manual

HON HONIG107CU10

HON Ignition 4-Leg Guest Chair User Manual

Model: HONIG107CU10

INTRODUCTION

This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your HON Ignition 4-Leg Guest Chair. Please read these instructions carefully before using the product to ensure proper function and longevity.



Image 1: Front view of the HON Ignition 4-Leg Guest Chair.

SAFETY INFORMATION

- Do not exceed the maximum weight capacity of 300 lbs (136 kg).
- Ensure all components are securely fastened before use.
- Use the chair on a level surface to prevent tipping.
- Keep children away from assembly parts.

SETUP AND ASSEMBLY

While the HON Ignition 4-Leg Guest Chair is designed for minimal assembly, some steps may be required to prepare it for use.

Required Tools:

- No special tools are typically required for this chair. Any necessary tools are usually included.

Assembly Steps:

1. Carefully unpack all components and verify against the packing list.
2. Place the chair seat upside down on a soft, non-abrasive surface to prevent scratches.
3. Attach the four-leg base to the underside of the seat using the provided hardware. Ensure all screws are tightened securely.
4. Turn the chair upright and ensure it is stable.
5. Confirm that the glides on the base are properly seated to protect flooring.

Note: The chair features a durable steel frame and fixed arms, which are typically pre-assembled to the seat and back unit.

OPERATING INSTRUCTIONS

The HON Ignition 4-Leg Guest Chair is designed for straightforward use in various office and common area settings.

General Use:

- Sit centrally on the seat with your back against the backrest for optimal support.
- The chair is designed for stationary use. Avoid rocking or standing on the chair.
- The fixed arms provide support when sitting or rising from the chair.

Stacking (if applicable):

This guest chair is designed to stack up to four high for efficient storage.

1. Lift the chair by its frame, ensuring a firm grip.
2. Carefully place it onto another identical chair, aligning the legs and seat to ensure stability.
3. Do not stack more than four chairs high to prevent instability and potential damage.

MAINTENANCE AND CARE

Regular maintenance will help preserve the appearance and extend the life of your HON Ignition 4-Leg Guest Chair.

Cleaning Instructions:

- **Fabric Upholstery:** The polyester fabric features Nano-Tex soil-repellent and stain-repellent technology. For general cleaning, vacuum regularly to remove dust and loose particles. For spills or stains, **spot clean** immediately with a mild, water-free solvent or upholstery shampoo. Test a small, inconspicuous area first. Do not saturate the fabric.
- **Frame and Base:** Wipe the steel frame and base with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.

Periodic Checks:

- Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary.
- Inspect glides for wear and tear. Replace if damaged to protect flooring.

TROUBLESHOOTING

This section addresses common issues you might encounter with your guest chair.

Problem	Possible Cause	Solution
Chair feels unstable or wobbly.	Loose fasteners or uneven floor surface.	Check and tighten all assembly screws. Ensure the chair is on a flat, level surface.
Squeaking noises during use.	Loose connections or friction between components.	Tighten all screws. If noise persists, apply a small amount of silicone lubricant to connection points (avoiding fabric).
Damage to flooring.	Worn or missing glides.	Inspect glides on the chair's base. Replace any worn or missing glides.

SPECIFICATIONS

Detailed specifications for the HON Ignition 4-Leg Guest Chair (Model HONIG107CU10).

Model Name: HON Ignition 4-Leg Guest Chair

Model Number: HONIG107CU10

Brand: HON

Color: Black

Material: Wood (core structures), Alloy Steel (frame), Polyester (seat material), Foam (fill material)

Product Dimensions (Overall): 27"D x 26"W x 39"H (68.6 cm D x 66 cm W x 99.1 cm H)

Seat Dimensions: 19.5" W x 16.75" D (49.5 cm W x 42.5 cm D)

Back Dimensions: 19.5" W x 20" H (49.5 cm W x 50.8 cm H)

Seat-to-Floor Distance: 18.5" (47 cm)

Item Weight: 41 lbs (18.6 kg)

Maximum Weight Recommendation: 300 lbs (136 kg)

Assembly: Required (minimal)

Care Instructions: Spot Clean

Features: Fixed arms, four-leg base with glides, stackable (up to 4 high), Nano-Tex soil/stain-repellent fabric, deeply sculpted lumbar support, wall-saver leg design.

Certifications: Meets or exceeds applicable ANSI/BIFMA standards.

WARRANTY INFORMATION

The HON Ignition 4-Leg Guest Chair is backed by the **HON Full Lifetime Warranty**. This warranty covers defects in materials and workmanship for the lifetime of the original owner. For specific terms, conditions, and to make a warranty claim, please refer to the official HON website or contact HON customer support.

CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about parts, please contact HON customer service.

Website: Visit the official HON website for FAQs and support resources.

Contact: Refer to the HON website for current contact information, including phone numbers and email support.

Note: Always have your product model number (HONIG107CU10) and purchase information ready when contacting support.

