

Fridja F-10

Fridja F10 Handheld Clothes Steamer User Manual

Model: F-10

1. INTRODUCTION

Thank you for purchasing the Fridja F10 Handheld Clothes Steamer. This powerful and portable steamer is designed to quickly and efficiently remove wrinkles from various fabrics, refresh garments, and even eliminate bacteria. Its compact design makes it ideal for both home use and travel. Please read this manual thoroughly before operating the appliance to ensure safe and optimal performance.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Use the appliance only for its intended use.
- To protect against the risk of electric shock, do not immerse the steamer in water or other liquids.
- Always turn off and unplug the appliance from the electrical outlet before filling or emptying the water tank, and when not in use.
- Do not operate the appliance with a damaged cord or plug, or if the appliance has been dropped or damaged.
- Do not allow the cord to touch hot surfaces.
- Always ensure the water tank is securely attached before operating.
- Do not direct steam at people, pets, or electrical appliances. Steam is hot and can cause burns.
- Use caution when handling hot parts, hot water, or steam.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PRODUCT OVERVIEW

3.1 Components



Figure 3.1: Fridja F10 Handheld Steamer with included accessories: delicate fabric guard, collar press, and water bottle adapter.

**Water bottle adapter:
Travel light, skip the tank.**

**Use the collar press:
Perfect collars and cuffs**



**Folding hanger, easy to steam
when on the go.**

Carry bag included

Figure 3.2: Close-up of the accessory kit, including the water bottle adapter, collar press, folding hanger, and carry bag.

The Fridja F10 Handheld Steamer comes with several useful accessories to enhance your steaming experience:

- **Main Steamer Unit:** The core device with a detachable water tank and steam nozzle.
- **Delicate Fabric Guard:** Protects delicate fabrics like silk and velvet from direct contact with the hot plate.
- **Collar Press:** Helps to achieve crisp collars and cuffs.
- **Portable Hook:** For hanging garments while steaming.
- **Water Bottle Adapter:** Allows you to use a standard water bottle as a water reservoir, ideal for travel.
- **Carry Bag:** For convenient storage and portability.

3.2 Specifications

Feature	Specification
Model	F-10

Feature	Specification
Power	1500 Watts
Voltage	230V
Water Tank Capacity	260 ml
Heat-up Time	Approx. 35 seconds
Continuous Steam Time	Up to 14 minutes
Weight	900 grams
Dimensions (L x W x H)	12 x 15 x 22 cm
Materials	Stainless Steel, Plastic
Cord Length	1.95 meters



1.95M
Cord



1500 Watt
Power



14 Minutes
Continuous
Steam



Ready In
35 Seconds



998g



Figure 3.3: Visual representation of key specifications including power, steam time, heat-up time, and weight.



Figure 3.4: The steamer's compact dimensions (12 x 15 x 22 cm) making it suitable for travel.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Fill Water Tank:**
 - Detach the water tank from the main unit by pulling it downwards.
 - Open the rubber stopper at the bottom of the tank.
 - Fill the tank with distilled or de-mineralized water up to the 'MAX' line. Do not overfill.
 - Close the rubber stopper securely and reattach the water tank to the main unit until it clicks into place.
 - Alternatively, for travel, use the water bottle adapter to connect a standard water bottle as your reservoir.
3. **Attach Accessories (Optional):**
 - For delicate fabrics, attach the delicate fabric guard over the steam nozzle.

- For collars and cuffs, use the collar press.

4. **Plug In:** Plug the power cord into a suitable electrical outlet (230V).

5. OPERATING INSTRUCTIONS



Powerful handheld clothes steamer. Ready in 35 seconds.



Figure 5.1: The Fridja F10 steamer in use, demonstrating its quick heat-up time and powerful steam output.

1. **Power On:** Press the power button. The indicator light will illuminate, and the steamer will begin to heat up. It will be ready for use in approximately 35 seconds.
2. **Select Steam Mode:** The F10 offers dual modes:
 - **Eco Mode:** For lighter fabrics and energy saving.
 - **Full Power Mode:** For heavier fabrics and stubborn wrinkles, providing 30g of thick, dense steam per minute.Switch between modes using the designated button or trigger, depending on your model variant.
3. **Steaming Garments:**

- Hang the garment on a hanger or use the portable hook.
- Hold the steamer upright, ensuring the water tank is below the steam nozzle.
- Gently pull the fabric taut with your free hand.
- Move the steam nozzle slowly downwards over the fabric, allowing the steam to penetrate and relax the fibers.
- For stubborn wrinkles, pass the steamer over the area multiple times.
- For delicate fabrics, use the delicate fabric guard to prevent direct contact with the hot plate.

- 4. Refreshing Furniture and Upholstery:** The steamer can also be used to refresh curtains, upholstery, bedding, and mattresses. Hold the steamer a few inches away from the surface and move it slowly. The high-temperature steam helps to kill 99.9% of bacteria.
- 5. Auto Shut-off:** The steamer is equipped with an automatic shut-off feature for safety when the water tank is empty or if the unit overheats.
- 6. After Use:** Turn off the steamer and unplug it from the outlet. Allow it to cool down completely before emptying any remaining water and storing.



Figure 5.2: Key features of the F10 steamer, including steam output, heated ironing plate, detachable water tank, dual modes, and

continuous steam button.



Figure 5.3: Demonstrating the use of the delicate fabric guard for sensitive materials like silk, velvet, and wool.

6. MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and optimal performance of your Fridja F10 Steamer.

- Empty Water Tank:** After each use, ensure the steamer has cooled down, then detach and empty any remaining water from the tank. This prevents mineral buildup.
- Descaling (Anti-Calc):** The F10 features an anti-calc water tank. However, if you notice reduced steam output or mineral residue, descaling may be necessary.
 - Mix a solution of 50% white vinegar and 50% water.
 - Fill the water tank with this solution.
 - Plug in the steamer and allow it to heat up.
 - Steam the solution until the tank is empty.

- Repeat with fresh, clean water to rinse out any vinegar residue.

Perform descaling every few months, or more frequently if you use hard water.

- Cleaning the Exterior:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Storage:** Store the steamer in a cool, dry place, preferably in its carry bag, away from direct sunlight and moisture. Ensure the water tank is empty before storage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or very little steam.	Water tank is empty. Steamer not heated up. Mineral buildup (calcification).	Refill water tank. Wait approximately 35 seconds for the steamer to heat up. Perform descaling procedure (refer to Section 6).
Water spitting from nozzle.	Overfilled water tank. Steamer not fully heated. Mineral buildup.	Do not fill past the 'MAX' line. Allow steamer to fully heat before use. Perform descaling procedure.
Steamer not turning on.	Not plugged in correctly. Power outlet issue. Safety auto shut-off activated.	Ensure plug is fully inserted. Test outlet with another appliance. Check water level, allow to cool down, then restart.
Wrinkles not removing effectively.	Not enough steam. Steaming too quickly. Incorrect mode selected.	Ensure water tank is full and steamer is fully heated. Move steamer slower over the fabric. Switch to Full Power Mode for tougher wrinkles.

If the problem persists after trying these solutions, please contact Fridja customer support.

8. WARRANTY AND SUPPORT

Fridja products are designed with quality and durability in mind. For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official Fridja website. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, you may contact Fridja customer service through their official channels. Please have your model number (F-10) and purchase details ready when contacting support.

 <p>Fridja f2500 Self Feeding Slow Juicer Instruction Manual</p>	<p>Comprehensive instruction manual for the Fridja f2500 Self Feeding Slow Juicer, covering assembly, operation, cleaning, safety, troubleshooting, and warranty information.</p>
 <p>Fridja f1900 Whole Fruit Slow Juicer: Instruction Manual</p>	<p>Comprehensive instruction manual for the Fridja f1900 Whole Fruit Slow Juicer. Learn how to assemble, operate, clean, and troubleshoot your juicer for optimal performance and healthy juice extraction.</p>
 <p>Fridja f900 Automatic Citrus Juicer Instruction Manual</p>	<p>Detailed instruction manual for the Fridja f900 Automatic Citrus Juicer. Learn about safety precautions, assembly, operation, cleaning, troubleshooting common issues, plug safety, proper disposal, and warranty information for your Fridja juicer.</p>
 <p>Fridja f77 Super Oven Pro Instruction Manual - Digital Air Fryer Oven</p>	<p>Comprehensive instruction manual for the Fridja f77 Super Oven Pro, a 30L digital air fryer oven. Learn about its features, specifications, safety guidelines, operation, cleaning, and maintenance.</p>
 <p>Philips STH7030/10 Garment Steamer: User Manual & Instructions</p>	<p>Get the most out of your Philips STH7030/10 garment steamer with this official user manual. Find detailed instructions, usage tips, maintenance advice, and safety information for effortless garment care.</p>
 <p>Philips 1000 Series Handheld Steamer User Manual</p>	<p>Comprehensive user manual for the Philips 1000 Series Handheld Steamer (STH1010/10), providing instructions on usage, maintenance, and troubleshooting in multiple languages.</p>

