

Grandeur 813868

Grandeur 813868 Carre' Tall Plate Biarritz Passage Door Knob Instruction Manual

Model: 813868 | Finish: Polished Brass | Backset: 2.75 inches

1. PRODUCT OVERVIEW

The Grandeur 813868 Carre' Tall Plate Biarritz Passage Door Knob is designed for interior doors where a locking mechanism is not required, such as hallways or closet doors. This model features a distinctive tall plate design, ideal for doors 84 inches or higher, ensuring an aesthetically balanced appearance. Crafted from solid, forged brass, it offers durability and a polished brass finish for a classic look. This passage knob is designed for a 2.75-inch backset.





Image 1.1: Grandeur Carre' Tall Plate Biarritz Passage Door Knob. This image displays the polished brass tall plate with a clear, faceted Biarritz knob, designed for interior passage doors.

2. SAFETY INFORMATION

- Always wear appropriate personal protective equipment, such as safety glasses, during installation.
- Keep small parts away from children to prevent choking hazards.
- Exercise caution when using power tools to avoid injury.
- Ensure all screws are tightened securely, but do not overtighten, which could strip threads or damage components.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Exterior Door Knob with Tall Plate

- Interior Door Knob with Tall Plate
- Latch Mechanism (for 2.75" backset)
- Standard Spindle
- Strike Plate
- Mounting Screws
- Drilling Template (if applicable)

4. SETUP AND INSTALLATION

Tools Required: Phillips head screwdriver, tape measure, pencil, drill (if door is not pre-drilled), wood chisel (optional).

1. **Prepare the Door:** Ensure your door has standard bore holes (typically 2-1/8" diameter) and a cross bore for the latch. The backset (distance from door edge to center of bore hole) should be 2.75 inches. If not pre-drilled, use the provided drilling template to mark and drill the necessary holes.
2. **Install the Latch Mechanism:** Insert the latch mechanism into the cross bore hole on the edge of the door. Ensure the bevel of the latch bolt faces the door frame. Secure the latch faceplate with the provided screws. If necessary, use a wood chisel to create a shallow mortise for the faceplate to sit flush with the door edge.
3. **Install the Exterior Knob Assembly:** Place the exterior knob assembly (knob and tall plate) onto the door, aligning the spindle receiver with the latch mechanism.
4. **Insert the Spindle:** Insert the square spindle through the latch mechanism from the exterior side, ensuring it passes through the spindle receiver on the exterior knob.
5. **Install the Interior Knob Assembly:** Position the interior knob assembly over the spindle and align the mounting posts with the holes on the exterior plate.
6. **Secure the Assemblies:** Insert the long mounting screws through the interior plate and into the mounting posts on the exterior plate. Tighten the screws evenly until the knob assemblies are secure and flush against the door. Do not overtighten.
7. **Install the Strike Plate:** Close the door and mark the position of the latch bolt on the door frame. Chisel out a shallow mortise for the strike plate and secure it with the provided screws. Ensure the latch bolt engages smoothly with the strike plate.
8. **Test Operation:** Turn both the interior and exterior knobs to ensure the latch retracts smoothly. Check that the door closes and latches properly.

5. OPERATING INSTRUCTIONS

To open a door equipped with the Grandeur 813868 Passage Door Knob, simply turn the knob in either direction. The latch bolt will retract, allowing the door to open. Release the knob to allow the latch bolt to extend and secure the door when closed.

6. MAINTENANCE

- **Cleaning:** Clean the polished brass finish with a soft, damp cloth. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Lubrication:** If the latch mechanism becomes stiff over time, a small amount of silicone-based lubricant can be applied to the moving parts of the latch bolt. Do not use oil-based lubricants, which can attract dust and grime.
- **Tightening:** Periodically check and tighten any loose mounting screws to ensure optimal performance and prevent wobbling.

7. TROUBLESHOOTING

- **Knob is loose or wobbly:**
Ensure all mounting screws are securely tightened. If the screws are stripped, they may need to be replaced with slightly larger ones or the holes repaired.
- **Latch bolt does not retract smoothly:**
Check for any obstructions in the latch mechanism or the strike plate. Ensure the spindle is correctly aligned and not binding. Apply a silicone-based lubricant if necessary.
- **Door does not latch properly:**
Verify that the strike plate is correctly aligned with the latch bolt. Adjust the strike plate position if needed. Ensure the door frame is not warped.






8. SPECIFICATIONS

Feature	Detail
Brand	Grandeur
Model Number	813868
Product Type	Passage Door Knob with Tall Plate
Finish	Polished Brass
Exterior Finish Material	Brass
Handle Material	Brass
Backset	2.75 inches
Specific Uses	Inside Doors (e.g., hallways, closets)
Special Feature	Easy to Install
Item Weight	5.75 pounds
Product Dimensions	2.62 x 2.5 x 11 inches
Number of Pieces	6 (components)
Batteries Required	No

9. WARRANTY AND SUPPORT

This Grandeur product is backed by a **Lifetime Warranty**. For warranty claims, technical assistance, or replacement parts, please contact Grandeur customer support directly. Refer to the official Grandeur website or your purchase documentation for specific contact information.

For additional information, you may visit the [Grandeur Store on Amazon](#).

	<p>Grandeur Gas Range Use and Care Guide: Models URY3055AS, URY3655AS, URY4855AS</p> <p>Comprehensive use and care guide for Grandeur gas ranges, including safety instructions, operation, cleaning, and troubleshooting for models URY3055AS, URY3655AS, and URY4855AS.</p>
	<p>Grandeur 36-Inch 6-Burner Gas Range - Grand Assurance Warranty Information</p> <p>Details the Grandeur Grand Assurance Warranty for 36-inch 6-burner gas ranges, covering 2-Year Parts & Labor and 10-Year Limited Warranty. Register online for peace of mind.</p>
	<p>Prop 65 Warning for Grandeur Gas Ranges</p> <p>California Proposition 65 warning for Grandeur gas ranges, detailing potential exposure to lead and its health risks. Information provided for Grandeur URY3655AS and URY3055AS models.</p>
	<p>Grandeur URY3655AS 36-Inch Freestanding Professional Gas Range - Specifications & Features</p> <p>Explore the Grandeur URY3655AS, a 36-inch freestanding professional gas range featuring 6 high-powered sealed burners, a 5.2 cu. ft. oven, commercial convection fan, and durable cast-iron grates. Detailed specifications and features for this stainless steel appliance.</p>
	<p>Bosma Aegis Lock Compatibility Guide</p> <p>A comprehensive guide detailing the compatibility of the Bosma Aegis Lock with various deadbolt brands and models, door specifications, WiFi requirements, and mobile device support.</p>