

Grandeur 842277

Grandeur 842277 Carre' One-Piece Handleset Instruction Manual

Model: 842277 | Brand: Grandeur

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Grandeur 842277 Carre' One-Piece Handleset. Please read all instructions carefully before beginning installation to ensure proper function and longevity of your hardware.

PRODUCT OVERVIEW

The Grandeur 842277 Carre' One-Piece Handleset is designed for exterior doors, featuring a C Grip and Circulaire Knob with a single cylinder lock mechanism. It is constructed from solid, forged brass and finished in Antique Pewter.

Key Features:

- Made of solid, forged brass for long-lasting durability.
- Ideal for doors 84 inches or higher, providing appropriate scale.
- Includes drilling template and mounting hardware for straightforward installation.
- Available with various Grandeur hardware door knobs and levers.

Included Components:

- Deadbolt latch and kit with cylinder
- Exterior one-piece handleset trim with grip
- Interior tall plate trim with turn
- Passage latch and kit
- Screws for installation
- Two keys



Image: Grandeur 842277 Carre' One-Piece Handleset in Antique Pewter. This image displays the complete handleset, including the exterior grip, deadbolt, and interior knob/lever components.

SETUP AND INSTALLATION

Proper installation is crucial for the security and functionality of your handleset. A drilling template and all

necessary mounting hardware are included to facilitate the process.

General Installation Steps:

1. **Prepare the Door:** Ensure your door is properly prepped according to the included drilling template. Verify the backset measurement (2.75" for this model) and bore hole diameters.
2. **Install Latches:** Insert the deadbolt latch and passage latch into the door edge. Secure them with the provided screws.
3. **Install Exterior Handleset:** Position the exterior one-piece handleset with the C grip and deadbolt cylinder through the door.
4. **Install Interior Components:** Attach the interior tall plate trim and Circulaire knob/lever, aligning them with the exterior components.
5. **Secure Components:** Fasten all components using the provided screws, ensuring they are snug but not overtightened. Test the operation of both the deadbolt and the passage latch.
6. **Adjust and Test:** Make any necessary adjustments to ensure smooth operation of the lock and latch mechanisms.

For detailed, step-by-step visual guidance, refer to the specific drilling template and installation instructions packaged with your handleset.

OPERATING INSTRUCTIONS

The Grandeur 842277 handleset features a single cylinder lock, providing secure entry and exit.

Locking and Unlocking from Exterior:

- To lock the deadbolt, insert the key into the cylinder and turn it until the deadbolt extends fully into the door frame. Remove the key.
- To unlock the deadbolt, insert the key into the cylinder and turn it until the deadbolt retracts. Remove the key.
- To open the door, depress the C grip thumb latch.

Locking and Unlocking from Interior:

- To lock the deadbolt, rotate the turn piece on the interior trim until the deadbolt extends fully.
- To unlock the deadbolt, rotate the turn piece on the interior trim until the deadbolt retracts.
- To open the door, turn the Circulaire knob/lever.

MAINTENANCE

Regular maintenance helps preserve the finish and functionality of your Grandeur handleset.

- **Cleaning:** Clean the handleset regularly with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or polishing agents, as these can damage the Antique Pewter finish.
- **Lubrication:** Periodically apply a small amount of graphite lubricant or a silicone-based spray to the keyway and the latch mechanisms to ensure smooth operation. Do not use oil-based lubricants, as they can attract dust and debris.
- **Inspection:** Periodically check all screws and fasteners to ensure they are tight. Loose components can affect performance and security.

TROUBLESHOOTING

If you encounter issues with your handleset, refer to the following common solutions:

Problem	Possible Cause	Solution
Key is difficult to insert or turn.	Dirt in keyway, worn key, or lack of lubrication.	Clean keyway with compressed air. Lubricate with graphite powder. Try a spare key.
Deadbolt or latch does not extend/retract smoothly.	Misalignment with strike plate, loose screws, or debris in mechanism.	Check strike plate alignment and adjust if necessary. Tighten all mounting screws. Lubricate the latch mechanism.
Handleset feels loose.	Mounting screws are loose.	Tighten all visible mounting screws on both interior and exterior components.

If problems persist after attempting these solutions, contact Grandeur customer support.

SPECIFICATIONS

Feature	Detail
Brand	Grandeur
Model Number	842277
Color	Antique Pewter
Exterior Finish	Pewter
Specific Uses	Outside doors
Lock Type	Single Cylinder Key Lock
Item Weight	7 Pounds (approx. 3.17 kg)
Metal Type	Brass
Handle Material	Bronze
Product Dimensions	0.5 x 3 x 19 inches (approx. 1.27 x 7.62 x 48.26 cm)
Size	Single Cylinder Lock - 2.75" Backset
UPC	662972422770

WARRANTY AND SUPPORT

Grandeur stands behind the quality of its products.

- **Warranty:** This Grandeur handleset is covered by a **Lifetime Warranty**. Please retain your proof of purchase for warranty claims.
- **Manufacturer:** Grandeur Hardware
- **Customer Support:** For technical assistance, warranty service, or to inquire about replacement parts, please contact Grandeur customer support through their official website or the retailer where the product was purchased.

