

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Grandeur](#) /

› [Grandeur 837256 Carre' Tall Plate Fifth Avenue Left-Handed Privacy Knob Installation and User Manual](#)

Grandeur 837256

Grandeur 837256 Carre' Tall Plate Fifth Avenue Left-Handed Privacy Knob User Manual

MODEL: 837256

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Grandeur Carre' Tall Plate Fifth Avenue Left-Handed Privacy Knob. Please read these instructions carefully before beginning installation to ensure proper function and longevity of your product. Retain this manual for future reference.

Product Overview

The Grandeur Carre' Tall Plate Fifth Avenue Knob is designed for interior doors requiring a privacy function. It features a tall plate design, suitable for doors 84 inches or higher, and a classic Fifth Avenue knob. This specific model is a left-handed privacy knob with a 2.375-inch backset and a timeless bronze finish.





A close-up view of the Grandeur Carre' Tall Plate Fifth Avenue Knob, featuring a timeless bronze finish. The tall rectangular plate has a classic stepped edge design, and the round knob is positioned towards the bottom of the plate.

Safety Information

- Always wear appropriate personal protective equipment, such as safety glasses, during installation.
- Keep small components out of reach of children to prevent choking hazards.
- Use only the tools specified in the installation instructions.
- Ensure the door is securely supported if removed from its hinges during installation.

Package Contents

Verify that all components are present before beginning installation:

- Door knob and chosen tall plate for both sides of door
- Latch mechanism
- Privacy spindle
- Privacy pin
- Strike plate
- Mounting screws
- Drilling template (if applicable)

Installation

Installation requires basic hand tools such as a screwdriver, measuring tape, and possibly a drill. A drilling template is included for new door preparations.

1. **Prepare the Door:** If installing on a new door, use the provided drilling template to mark and drill holes for the latch mechanism and the knob assembly. Ensure the backset (distance from the door edge to the center of the knob hole) is 2.375 inches.
2. **Install the Latch Mechanism:** Insert the latch mechanism into the edge of the door. Secure it with the provided screws. Ensure the latch bolt faces the correct direction for the door swing.
3. **Determine Handedness:** This is a left-handed privacy knob. If the hinges are located on the left side of the door when viewed from the side where the knob will be installed, then this left-handed knob is correct. The privacy pin will be located on the right side of the knob when installed.
4. **Assemble the Knob:** Insert the privacy spindle through the latch mechanism. Attach the exterior knob and tall plate assembly, ensuring the spindle engages properly.
5. **Install Interior Knob:** Place the interior knob and tall plate assembly over the spindle and secure it to the exterior assembly using the mounting screws. Tighten screws evenly to prevent misalignment.
6. **Install Strike Plate:** On the door frame, mark and chisel out an area for the strike plate. Secure the strike plate with screws, ensuring the latch bolt engages smoothly.

Operation

To operate the privacy knob:

- **Locking:** From the interior side, press the privacy pin located on the knob's base. This will prevent the exterior knob from turning.
- **Unlocking:** Turn the interior knob to retract the latch bolt and unlock the door. In an emergency, the privacy function can be disengaged from the exterior side using a small tool inserted into the emergency release hole.
- **Opening:** Turn either the interior or exterior knob to retract the latch bolt and open the door.

Maintenance

To maintain the appearance and function of your Grandeur door knob:

- **Cleaning:** Clean the knob and plate with a soft, damp cloth. Avoid abrasive cleaners, solvents, or

polishing agents, as these can damage the finish.

- **Lubrication:** Periodically apply a small amount of silicone-based lubricant to the latch mechanism to ensure smooth operation. Do not use oil-based lubricants.
- **Inspection:** Regularly check all screws and connections for tightness. Tighten as necessary to prevent wobbling or misalignment.

Troubleshooting

Problem	Possible Cause	Solution
Knob is loose or wobbly	Mounting screws are loose.	Tighten the mounting screws on the interior side of the knob.
Latch does not retract smoothly	Latch mechanism is dry or obstructed.	Apply silicone-based lubricant to the latch bolt. Check for debris in the latch bore.
Privacy function does not engage/disengage	Privacy pin or spindle misalignment.	Ensure the privacy spindle is correctly seated. Re-check handedness during installation.
Door does not latch properly	Strike plate misalignment or incorrect installation.	Adjust the strike plate position on the door frame. Ensure the latch bolt fully extends into the strike plate hole.

Specifications






- **Model Number:** 837256
- **Brand:** Grandeur
- **Product Type:** Privacy Door Knob with Tall Plate
- **Finish:** Timeless Bronze
- **Material:** Solid Forged Brass
- **Backset:** 2.375 inches
- **Handing:** Left-Handed
- **Plate Dimensions:** Approximately 2.66 x 11 inches
- **Item Weight:** Approximately 5.75 pounds
- **Special Features:** Easy to Install, Keyless Privacy Function

Warranty and Support

This Grandeur product is covered by a **Lifetime Warranty** against defects in material and workmanship. For warranty claims or technical support, please contact Grandeur customer service. Keep your proof of purchase for warranty validation.

For further assistance, please visit the official Grandeur website or contact their customer support directly.

Related Documents - 837256

 <p>GRANDEUR Use and Care Guide</p>	<p>Grandeur Gas Range Use and Care Guide: Models URY3055AS, URY3655AS, URY4855AS</p> <p>Comprehensive use and care guide for Grandeur gas ranges, including safety instructions, operation, cleaning, and troubleshooting for models URY3055AS, URY3655AS, and URY4855AS.</p>
	<p>Grandeur 36-Inch 6-Burner Gas Range - Grand Assurance Warranty Information</p> <p>Details the Grandeur Grand Assurance Warranty for 36-inch 6-burner gas ranges, covering 2-Year Parts & Labor and 10-Year Limited Warranty. Register online for peace of mind.</p>
	<p>Prop 65 Warning for Grandeur Gas Ranges</p> <p>California Proposition 65 warning for Grandeur gas ranges, detailing potential exposure to lead and its health risks. Information provided for Grandeur URY3655AS and URY3055AS models.</p>
	<p>Grandeur URY3655AS 36-Inch Freestanding Professional Gas Range - Specifications & Features</p> <p>Explore the Grandeur URY3655AS, a 36-inch freestanding professional gas range featuring 6 high-powered sealed burners, a 5.2 cu. ft. oven, commercial convection fan, and durable cast-iron grates. Detailed specifications and features for this stainless steel appliance.</p>
	<p>Bosma Aegis Lock Compatibility Guide</p> <p>A comprehensive guide detailing the compatibility of the Bosma Aegis Lock with various deadbolt brands and models, door specifications, WiFi requirements, and mobile device support.</p>