

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bush Furniture](#) /
- › [Bush Furniture Studio C 60W x 24D Credenza Desk \(Model SCD360WH\) Instruction Manual](#)

Bush Furniture SCD360WH

Bush Furniture Studio C 60W x 24D Credenza Desk

MODEL: SCD360WH

1. Introduction

This manual provides essential instructions for the assembly, operation, and maintenance of your Bush Furniture Studio C 60W x 24D Credenza Desk. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Studio C Credenza Desk is designed for both home and professional office environments, offering a durable and functional workspace. Its thermally fused laminate surface is engineered to resist scratches, stains, and dents, ensuring long-lasting appeal.

2. Safety Information

WARNING:

Assembly and use instructions include safety information. Always follow the provided instructions to ensure safe assembly and use. Failure to do so may result in injury or damage to the product.

- Ensure all components are present and undamaged before assembly.
- Do not overtighten screws, as this may damage the material.
- Keep small parts away from children during assembly.
- Place the desk on a level surface to prevent instability.
- Do not exceed the maximum weight recommendation of 200 pounds on the desktop.

3. Setup and Assembly

Assembly is required for this product. While it is designed for single-person assembly, having an additional person may ease the process. Please ensure you have adequate space and the necessary tools before starting.

3.1 Unpacking

Carefully unpack all components and lay them out on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches. Verify that all parts listed in the included assembly guide are present.

3.2 Assembly Steps

Refer to the detailed assembly instructions provided in the product packaging. General steps typically involve:

1. Attaching the side panels to the desktop.
2. Securing the back panel.
3. Installing any adjustable feet or glides.

Tip: Some users find it helpful to prop up the back panel with books or other objects to align it with the side panels during installation.



Figure 1: Assembled Bush Furniture Studio C 60W x 24D Credenza Desk in White.



Figure 2: Detail of the desk's durable edge and corner construction.

4. Operating Instructions

Your Studio C Credenza Desk is designed for versatile use in various office settings.

4.1 Workspace Utilization

The spacious 60-inch wide desktop provides ample room for your computer, monitors, documents, and other office essentials. The durable thermally fused laminate surface is built to withstand daily use.



Figure 3: The desk provides a spacious and functional workspace.

4.2 Wire Management

The desk includes a built-in wire management grommet to help keep cables and cords organized and out of sight, maintaining a tidy workspace.



Figure 4: The wire management grommet helps organize cables.

4.3 Configuration Options

The Studio C collection offers various coordinating storage and desk options, including mobile file cabinets, lateral files, hutches, and bookcases, allowing you to customize your office layout as needed. The desk's finished back panel allows for flexible placement within a room.

Your browser does not support the video tag.

Video 1: Overview of the Bush Business Furniture Studio C Collection, showcasing various configurations and finishes. This video highlights the versatility and design options available within the Studio C line.

5. Maintenance

To maintain the appearance and longevity of your Bush Furniture Studio C Credenza Desk, follow these simple care instructions:

- **Cleaning:** Wipe the surface with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the laminate finish.
- **Spills:** Clean up spills immediately to prevent staining.

- **Heat and Moisture:** Use coasters for beverages and protective pads for hot items to prevent damage to the desktop.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading.

6. Troubleshooting

If you encounter any issues with your desk, consider the following common solutions:

- **Wobbling Desk:** Ensure the desk is placed on a level surface. Check that all assembly hardware is securely tightened. If the desk has adjustable glides, adjust them to stabilize the unit.
- **Scratches/Dents:** While the laminate is resistant, minor cosmetic damage can occur. For small scratches, furniture repair markers or kits designed for laminate surfaces may help.
- **Missing Parts:** If any parts were missing upon delivery, contact Bush Furniture customer support immediately for assistance.

7. Specifications

Feature	Detail
Brand	Bush Furniture
Model Number	SCD360WH
Product Dimensions (D x W x H)	23.35"D x 59.45"W x 29.84"H
Color	White
Style	Commercial
Base Material	Engineered Wood
Top Material Type	Engineered Wood
Finish Type	White
Special Feature	Adjustable (feet/glides)
Item Weight	110.2 Pounds
Maximum Weight Recommendation	200 Pounds
Required Assembly	Yes
Recommended Number of People for Assembly	1
Product Care Instructions	Wipe with Damp Cloth

8. Warranty Information

The Bush Furniture Studio C 60W x 24D Credenza Desk is backed by the Bush Business Furniture **10 Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. Please refer to the warranty documentation included with your product for full terms and conditions, or visit the official Bush Furniture website for more details.

9. Customer Support

For assembly assistance, missing parts, or any other inquiries regarding your Bush Furniture product, please contact Bush Furniture customer support:

- **Website:** Visit the official Bush Furniture website for FAQs and support resources.
- **Phone:** Refer to the contact information provided in your product packaging.

When contacting support, please have your model number (SCD360WH) and purchase information readily available.