Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYOUNG DJ13U-G91

Joyoung Automatic Soy Milk Maker DJ13U-G91 User Manual

Model: DJ13U-G91 | Brand: JOYOUNG

Introduction

Thank you for choosing the Joyoung Automatic Soy Milk Maker DJ13U-G91. This appliance is designed to simplify the process of making fresh soy milk, nut milk, and other healthy beverages at home. Please read this manual thoroughly before first use to ensure safe and optimal operation.

Important Safety Information

- Always unplug the appliance from the power outlet before cleaning or when not in use.
- Do not immerse the motor head (top part) in water or any other liquid to avoid electric shock.
- Keep hands and utensils away from the moving blade during operation to prevent injury.
- Ensure the appliance is placed on a stable, flat, and heat-resistant surface.
- Do not operate the appliance with a damaged cord or plug. Contact customer service for repair.
- This appliance is for household use only. Do not use outdoors.
- Keep out of reach of children.
- Exercise caution when handling hot liquids and steam.

Product Overview

The Joyoung DJ13U-G91 features a compact design with multiple functions for versatile beverage preparation.



Figure 1: Joyoung Automatic Soy Milk Maker DJ13U-G91, front view.

Components:

- **Motor Head:** Contains the heating element, motor, and control panel.
- **Grinding Blade:** Located under the motor head for processing ingredients.
- **Stainless Steel Jug:** The main container for ingredients and liquid, with capacity markings.
- **Power Cord:** Detachable power supply.



Figure 2: Interior view of the stainless steel jug with 900ml, 1100ml, and 1300ml capacity markings.



Figure 3: Close-up view of the ultra-fine grinding blade located beneath the motor head.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the stainless steel jug and grinding blade with warm, soapy water. Wipe the exterior of the motor head with a damp cloth. Ensure all parts are dry before assembly.
3. **Assemble:** Place the motor head securely onto the stainless steel jug.
4. **Position:** Place the assembled unit on a stable, flat, and heat-resistant surface near a power outlet.
5. **Connect Power:** Plug the power cord into the appliance and then into a 120V-60Hz power outlet.

Operation

The control panel offers various functions for different types of beverages. Refer to Figure 4 for button layout.



Figure 4: Top view of the control panel with various function buttons.

General Steps:

1. **Add Ingredients:** Place your desired ingredients (e.g., soaked soybeans, nuts, grains) into the stainless steel jug.
2. **Add Water:** Fill the jug with water between the minimum (900ml) and maximum (1300ml) fill lines. Do not overfill.
3. **Select Function:** Press the "Select" button to cycle through the available functions until your desired program is highlighted. Available functions include:
    - **Grains:** For mixed grain beverages.
    - **Dry/Soaked Beans:** For making soy milk from dry or pre-soaked soybeans.
    - **Rice Paste:** For preparing rice-based pastes or porridges.
    - **Aromatic Soymilk:** A specialized program for enhanced soy milk flavor.
    - **Porridge:** For cooking various types of porridge.
    - **Nut Milk:** Specifically designed for making milk from nuts like almonds or walnuts.
    - **Juice:** For blending fruits or vegetables into juice (no heating).
    - **Rapid Soymilk:** A quicker program for soy milk preparation.
4. **Start:** Once the desired function is selected, press the "Start/Cancel" button for approximately 3 seconds until you hear a "di-di" sound, indicating the program has begun.

5. **Completion:** The appliance will automatically complete the program and emit a sound.

Special Functions:

- **Warming Function:** If your beverage has cooled, press the "Warming" button to reheat it. This function is useful for maintaining the temperature of prepared drinks.
- **Easy Washing:** After use, press the "Easy Washing" button. The machine will perform a preliminary cleaning cycle. This helps loosen residue, making manual cleaning easier.

Demonstration Video:

Your browser does not support the video tag.

Video 1: A demonstration of how to make soy milk using the Joyoung DJ13U-G91. This video illustrates the process from adding ingredients to selecting a function and starting the machine.

Cleaning and Maintenance

Proper cleaning ensures the longevity and hygiene of your soy milk maker.

1. **Unplug:** Always unplug the appliance before cleaning.
2. **Immediate Cleaning:** For best results, clean the jug and blade immediately after use to prevent food residue from drying and sticking.
3. **Easy Washing Function:** Use the "Easy Washing" function first to pre-clean the interior.
4. **Manual Cleaning:**
    - Carefully remove the motor head from the jug.
    - Wash the stainless steel jug and the grinding blade (attached to the motor head) with warm, soapy water and a soft brush or sponge.
    - **Important:** Do not immerse the motor head in water. Wipe its exterior with a damp cloth. Ensure no water enters the electrical components.
    - Rinse thoroughly and dry all parts completely before storage or next use.
5. **Storage:** Store the appliance in a dry, clean place.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not start.	Not plugged in; power outage; motor head not properly seated.	Check power connection; ensure motor head is securely placed on the jug.
Soy milk is too thin/thick.	Incorrect ingredient-to-water ratio.	Adjust the amount of beans/grains or water according to desired consistency.
Unusual noise during operation.	Ingredients may be too hard or too much.	Ensure ingredients are properly soaked (if required); do not overfill.
Overflow during cooking.	Overfilling the jug.	Do not exceed the maximum fill line (1300ml).

Specifications

Model: DJ13U-G91

Brand: JOYOUNG

Capacity: 900-1300 ml

Input Voltage: 120 V-60 Hz

Rated Power: 1100 W

Motor Power: 200 W

Product Dimensions: 14.17"D x 8.86"W x 14.17"H (260x225x360mm)

Net Weight: 2.2 KG

Material: 304 Food-grade Stainless Steel (jug)

Special Features: Warming Function, Easy Washing, Ultra-fine Grinding Technology, Nut Milk Function



Figure 5: Diagram showing the dimensions of the Joyoung DJ13U-G91 soy milk maker.

Warranty and Support

This Joyoung Automatic Soy Milk Maker DJ13U-G91 comes with a**1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, technical support, or service inquiries, please contact your retailer or the official Joyoung customer service. Please have your model number (DJ13U-G91) and proof of purchase ready.

© 2023 JOYOUNG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0778GG3FN

More documents and user manuals: **https://manuals.plus/**