

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Kappesberg](#) /
- › [Kappesberg B256 Chest of Drawers with Shoe Rack - Instruction Manual](#)

Kappesberg B256

Kappesberg B256 Chest of Drawers with Shoe Rack - Instruction Manual

PRODUCT OVERVIEW

The Kappesberg B256 Chest of Drawers with Shoe Rack is designed to provide practical storage and organization for your living space. This unit features five spacious drawers and an integrated shoe rack or cabinet section, making it suitable for bedrooms, living rooms, or offices. Its almond finish complements various interior styles.



Image: Front view of the Kappesberg B256 Chest of Drawers with Shoe Rack, showcasing its almond finish and five drawers.

SAFETY INFORMATION

- Always read and follow all assembly instructions carefully.
- Assembly should ideally be performed by two adults to ensure safety and ease.
- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Assemble the unit on a soft, clean surface (e.g., a carpet or blanket) to prevent scratching or damage.
- Do not overload drawers. Distribute weight evenly to maintain stability.
- For added safety, it is highly recommended to secure the unit to a wall using appropriate anti-tip hardware (not included) to prevent tipping, especially in households with children.
- Do not stand or climb on the unit.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Chest of Drawers main frame
- 5 Drawer fronts and internal components
- Shoe rack / Cabinet section components
- Back panels
- Shelves (for shoe rack/cabinet)
- Hardware kit (screws, dowels, drawer slides, handles, etc.)
- Assembly manual (this document)

ASSEMBLY INSTRUCTIONS

Please read all instructions thoroughly before starting assembly. Ensure you have sufficient space and the necessary tools (e.g., screwdriver, hammer). Two people are recommended for assembly.

General Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface. Identify each part using the provided diagrams.
2. Begin by assembling the main frame of the chest of drawers, following the numerical sequence in the detailed diagrams.
3. Attach the drawer slides to the internal panels of the chest.
4. Assemble each of the five drawers individually, ensuring the bottom panels are securely fitted.
5. Assemble the shoe rack/cabinet section, including the internal shelves.
6. Attach the back panels to both the chest of drawers and the shoe rack/cabinet.
7. Insert the assembled drawers into their respective slides.
8. Attach handles to the drawer fronts.
9. Carefully move the assembled unit to its desired location.
10. Secure the unit to the wall using anti-tip hardware if desired (recommended).



Image: The Kappesberg B256 unit with drawers pulled out and the cabinet door open, revealing internal storage.

USAGE

The Kappesberg B256 unit is designed for storing clothing, accessories, shoes, and other household items. To ensure longevity and proper function:

- Open and close drawers gently. Avoid forcing them.
- Distribute the weight of items evenly across the drawers and shelves to prevent strain on the structure.
- Do not place excessively heavy items on top of the unit.
- Utilize the shoe rack/cabinet section for footwear or other items that fit comfortably on the shelves.

CARE AND MAINTENANCE

Proper care will help maintain the appearance and functionality of your Kappesberg B256 unit.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. For stubborn marks, use a mild soap solution and immediately dry with a clean cloth.
- **Avoid:** Do not use abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.

- **Spills:** Clean up spills immediately to prevent staining or damage to the wood material.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure the unit remains stable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers do not slide smoothly	Misaligned drawer slides; loose screws; obstruction in the slide mechanism.	Check that drawer slides are correctly aligned and securely fastened. Ensure no items are blocking the slides.
Unit wobbles or is unstable	Uneven floor; loose assembly screws.	Ensure the unit is on a level surface. Tighten all assembly screws. Consider using furniture levelers if the floor is uneven. Secure to wall with anti-tip hardware.
Cabinet door does not close properly	Misaligned hinges; obstruction.	Check hinge alignment and tighten screws. Ensure nothing is obstructing the door's path.

SPECIFICATIONS



Image: Dimensional drawing of the Kappesberg B256 unit, indicating a height of 178cm, width of 137cm, and depth of 47cm.

Feature	Detail
Brand	Kappesberg
Model	B256
Material	MDP (Medium Density Particleboard), Engineered Wood
Dimensions (P x L x A)	47P x 137L x 178A centimeters (Depth x Width x Height)
Number of Drawers	5
Color	Beige (Almond finish)
Item Weight	94000 Grams (94 kg)
Mounting Type	Floor Mount
Room Type	Bedroom

Feature	Detail
Manufacturer	Mobly

WARRANTY AND SUPPORT

This Kappesberg B256 Chest of Drawers with Shoe Rack comes with **6-month warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical assistance, missing parts, or warranty inquiries, please contact Kappesberg customer support through their official website or the retailer where the product was purchased. Provide your model number (B256) and purchase details when contacting support.