

Barbie 765940816981

Barbie Fashion Plates All-in-One Studio Sketch Design Activity Set Instruction Manual

Model: 765940816981

INTRODUCTION

Welcome to the world of fashion design with your Barbie Fashion Plates All-in-One Studio! This activity set allows aspiring designers aged 6 and up to create unique and stylish outfits for Barbie. Mix and match various fashion plates, add color with crayons, and bring your creative visions to life. This manual provides detailed instructions to help you get started and make the most of your design studio.

WHAT'S INCLUDED

Your Barbie Fashion Plates All-in-One Studio includes the following components:

- 15 Double-Sided Fashion Plates: These plates feature various clothing items and accessories that can be mixed and matched to create over 100 unique designs.
- 1 Drawing Tablet (5 x 9in., 20 Sheets): A dedicated surface for placing your fashion plates and paper to create rubbings.
- 1 Crayon Holder (1.84 x 3.5in): Designed to hold the rubbing crayon for easy and even application.
- 8 Colored Crayons: Includes 1 Brown, 1 Yellow, 1 Blue, 1 Orange, 1 Pink, 1 Purple, 1 Green, and 1 Black crayon for coloring your designs.
- Easy-To-Follow Instructions: A guide to help you understand the process and unleash your creativity.



Image: All components of the Barbie Fashion Plates All-in-One Studio, including the drawing tablet, various fashion plates, crayon holder, and colored crayons.

SETUP

1. **Prepare the Drawing Tablet:** Open the drawing tablet. You will see slots where the fashion plates fit.
2. **Select Fashion Plates:** Choose three double-sided fashion plates to create your desired outfit. These typically include a head/top, a torso/middle, and a leg/bottom section.
3. **Insert Fashion Plates:** Carefully slide your chosen fashion plates into the designated slots on the drawing tablet. Ensure they are securely in place and aligned to form a complete figure.
4. **Place Paper:** Take one sheet of paper from the drawing tablet or use a standard piece of paper cut to size. Place it over the assembled fashion plates on the tablet.
5. **Secure Paper:** Close the clear frame of the drawing tablet over the paper. This will hold the paper and the fashion plates firmly in position for rubbing.



Image: The product box illustrating the steps for setting up the fashion plates and paper on the drawing tablet.

Your browser does not support the video tag.

Video: A quick demonstration of how to set up the Barbie Fashion Plates All-in-One Studio, including placing the plates and paper.

OPERATING INSTRUCTIONS

1. **Create the Outline:** Take the black crayon and insert it into the crayon holder. Hold the crayon holder

flat against the paper and rub it firmly over the entire surface of the paper. The raised designs on the fashion plates will transfer as an outline onto your paper.

2. **Add Color:** Once the outline is complete, open the drawing tablet and remove your paper. Use the included colored crayons to fill in your fashion design with vibrant colors. Experiment with different color combinations to create unique looks.
3. **Experiment with Textures:** Some fashion plates may have textured patterns on their reverse side. You can use these textures by placing them under specific areas of your design (e.g., a skirt or top) and rubbing a crayon over them to add patterns.
4. **Mix and Match:** Don't be afraid to try different combinations of head, torso, and leg plates to create a wide variety of styles.



Image: A hand demonstrating the rubbing technique with a crayon to transfer the fashion plate design onto paper.



Image: Examples of completed fashion designs, showcasing different outfits and coloring styles created with the set.

Your browser does not support the video tag.

Video: A demonstration of the fashion design process using the studio, including selecting plates, rubbing, and coloring.

MAINTENANCE

To ensure the longevity of your Barbie Fashion Plates All-in-One Studio:

- **Cleaning Plates:** The fashion plates can be wiped clean with a dry cloth if they accumulate crayon residue.
- **Storage:** Store all components, including plates, crayons, and the drawing tablet, in a cool, dry place away from direct sunlight to prevent damage or warping. The compact design allows for easy storage and travel.
- **Crayon Replacement:** If the included crayons wear down, standard crayons can be used as replacements.

TROUBLESHOOTING

If you encounter any issues while using your Barbie Fashion Plates All-in-One Studio, consider the

following:

- **Faint Rubbings:** Ensure the paper is placed flat and securely over the fashion plates. Apply firm, even pressure when rubbing the crayon across the entire surface.
- **Crayon Breakage:** Crayons can break if too much pressure is applied or if they are dropped. Use a gentle, consistent rubbing motion.
- **Misaligned Designs:** Double-check that the fashion plates are correctly inserted into their slots and that the paper is aligned before closing the frame.

SPECIFICATIONS

Brand	Barbie
Model Name	Barbie Fashion Plates All-in-One Studio by Horizon Group USA
Item Model Number	765940816981
Age Range (Recommended)	6 years and up
Dimensions (L x W x H)	9.65 x 8.7 x 12.6 inches
Item Weight	15.8 ounces
Material	Paper
Number of Pieces	15 (Fashion Plates)
Included Components	15 double-sided fashion plates, drawing tablet, 20 sheets of paper, crayon holder, 8 colored crayons, easy-to-follow instructions



Image: The product packaging displaying the dimensions of the Barbie Fashion Plates All-in-One Studio.

WARRANTY AND SUPPORT

For any questions regarding your Barbie Fashion Plates All-in-One Studio, please refer to the manufacturer's contact information provided on the product packaging. Specific warranty details are typically included with the product at the time of purchase.