

[Manuals.plus](#) /

› [Aigostar](#) /

› Aigostar Forest Mist Misting Fan User Manual

Aigostar AIG-8433325184971

Aigostar Forest Mist Misting Fan User Manual

Model: AIG-8433325184971

1. INTRODUCTION

Thank you for choosing the Aigostar Forest Mist Misting Fan. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before use and retain it for future reference.

The Aigostar Forest Mist Misting Fan is designed to provide powerful air circulation and refreshing mist, enhancing comfort in your home or office.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using this fan.
- Ensure the power supply matches the voltage specified on the rating label.
- Do not immerse the fan, plug, or cord in water or other liquids.
- Unplug from the outlet when not in use, when moving the fan from one location to another, and before cleaning.
- Do not operate any fan with a damaged cord or plug, or after the fan malfunctions or has been dropped or damaged in any manner.
- Keep the fan out of reach of children and pets.
- Do not insert fingers or any other objects through the grille when the fan is operating.
- Place the fan on a stable, level surface to prevent it from tipping over.
- Do not use the fan in areas where highly flammable liquids or vapors are stored or present.
- Only use attachments recommended or sold by the manufacturer.
- Do not block air openings or operate near curtains or other materials that may block airflow.
- Use only clean, distilled water in the water tank to prevent mineral buildup and ensure optimal misting performance.

3. PACKAGE CONTENTS

Carefully unpack your Aigostar Forest Mist Misting Fan and check that all items are present and in good condition. If any items are missing or damaged, please contact customer support.

- Misting Fan Unit (Base, Stand, Fan Head)

- Remote Control
- Water Tank (1.8L capacity)
- Front and Rear Grilles
- Fan Blades
- Base Wheels (pre-installed or separate)
- Instruction Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Aigostar Forest Mist Misting Fan.



Figure 4.1: Aigostar Forest Mist Misting Fan and Remote Control. This image shows the full fan unit, including the main body, fan head, and the separate remote control. Mist is depicted flowing from the fan, indicating its humidifying capability.

01.



Télécommande longue portée de 6m

02.




Roues universelles cachées

03.



Réservoir d'eau de 1,8 L

04.



Grille de sécurité

Figure 4.2: Key Components of the Misting Fan. This image highlights four important parts: the remote control for convenient operation, hidden universal wheels on the base for easy movement, the 1.8L water tank for misting, and the safety grille covering the fan blades.

Key Features:

- **Ultrasonic Misting:** Integrated 1.8L water tank with 140 ml/h atomization, providing a refreshing mist. The mist function can operate independently.
- **Ionic Function:** Releases negative ions for effective air purification, creating a fresher environment.
- **LED Display & Remote Control:** Clear LED screen shows operating status. Infrared remote control allows convenient operation from a distance.
- **Programmable Timer:** Set auto-off times for 1h, 2h, 4h, or 8h for personalized comfort.
- **3 Speeds & 3 Modes:** Choose from Low, Medium, High speeds and Normal, Natural, or Night modes to suit your preference.
- **Wide Angle Airflow:** Features 80° left-right oscillation and 16° up / 8° down tilt for maximum room coverage.
- **Low Noise Operation:** Operates at a low noise level of 45 dB, making it suitable for quiet environments like offices and bedrooms.

5. SETUP AND ASSEMBLY

Follow these steps to assemble your Aigostar Forest Mist Misting Fan. It is recommended to have two people for easier assembly.



Figure 5.1: Step-by-step Installation Guide. This image illustrates the six main steps for assembling the fan: 1. Install the telescopic rod onto the base. 2. Mount the wheels onto the base. 3. Install the main unit onto the base. 4. Place the rear protection and fan blades. 5. Install the front protection and screw it. 6. Connect the mist tube and the water tank.

- 1. Install the Telescopic Rod:** Insert the telescopic rod into the designated slot on the fan's base. Ensure it is securely seated.
- 2. Mount the Wheels:** If not pre-installed, attach the universal wheels to the underside of the base. These wheels allow for easy movement of the fan.
- 3. Install the Main Unit:** Carefully place the main fan unit onto the assembled base, aligning the connection points.
- 4. Attach Rear Grille and Blades:** Place the rear safety grille onto the motor shaft, followed by the fan blades. Secure the blades with the provided cap.
- 5. Install Front Grille:** Position the front safety grille over the fan blades and secure it firmly with the retaining screws or clips.

Ensure both grilles are properly aligned and fastened for safety.

6. **Connect Mist Tube and Water Tank:** Connect the misting tube from the fan head to the water tank. Ensure a tight connection to prevent leaks. Fill the 1.8L water tank with clean, distilled water before inserting it into its compartment at the base of the fan.

Once assembled, place the fan on a firm, level surface away from obstacles that could impede airflow.

6. OPERATING INSTRUCTIONS

Your Aigostar Forest Mist Misting Fan can be operated using the control panel on the unit or the included remote control.

6.1 Control Panel and LED Display



Figure 6.1: LED Display and Control Panel. The central LED screen displays the current temperature and operational status. Surrounding buttons allow control over various functions like oscillation, speed, mode, timer, and misting. The LED display provides real-time information about the fan's settings, including temperature and active functions. The buttons on the control panel correspond to the functions on the remote control.

6.2 Remote Control Operation



Figure 6.2: Remote Control for Aigostar Misting Fan. The remote allows convenient control of all fan functions from a distance, including power, speed, mode, oscillation, timer, and misting.

Ensure the remote control has working batteries (not included, typically AAA). Point the remote directly at the fan's control panel for optimal response.

- **Power Button** (): Turns the fan ON or OFF.
- **Speed Button** (): Cycles through fan speeds: Low, Medium, High.

- **Mode Button** (⚙️): Selects operating modes: Normal, Natural, Night.



Figure 6.3: Fan Modes and Speeds. This graphic illustrates the three available modes (Normal, Natural, Night) and the three speed settings (Low, Medium, High) for customized airflow.

- **Normal Mode:** Constant airflow at the selected speed.
- **Natural Mode:** Simulates natural breeze by varying fan speed.
- **Night Mode:** Operates at a lower, quieter speed for undisturbed sleep.
- **Oscillation Button** (↔️): Activates or deactivates the 80° horizontal oscillation.



Figure 6.4: Oscillation and Tilt Functionality. The fan offers an 80° automatic oscillation (40° left, 40° right) and a 24° inclinable head (16° up, 8° down) for broad air distribution.

- **Timer Button ():** Sets the auto-off timer for 1h, 2h, 4h, or 8h.




Figure 6.5: Timer Function. The fan can be programmed to automatically turn off after 1, 2, 4, or 8 hours, ideal for use during sleep or when leaving a room.

- **Mist Button ():** Turns the ultrasonic misting function ON or OFF. Ensure the water tank is filled.



Figure 6.6: Ionic Function. This image illustrates the negative ion release feature, which helps purify the air and create a fresher environment, complementing the misting function.

- **Ionic Function Button ():** Activates or deactivates the negative ion air purification.

6.3 Filling the Water Tank

To use the misting function, the water tank must be filled.

1. Turn off and unplug the fan.
2. Carefully remove the water tank from its compartment at the base of the fan.
3. Unscrew the cap at the bottom of the tank and fill it with clean, distilled water. Using distilled water helps prevent mineral buildup and extends the life of the misting mechanism.
4. Securely replace the cap and reinsert the water tank into the fan unit.
5. Plug in the fan and activate the mist function.




Figure 6.7: Water Tank Capacity. The 1.8L water tank provides ample capacity for extended misting operation, equivalent to approximately 12 glasses of water.

7. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your fan.

7.1 General Cleaning

- Always unplug the fan before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
- For the fan blades and grilles, carefully remove the front grille (refer to assembly instructions in Section 5) and wipe the blades and grilles with a damp cloth. Ensure all parts are dry before reassembling.

7.2 Water Tank and Misting Unit Cleaning

- Empty the water tank after each use, especially if the fan will not be used for an extended period.
- Rinse the water tank with clean water. For mineral buildup, use a solution of white vinegar and water (1:1 ratio), let it soak for 30 minutes, then rinse thoroughly.
- Clean the misting nozzle and surrounding area with a soft brush or cotton swab to remove any mineral deposits.
- Ensure all water-related components are completely dry before storage to prevent mold or mildew growth.

7.3 Storage

When storing the fan, especially during off-season, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

8. TROUBLESHOOTING

If you encounter issues with your Aigostar Forest Mist Misting Fan, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; Power outlet malfunction; Power button not pressed.	Ensure the fan is securely plugged into a working outlet. Press the power button on the unit or remote.

Problem	Possible Cause	Solution
No mist is produced.	Water tank empty; Mist function not activated; Misting nozzle clogged; Water tank not properly installed.	Fill the water tank with distilled water. Press the mist button. Clean the misting nozzle. Ensure the water tank is correctly seated.
Weak airflow.	Fan speed too low; Air intake/outlet blocked; Fan blades dirty.	Increase fan speed. Ensure nothing is blocking the grilles. Clean the fan blades.
Fan is noisy.	Fan not on a level surface; Loose parts; Fan blades dirty.	Place the fan on a stable, level surface. Check for any loose components and tighten them. Clean the fan blades. Note: Some noise is normal, especially at higher speeds.
Remote control not working.	Batteries dead or incorrectly inserted; Obstruction between remote and fan; Remote out of range.	Replace batteries. Ensure no obstructions. Point remote directly at the fan's control panel within 6 meters range.

If the problem persists after trying these solutions, please contact Aigostar customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	Aigostar
Model Number	AIG-8433325184971
Color	Grey
Dimensions (L x W x H)	36 x 44 x 135 cm
Weight	10.78 kg
Power	95 Watts
Noise Level	45 dB
Water Tank Capacity	1.8 Liters
Misting Output	140 ml/h
Oscillation Angle	80° (horizontal)
Tilt Angle	16° up, 8° down
Timer Settings	1h, 2h, 4h, 8h
Fan Speeds	3 (Low, Medium, High)
Operating Modes	3 (Normal, Natural, Night)
Special Features	Ultrasonic Misting, Ionic Function, LED Display, Remote Control, Auto-off Function, Water Resistant (for misting components), Oscillation

Feature	Detail
Power Source	Electric Cable
Recommended Uses	Cooling, Ventilation, Air Circulation

10. WARRANTY AND CUSTOMER SUPPORT

Aigostar products are designed and manufactured to the highest quality standards. For warranty information, technical support, or any questions regarding your product, please contact Aigostar customer service through the retailer where you purchased the product or visit the official Aigostar website.

Please have your model number (AIG-8433325184971) and purchase date ready when contacting support.

© 2025 Aigostar. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B077F8S348>

More documents and user manuals: <https://manuals.plus/>