

ANDYCINE A6 V2

ANDYCINE A6 V2 6-Inch HDMI Field Monitor User Manual

1. INTRODUCTION

Thank you for choosing the ANDYCINE A6 V2 6-Inch HDMI Field Monitor. This manual provides essential information for setting up, operating, and maintaining your device. The A6 V2 monitor is designed to enhance your video production workflow with its high-resolution display, versatile connectivity, and advanced monitoring features.

2. WHAT'S IN THE BOX

Your ANDYCINE A6 V2 package includes the following items:

- 1x ANDYCINE A6 V2 Camera HDMI Monitor
- 1x Micro HDMI Cable
- 1x NP-F Series Battery
- 1x Battery Charge Cable
- 1x Carry Case
- 1x Sunshade
- 1x Tilt Arm
- 1x User Manual



Figure 2.1: ANDYCINE A6 V2 Field Monitor and included accessories.

3. PRODUCT FEATURES

- **IPS 1920x1080P Screen:** The A6 V2 features a native 1920x1080 resolution IPS screen, offering 170-degree viewing angles for a better visual experience, suitable for both indoor and outdoor use.

Display True Colors





Figure 3.1: IPS 1920x1080P Screen.

- **4K HDMI In and Output:** This 4K field monitor accepts max 4K 30FPS HDMI signals. The HDMI loop-out function allows you to connect to an external monitor for efficient workflow.


Fits most kinds of cameras



NP-F series battery slot

Provides power for indoor and outdoor or handheld applications.

(Compatible battery: F970 F960 F950 F930 F770 F750 F730 F570 F550 F530 QM91D QM91 QM90D QM90 QM71D QM710 M70D QM70 QM51D QM51 FM71 FM70)



LP-E6 battery slot

Provides power for indoor and outdoor or handheld applications.

Figure 3.2: 4K HDMI Loop-out.

- **Advanced Functions:** Features like Waveform, Zebra, Histogram, Focus Peaking, and Ratio Marker assist in accurate and safe shooting. With 3D LUT loadable functions, you can preview LUT effects during monitoring.

Practical auxiliary tools

Help you shoot more easily, minimizing unusable shots




Figure 3.3: Advanced Monitoring Tools.

- **Multi Power Supply and Multi Mount Points:** The monitor accepts NP-F series batteries (included), DC Input, and USB-C (5V 2A) Input as power sources. It features 1/4-inch 20 threaded mounting points on the side and bottom, and includes a tilt arm for comfortable viewing.

Compact size & lightweight

Unit Weight: 190 g / 0.41 lb



Figure 3.4: Multi Power Supply and Mounting Options.

- **Compact Size & Lightweight:** The monitor is designed to be compact and lightweight for easy portability and integration into various camera setups.









Figure 3.5: Compact Size and Lightweight Design.

4. SETUP AND INSTALLATION

Follow these steps for initial setup and installation of your ANDYCINE A6 V2 monitor:

1. **Unboxing:** Carefully remove all components from the packaging. Verify that all items listed in the

Related Documents - A6 V2

| | |
|--|---|
| <p>6" Touchscreen Monitor 4K HDMI/3D LUT/HDR</p>  <p>User Manual</p> | <p>Feelworld 6" Touchscreen Monitor 4K HDMI/3D LUT/HDR User Manual</p> <p>Comprehensive user manual for the Feelworld 6-inch 4K HDMI/3D LUT/HDR touchscreen monitor, covering features, operation, technical specifications, and troubleshooting.</p> |
| <p>7" FHD 2200nit Ultra Bright Daylight Viewable Field Monitor</p>  <p>User Manual</p> | <p>7-inch FHD 2200nit Ultra Bright Daylight Viewable Field Monitor User Manual</p> <p>User manual for the 7-inch FHD 2200nit Ultra Bright Daylight Viewable Field Monitor, detailing features, operation, technical specifications, and troubleshooting. This guide provides comprehensive information for users of the Andycine field monitor.</p> |
|  <p>User Manual</p> | <p>Ikan AX20-FK-V2 Atlas 21.5" Field and Studio 4K Monitor Quick Start Guide</p> <p>Quick start guide for the Ikan AX20-FK-V2 Atlas 21.5" Field and Studio 4K Monitor, detailing its features, specifications, and what's included.</p> |
| <p>Marshall Broadcast AV Division</p> <p>ML-454-V2 Quad 4.5" Rack Mount Monitor with 3G-SDI, HDMI and Composite Inputs</p>  <p>User Manual</p> | <p>Marshall ML-454-V2 Quad 4.5" Rack Mount Monitor User Manual</p> <p>User manual for the Marshall ML-454-V2, a quad 4.5-inch rack mount monitor featuring 3G-SDI, HDMI, and composite inputs. This guide covers overview, unpacking, installation, basic operation, menu functions, technical specifications, and warranty information.</p> |
| <p>Marshall Broadcast AV Division</p> <p>ML-454-V2 Quad 4.5" Rack Mount Monitor with 3G-SDI, HDMI and Composite Inputs</p>  <p>User Manual</p> | <p>Marshall ML-454-V2 Quad 4.5" Rack Mount Monitor User Manual</p> <p>User manual for the Marshall ML-454-V2 Quad 4.5-inch Rack Mount Monitor, detailing its features, installation, operation, menu functions, specifications, and warranty. Supports 3G-SDI, HDMI, and Composite video inputs for broadcast and professional AV applications.</p> |
|  <p>User Manual</p> | <p>KAWA A6 Smart Pan-Tilt Camera User Manual</p> <p>This document provides a comprehensive user manual for the KAWA A6 Smart Pan-Tilt Camera, covering product appearance, specifications, power source, installation instructions, and certifications.</p> |

