

## WHIRLPOOL AKZ9629IX

# Whirlpool AKZ9629IX Pyrolytic Built-in Oven User Manual

Model: AKZ9629IX | Brand: Whirlpool

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Whirlpool AKZ9629IX Pyrolytic Built-in Oven. Please read these instructions carefully before using the appliance and retain them for future reference.

### 1.1. Product Overview

The Whirlpool AKZ9629IX is a 73-liter multifunction built-in oven featuring pyrolytic self-cleaning, pulsed heat cooking, and a range of automatic 6th Sense programs. Designed for integration into your kitchen, it offers advanced cooking capabilities with an A+ energy efficiency rating.



Figure 1: Front view of the Whirlpool AKZ9629IX Built-in Oven, showcasing its stainless steel finish and digital display.

## 1.2. Safety Information

Always adhere to the following safety guidelines:

- Ensure the oven is correctly installed by a qualified professional before use.
- Keep children away from the appliance during operation, especially during pyrolytic cleaning, due to high temperatures.
- Do not use abrasive cleaners or sharp metal scrapers to clean the oven door glass, as they can scratch the surface and lead to shattering.
- Always use oven mitts when handling hot dishes or oven accessories.
- The oven door remains cool to the touch during normal operation due to its cold door feature (4 glass panes), but exercise caution.
- This appliance is equipped with a child safety lock. Refer to the operating section for activation and deactivation.

## 2. INSTALLATION AND SETUP

The Whirlpool AKZ9629IX is designed for built-in installation. Proper installation is crucial for safety and optimal performance.

## 2.1. Installation Requirements

- **Type:** Built-in
- **Power Supply:** Electric, 3650 Watts total power. Ensure your electrical supply meets these requirements.
- **Ventilation:** Adequate ventilation around the appliance is necessary.

## 2.2. Dimensions

Refer to the diagram below for precise installation dimensions. The oven requires a cabinet opening that accommodates its specific measurements.

- **Product Dimensions (H x W x D):** 59.5 cm x 59.5 cm x 56.4 cm
- **Weight:** 37 kg




Figure 2: Detailed diagram showing the required cabinet dimensions for installing the Whirlpool AKZ9629IX oven.

**Note:** Installation should only be performed by a qualified technician to ensure compliance with local safety standards and proper functioning.

## 3. OPERATING INSTRUCTIONS

Your Whirlpool AKZ9629IX oven offers a variety of cooking functions and programs for diverse culinary needs.

### 3.1. Control Panel Overview

The oven features a digital display and intuitive controls. Consult the full manual for detailed explanations of each button and indicator.



Figure 3: Interior view of the oven, showing the multiple rack positions and internal lighting.

### 3.2. Cooking Functions

The oven includes 10 traditional functions and 6 special functions:

- **Traditional Functions:**

- Convection (Natural)
- Pulsed Heat (Fan Assisted)
- Grill
- Turbo Grill (Ventilated Grill)
- Rotating Heat (True Fan Cooking)
- And more...

- **Special Functions:**

- Rapid Preheating
- Defrost / Keep Warm
- Dough Proving
- Eco-Pulsed Heat
- And more...

**Temperature Adjustment:** The temperature can be set up to 250 °C. Use the control knob or touch buttons to

adjust the desired temperature.

**Cooking Levels:** The oven cavity offers 5 cooking levels for flexible placement of dishes.

### 3.3. 6th Sense Automatic Programs

The 6th Sense technology simplifies cooking by automatically setting the optimal temperature and time for various food categories:

- Gratins, Stews
- Meat, Poultry
- Large Cuts of Meat
- Bread Baking
- Pizza / Savory Pie
- Pastries
- Extra Browning

To use a 6th Sense program, select the desired food category from the menu. The oven will then guide you through the process.

## 4. CLEANING AND MAINTENANCE

Regular cleaning and maintenance ensure the longevity and optimal performance of your oven.

### 4.1. Pyrolytic Cleaning

The Whirlpool AKZ9629IX features a pyrolytic self-cleaning mode, which burns off food residues at high temperatures, turning them into ash that can be easily wiped away.

- **Activation:** Select the Pyrolytic cleaning function from the menu. The oven will automatically lock the door during the cycle.
- **Express Pyrolysis:** An accelerated cleaning option is available for lighter soiling.
- **Before Pyrolysis:** Remove all accessories (racks, baking trays) from the oven cavity. Wipe away any large spills.
- **After Pyrolysis:** Once the oven has cooled, wipe the interior with a damp cloth to remove the ash residue.

**Important:** Ensure the kitchen is well-ventilated during pyrolytic cleaning. The oven door remains locked until the temperature drops to a safe level.

### 4.2. General Cleaning

- **Exterior:** Clean the stainless steel exterior with a soft cloth and a mild, non-abrasive cleaner.
- **Oven Door:** The oven door and its glass panes are removable for easier cleaning. Refer to the full manual for instructions on how to safely remove and reattach them.
- **Accessories:** Wash racks and baking trays with warm soapy water.

## 5. TROUBLESHOOTING

Before contacting customer service, consult this section for solutions to common issues.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Oven does not turn on.	No power supply; oven not properly plugged in; circuit breaker tripped.	Check power connection; reset circuit breaker.
Oven not heating correctly.	Incorrect function or temperature setting; door not fully closed.	Verify settings; ensure door is securely shut.
Pyrolytic cleaning not starting.	Oven door not closed properly; accessories still inside.	Close door firmly; remove all accessories.
Child lock activated.	Child lock feature engaged.	Refer to the operating section for instructions on deactivating the child lock.

If the issue persists after attempting these solutions, please contact Whirlpool customer support.

## 6. TECHNICAL SPECIFICATIONS

Detailed specifications for the Whirlpool AKZ9629IX Built-in Oven:

Feature	Specification
Brand	Whirlpool
Model Number	AKZ9629IX
Manufacturer	WHIRLPOOL
Product Dimensions (H x W x D)	59.5 cm x 59.5 cm x 56.4 cm
Weight	37 kg
Cavity Volume	73 Liters
Cleaning Method	Pyrolytic
Heating Method	Pulsed Heat (Fan Assisted), Convection, Grill
Max. Temperature	250 °C
Number of Functions	10 Traditional + 6 Special
Cooking Levels	5
Door Type	Cold Door (4 Glass Panes), Removable
Lighting	40 W Halogen
Total Power	2500 W (Grill: 3655 W)
Energy Efficiency Class	A+
Energy Consumption (Conventional)	0.91 kWh/cycle
Energy Consumption (Pulsed Heat)	0.70 kWh/cycle
Special Features	Pyrolysis, Pulsed Heat, Rapid Preheating, Defrost, Child Safety Lock

## 6.1. Energy Label Information

The energy label provides information on the appliance's energy efficiency.






Figure 4: Energy label for the Whirlpool AKZ9629IX, indicating an A+ energy efficiency class and consumption values.

For more detailed product information and the official product card, please visit the EPREL database:

[EPREL Product Information \(ID: 116126\)](#)

## 7. WARRANTY AND SUPPORT

For warranty information, technical assistance, or spare parts, please contact Whirlpool customer service.

### 7.1. Manufacturer Contact Information


- **Manufacturer:** WHIRLPOOL
- **Supplier:** BEKO EUROPE MANAGEMENT S.R.L. (as per EPREL data)
- **Email:** [public\\_inquiry@europeanappliances.com](mailto:public_inquiry@europeanappliances.com)
- **Telephone:** +39 02 83715807
- **Website:** [www.bekoeurope.com](http://www.bekoeurope.com)
- **Address:** VIA VARESINA, 204, 20156 MILANO, ITALY

Please have your model number (AKZ9629IX) and purchase date available when contacting support.



### Related Documents - AKZ9629IX

 <p>Whirlpool W Collection 60cm Multifunction Hydrolytic Oven</p> <p>W4OMK38HU0XA</p> <p>FEATURES &amp; BENEFITS</p> <p>TECHNICAL SPECIFICATIONS</p>	<p><a href="#">Whirlpool W4OMK38HU0XA 60cm Multifunction Hydrolytic Oven - Features, Specs &amp; Installation</a></p> <p>Detailed specifications and features for the Whirlpool W4OMK38HU0XA 60cm Multifunction Hydrolytic Oven, including Cook3, Turbo Grill, Smart Clean technology, and installation dimensions.</p>
---	---

	<p><a href="#"><u>Whirlpool Small Electric Built-In Convection Oven Use &amp; Care Guide</u></a></p> <p>Comprehensive guide for the Whirlpool Small Electric Built-In Convection Oven, covering safety, operation, cooking modes, care, and troubleshooting. Includes instructions for manual and assisted cooking, settings, and cleaning.</p>
	<p><a href="#"><u>Whirlpool Small Electric Built-in Convection Oven Use &amp; Care Guide</u></a></p> <p>Comprehensive guide for using, caring for, and troubleshooting your Whirlpool small electric built-in convection oven, including safety instructions, cooking modes, and maintenance.</p>
	<p><a href="#"><u>Whirlpool WOS52EM4AS Built-In Electric Convection Oven Use &amp; Care Guide</u></a></p> <p>Comprehensive use and care guide for the Whirlpool WOS52EM4AS built-in electric convection oven, covering safety, operation, cooking functions, maintenance, and troubleshooting.</p>
	<p><a href="#"><u>Whirlpool MBNA910X Microwave Oven User Manual</u></a></p> <p>Official user manual for the Whirlpool MBNA910X Solo Microwave Oven. This guide details the appliance's features, including its 22L capacity, 750W power, and functions like microwave cooking, steam preparation, and Jet Defrost. It provides comprehensive instructions for operation, daily use, cleaning, maintenance, and troubleshooting. Model number: 859991659450.</p>
	<p><a href="#"><u>Guide d'utilisation et d'entretien : Four à convection électrique encastré Whirlpool</u></a></p> <p>Manuel complet pour le four encastré électrique à convection Whirlpool. Ce guide fournit des instructions détaillées sur l'utilisation, l'entretien, la sécurité et le dépannage pour les modèles GBD277, GBD307, GBS277 et GBS307.</p>