

Manuals.plus /
› Play22 /
› Play22 Wooden Train Set (12-Piece) Instruction Manual

Play22 6006

Play22 Wooden Train Set (12-Piece) Instruction Manual

Model: 6006 | Brand: Play22

1. INTRODUCTION

Thank you for choosing the Play22 Wooden Train Set. This 12-piece magnetic train set is designed to provide engaging play for children aged 3 years and up. It encourages the development of strong color recognition and motor skills. The set is compatible with most major wooden railway brands, allowing for expanded play possibilities.



Image 1: The Play22 Wooden Train Set, featuring 12 distinct magnetic train cars, neatly arranged within its wooden storage box.

2. PRODUCT CONTENTS

The Play22 Wooden Train Set includes 12 unique magnetic train cars, designed for versatile play. The components are:

- Engines (multiple designs)
- Tender car
- Coaches (passenger cars)
- Convertible coach-hopper car
- Cargo car with magnetic cargo load
- Tanker car with magnetic tanker load
- Hopper car
- Cabooses

ENDLESS COMBINATIONS

FOR LOTS OF IMAGINATIONS

REMOVABLE
CARGO CARS



CRANE **NOT**
INCLUDED



stronger
front & rear
magnets
for longer
trains

Image 2: A selection of the magnetic train cars, demonstrating their individual designs and the removable cargo features.

3. SETUP

The Play22 Wooden Train Set is ready for play directly out of its storage box. No assembly is required for individual train cars. Each train car features magnetic connectors on both ends, allowing for easy attachment and detachment.

1. Carefully remove the desired train cars from the wooden display box.
2. To connect two train cars, bring their magnetic ends close together. The magnets will automatically align and connect.
3. To detach, gently pull the connected cars apart.

The set is designed for intuitive connection, enabling children to easily create various train configurations.

4. OPERATING INSTRUCTIONS

The Play22 Wooden Train Set offers versatile play options:

- **Free Play:** Children can connect the train cars in any order they choose, fostering creativity and problem-solving skills.
- **Track Compatibility:** These wooden train cars are compatible with all major brands of wooden railway tracks (tracks sold separately). Place the assembled train onto a compatible track and push it along.
- **Removable Cargo:** Some train cars feature removable cargo pieces (e.g., magnetic cargo load, tanker load). These can be taken off and re-attached, adding another layer of interactive play.



Image 3: A child interacting with the train set on a wooden track, showcasing the product in use.

5. MAINTENANCE

To ensure the longevity of your Play22 Wooden Train Set, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the wooden train cars with a damp cloth as needed. Avoid submerging them in water or using harsh cleaning agents, as this may damage the wood or paint.
- **Storage:** Store the train set in its original wooden display box when not in use. This helps protect the pieces from dust and damage, and keeps them organized.

- **Inspection:** Periodically inspect all train cars for any signs of wear or damage. Discontinue use if any parts become loose or broken.



Image 4: The train set stored in its wooden box, illustrating proper storage for product longevity.

6. TROUBLESHOOTING

For a simple wooden train set, troubleshooting is generally minimal. Here are a few common points:

- **Magnets Not Connecting:** Ensure the magnetic ends of the train cars are clean and free from debris. The magnets are designed to connect easily; if they repel, try flipping one of the cars around to align the poles correctly.
- **Wheels Not Rolling Smoothly:** Check for any hair, lint, or small debris caught in the axles of the wheels. Carefully remove any obstructions.
- **Compatibility Issues:** While designed to be compatible with most wooden tracks, slight variations in track design from other brands might occasionally cause minor fit issues. This is generally rare.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	13 x 8 x 2 inches
Item Weight	1.99 pounds
Model Number	6006
Manufacturer Recommended Age	3 years and up
Material	Wood with magnetic connectors
Safety Compliance	Meets ASTM F963, Safety Tested, Lead-Free

8. SAFETY INFORMATION

The Play22 Wooden Train Set is designed with safety in mind. It meets all safety requirements of ASTM F963, is safety tested, and lead-free. However, please observe the following:

- **Choking Hazard:** Small parts may be present. Not suitable for children under 3 years of age. Adult supervision is recommended during play.
- **Magnets:** This product contains magnets. Swallowed magnets can stick together across intestines causing serious infections and death. Seek immediate medical attention if magnets are swallowed or inhaled.

9. WARRANTY AND SUPPORT

For any questions, comments, or support regarding your Play22 Wooden Train Set, please refer to the contact information provided on the product packaging or visit the official Play22 website. Specific warranty details may vary and are typically outlined with your purchase documentation.

© 2025 Play22. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B077H8K5D1>

More documents and user manuals: <https://manuals.plus/>