

[manuals.plus](#) /

› [TENGA](#) /

› [TENGA FLIP 0 \(Zero\) TFZ-002 Black Instruction Manual](#)

**TENGA TFZ-002**

## **TENGA FLIP 0 (Zero) TFZ-002 Black Instruction Manual**

Model: TFZ-002

### **1. INTRODUCTION**

---

Thank you for choosing the TENGA FLIP 0 (Zero) TFZ-002 Black. This reusable pleasure device is designed to provide a unique experience with its innovative flip-open structure and internal vacuum sensation. This manual provides essential information for safe and effective use, cleaning, and maintenance of your device.






Image 1.1: The TENGA FLIP 0 (Zero) TFZ-002 Black device.

## 2. SAFETY INFORMATION

---

Please read all safety instructions before using the device. Failure to follow these instructions may result in injury or damage to the product.

- This product is intended for adult use only.
- Do not use if the device appears damaged or compromised.
- Discontinue use immediately if you experience any discomfort or pain.
- Clean the device thoroughly before and after each use as instructed in this manual.
- Use only water-based lubricants with this device. Oil-based lubricants may damage the material.
- Keep out of reach of children.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

## 3. PACKAGE CONTENTS

---

Verify that all items are present in your package:

- TENGA FLIP 0 (Zero) TFZ-002 Black Device
- Dedicated Stand/Drying Case
- Sample Lubricant (TENGA HOLE LOTION REAL)
- Instruction Manual

## 4. SETUP

---

1. **Unpack the Device:** Carefully remove the TENGA FLIP 0 from its packaging and the clear display case.
2. **Initial Cleaning:** Before first use, open the device and rinse the interior thoroughly with lukewarm water. Allow it to air dry completely.
3. **Apply Lubricant:** Apply a generous amount of water-based lubricant to the entrance and interior of the device. Ensure even distribution for optimal sensation and comfort.

## 5. OPERATION

---

The TENGA FLIP 0 features a unique flip-open design for easy access and an intricate internal structure for varied sensations.

### 5.1 Device Opening and Closing

- To open the device, press the release buttons on the sides and gently flip the two halves apart.
- To close, align the two halves and press them together until the side latches click securely into place.


### 5.2 Using the Device

1. Ensure the device is clean and lubricated.
2. Insert into the device. The integrated pivot allows for seamless entry.
3. Squeeze the exterior pressure pads to create an internal vacuum and intensify sensations. Experiment with different pressure levels to find your preferred experience.
4. The elastomer interior is designed with less dead space to stimulate all surfaces and enhance vacuum suction.

### 5.3 Internal Structure

The FLIP 0's interior is engineered with distinct features to provide varied stimulation:

## INTERNAL STRUCTURE



Firmer material and bold details create even stronger sensations and suction.

Image 5.1: Detailed view of the internal structure.

- **Solid End Orb:** Located at the deep end, designed to provide a surprising and delightful sensation.
- **Dynamic Flick Orb:** Springs into action with each movement, offering dynamic stimulation.
- **Cross Rampart:** Stimulates as you pass through each overlapping layer.
- **Geared Edge:** Firm edges provide immediate intensity upon insertion.

## 6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance are crucial for hygiene and extending the lifespan of your TENGA FLIP 0.

1. **Open the Device:** Press the side release buttons and open the device completely.
2. **Rinse Thoroughly:** Rinse the interior of both halves under lukewarm running water. Use your fingers to gently clean all textured areas.
3. **Optional Cleaning Solution:** For a deeper clean, a mild, antibacterial soap can be used. Ensure all soap residue is completely rinsed off.



Image 6.1: Rinsing the open device under water.

4. **Drying:** Place the opened device onto its dedicated stand. The stand is designed to hold the device open, allowing for optimal airflow and hygienic air drying.



Image 6.2: Device drying on its stand.

5. **Avoid Harsh Cleaners:** Do not use alcohol-based cleaners, petroleum-based products, or abrasive materials, as these can damage the elastomer.

## 7. STORAGE

---

Store your TENGA FLIP 0 in a clean, dry place away from direct sunlight and extreme temperatures.

Ensure the device is completely dry before closing and storing to prevent mold or mildew growth.

## 8. TROUBLESHOOTING

If you encounter any issues with your TENGA FLIP 0, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Reduced suction or vacuum effect.	Device not fully closed; insufficient lubricant; damaged material.	Ensure the device is securely latched. Apply more lubricant. Inspect for tears or damage; if damaged, replacement may be necessary.
Device does not close securely.	Latching mechanism is broken or obstructed.	Check for any debris obstructing the latches. If latches are broken, the device may need replacement.
Lubricant leaks during use.	Device not fully closed; excessive lubricant; material damage.	Ensure the device is securely latched. Adjust lubricant quantity. Inspect for damage.
Unpleasant odor.	Improper or insufficient cleaning.	Thoroughly clean and dry the device after each use as per Section 6.

## 9. SPECIFICATIONS

Feature	Detail
Model Name	FLIP ZERO
Item Model Number	TFZ-002
Brand	TENGA
Color	Black
Material	Thermoplastic Elastomer (TPE)
Product Dimensions	3.62 x 3.03 x 8.46 inches
Item Weight	1.04 Pounds
Manufacturer	TENGA
Date First Available	September 19, 2016

## 10. WARRANTY AND SUPPORT

For warranty information or product support, please contact TENGA customer service. Details can typically be found on the official TENGA website or through your retailer.

**Website:** [www.tenga.co.jp/en/](http://www.tenga.co.jp/en/)

