

Mengshen MS-A006A

Mengshen MS-A006A Self Stirring Coffee Mug Instruction Manual

Model: MS-A006A

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Mengshen MS-A006A Self Stirring Coffee Mug. This innovative mug is designed to automatically mix your beverages, such as coffee, tea, milk, or hot chocolate, with the press of a button. Please read this manual thoroughly before first use and retain it for future reference.

2. SAFETY INFORMATION

- **Warning:** This product contains small parts which may be hazardous.
- **Warning:** Remove all packaging attachments before use.
- The packaging contains important safety information. Please read carefully before use and retain all information for future reference.
- Do not immerse the entire mug in water or other liquids, especially the battery compartment.
- This mug is **not dishwasher safe**. Hand wash only.
- Keep out of reach of children.
- Ensure the lid is securely closed when stirring or transporting to prevent spills.

3. PRODUCT OVERVIEW

The Mengshen MS-A006A Self Stirring Coffee Mug features a double-layer stainless steel interior for durability and insulation. It includes an integrated stirring mechanism powered by batteries, activated by a button on the handle.



Figure 3.1: Mengshen MS-A006A Self Stirring Coffee Mug (Exterior View)



Figure 3.2: Interior view of the mug, showing the stirring propeller at the base.

4. SETUP: BATTERY INSTALLATION

The self-stirring mechanism requires 2 x AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover at the bottom of the mug.
2. Twist or slide the cover to open it.
3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover securely.



Figure 4.1: Battery compartment at the base of the mug, showing where to insert 2 AAA batteries.

5. OPERATING INSTRUCTIONS

To use the self-stirring function:

1. Pour your desired beverage into the mug.
2. Add any powders or ingredients you wish to mix (e.g., coffee, sugar, milk powder).
3. Press the yellow button located on the handle of the mug. The internal propeller will begin to stir your drink.
4. Once your beverage is mixed to your satisfaction, release the button to stop stirring.
5. You can use the included lid to keep your drink warm and prevent spills, especially when traveling.



Figure 5.1: Press the yellow button on the handle to activate the stirring function.

Your browser does not support the video tag.

Video 5.1: Demonstration of the self-stirring function with water. The video shows the mug being filled with water, the button being pressed to activate stirring, and the water swirling inside. The lid is also demonstrated.

6. CLEANING AND MAINTENANCE

- **Hand wash only:** This mug is not suitable for dishwashers.
- To clean, rinse the interior of the mug with warm water and mild soap.
- Do not submerge the base of the mug where the battery compartment is located.
- Wipe the exterior with a damp cloth.
- Ensure the mug is completely dry before storing or installing new batteries.
- If the mug will not be used for an extended period, remove the batteries to prevent leakage.

7. TROUBLESHOOTING

- **Stirring mechanism not working:**
 - Check if batteries are correctly installed with proper polarity.
 - Replace old batteries with new AAA batteries.
 - Ensure the stirring propeller at the bottom is not obstructed.
- **Leakage from lid:**
 - Ensure the lid is properly aligned and securely closed.
 - Check the silicone seal on the lid for any damage or misalignment.
- **Incomplete mixing:**
 - Reduce the amount of powder or thick ingredients.
 - Ensure there is enough liquid for proper mixing.

8. SPECIFICATIONS

Feature	Detail
Brand	Mengshen
Model Number	MS-A006A
Capacity	400 Milliliters
Material	Stainless Steel (Interior)
Power Source	2 x AAA Batteries (not included)
Special Feature	Self-stirring mechanism
Product Dimensions	1.97"D x 1.97"W x 1.97"H <i>(Note: These dimensions may refer to packaging or internal components. Please refer to the actual product for accurate mug size.)</i>
Care Instructions	Hand wash only, not dishwasher safe

9. WARRANTY AND SUPPORT

For warranty information or product support, please contact Mengshen customer service through the retailer where the product was purchased. Please have your model number (MS-A006A) and purchase date available when contacting support.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question