

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CKPSMS](#) /

› [CKPSMS Metal Bobbins #0115367000 Instruction Manual](#)

CKPSMS 0115367000

CKPSMS Metal Bobbins #0115367000 Instruction Manual

Model: 0115367000

INTRODUCTION

This manual provides essential information for the proper use and maintenance of CKPSMS Metal Bobbins, part number 0115367000. These bobbins are designed as compatible replacements for a wide range of BERNINA sewing machine models. Please read this manual thoroughly before use to ensure optimal performance and compatibility with your sewing machine.



Image: A pack of 30 CKPSMS Metal Bobbins, part number 0115367000.

COMPATIBILITY

The CKPSMS Metal Bobbins #0115367000 are compatible with a broad range of BERNINA sewing machine models. It is crucial to verify your machine's model number against the lists below to ensure correct fitment.

Compatible BERNINA Models:

- **1-Series:** 125, 130, 135, 135S, 140, 145, 145S, 150, 153, 155, 160, 163, 165, 170
- **2-Series:** 210, 220, 230, 230PE, 240
- **3-Series:** 330, 350, 350PE, 380
- **4-Series:** 430, 440
- **5-Series:** 530, 532, 534, 550QE
- **6-Series:** 600, 610, 630, 642, 644
- **7-Series:** 700, 707, 708, 709, 717, 718, 719, 730 Record *(Note: NOT Artista 730), 731, 732*
- **8-Series:** 800, 801, 801S, 802, 802S, 803, 807, 808, 809, 810, 811, 817, 818, 819, 830, 830E, 831, 832
- **9-Series:** 900, 900E, 910, 930, 931, 932

- **1000-Series:** 1004, 1005, 1006, 1008, 1010, 1011, 1015, 1020, 1030, 1031, 1080, 1080QE, 1090, 1090QE
- **1100-Series:** 1120, 1130, 1130LE, 1130S
- **1200-Series:** 1230, 1260
- **1500-Series:** 1530
- **B-Series:** B215, B330, B380
- *Also compatible with all Activa, Aurora & Virtuosa Models within the listed series.*

Important Incompatibility Notice:

These bobbins (#0115367000) are **NOT** compatible with the following BERNINA models, which typically use Bobbin #0060265000:

- **1000-Series:** 1000, 1000S, 1001, 1050, 1070
- **1600-Series:** 1630
- **Artista Series:** Artista 180, Artista 185, Artista 200, Artista 640, Artista 730, Artista 730E
- **Aurora Series:** Aurora 435, Aurora 450
- **B-Series:** B560, B580

SETUP AND INSTALLATION

Installing the bobbin correctly is essential for proper sewing machine operation. Always refer to your specific BERNINA sewing machine's instruction manual for detailed steps on bobbin winding and insertion, as procedures may vary slightly by model.

1. Winding the Bobbin:

Place the empty CKPSMS metal bobbin onto the bobbin winder spindle of your sewing machine. Follow your machine's instructions for threading the bobbin winder and winding the thread onto the bobbin. Ensure the thread winds evenly and smoothly.

2. Inserting the Bobbin:

Once wound, remove the bobbin from the winder. Open the bobbin case area of your sewing machine. Depending on your machine, you will either insert the bobbin directly into a drop-in bobbin case or place it into a separate metal bobbin case before inserting it into the machine. Ensure the thread is correctly routed through any tension springs or guides as specified by your machine's manual.

3. Testing:

After installation, perform a test stitch on a scrap piece of fabric to confirm proper tension and stitch formation before beginning your project.

OPERATING GUIDELINES

These bobbins function as standard metal bobbins within compatible BERNINA sewing machines. Adhere to the operating instructions provided with your sewing machine for all sewing tasks, including thread selection, tension adjustments, and fabric handling.

- **Thread Compatibility:** Use high-quality sewing thread appropriate for your project and machine.
- **Tension:** Proper upper and lower thread tension is crucial for balanced stitches. Adjust as needed according to your machine's guidelines.
- **Regular Checks:** Periodically check the bobbin for any signs of wear or damage that could affect thread flow or machine performance.

MAINTENANCE

Proper care of your bobbins will extend their lifespan and contribute to consistent sewing performance.

- **Cleaning:** Remove any lint or thread residue from the bobbins regularly, especially after extensive use. A small brush or compressed air can be used.
- **Storage:** Store bobbins in a clean, dry bobbin case or organizer to prevent dust accumulation and tangling of threads. Avoid storing them loosely where they can get scratched or bent.
- **Inspection:** Before each use, quickly inspect bobbins for any burrs, nicks, or deformities that could snag thread or damage your machine. Discard any damaged bobbins.

TROUBLESHOOTING

If you encounter issues while using these bobbins, consider the following common troubleshooting steps:

- **Thread Breakage or Uneven Stitches:**
 - Ensure the bobbin is wound evenly and not overfilled.
 - Check that the bobbin is inserted correctly into the bobbin case and that the thread is properly routed through all guides.
 - Verify that the bobbin is the correct size (#0115367000) for your specific BERNINA model. Refer to the compatibility section.
 - Adjust upper and lower thread tension as per your sewing machine's manual.
 - Inspect the bobbin for any damage (burrs, nicks) that might be snagging the thread.
- **Bobbin Not Fitting:**
 - Double-check your BERNINA model against the compatibility list. Some BERNINA models require a different bobbin type (e.g., #0060265000).
 - Ensure no foreign objects or lint are obstructing the bobbin area.

For persistent issues, consult your BERNINA sewing machine's comprehensive troubleshooting guide or contact a qualified sewing machine technician.

SPECIFICATIONS

Product Specifications

Feature	Detail
Part Number	0115367000
Alternative Part Numbers	0015367200, 0115367T
Material	Steel
Quantity per Pack	30 Pieces
Approximate Diameter	20.6 mm
Approximate Width	11.7 mm
Approximate Center Hole Diameter	6 mm

Feature	Detail
Item Weight (30 pcs)	118 g

Notice:

Please pay attention to the size of the product ! #0115367000 NOT fit BERNINA1000, 1000S, 1001, 1050, 1070, 1630, Artista 180, Artista 185, Artista 200, Artista 640, Artista 730, Artista 730E, Aurora 435, Aurora 450, B560, B580. These Models use Bobbin #0060265000 !!




Image: Detailed dimensions of the CKPSMS Metal Bobbin #0115367000.

SUPPORT AND CONTACT

For further assistance or inquiries regarding CKPSMS products, please refer to the official CKPSMS store or contact their customer support. CKPSMS specializes in sewing machine spare parts and can provide expert guidance.

CKPSMS Official Store: [Visit CKPSMS Store on Amazon](#)