

[Manuals.plus](#) /

> [Aikmi](#) /

> Aikmi Digital LCD Alarm Clock User Manual

Aikmi Digital LCD Alarm Clock

Aikmi Digital LCD Alarm Clock User Manual

Model: Digital LCD Alarm Clock

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Aikmi Digital LCD Alarm Clock. Please read this manual thoroughly before using the product to ensure proper function and longevity.

PRODUCT OVERVIEW

IT'S NOT JUST THE ALARM CLOCK
IT'S THE POWER TO WAKE UP LIFE



YOUR TIME MANAGER
CLOSE TO LIFE, MORE INTELLIGENT

Figure 1: Front View of the Alarm Clock. This image displays the clock's large LCD screen showing the time, AM/PM indicator, alarm status, month, date, and current temperature.

PRODUCT INTRODUCTION



BACKLIGHT/SNOOZE BUTTON



TIME DISPLAY



BATTERY BOX



ADJUSTING BUTTON

Figure 2: Rear Controls and Battery Compartment. This image highlights the various buttons and switches on the back of the clock for setting time, date, alarm, and sensor functions, along with the battery compartment.

The Aikmi Digital LCD Alarm Clock is designed for clear time display and reliable alarm functionality. It features a large LCD screen, a gentle wake-up alarm, a 5-minute snooze function, and an intelligent backlight sensor for visibility in various lighting conditions. It also displays date and temperature.

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert three (3) AAA batteries, ensuring correct polarity (+/-). Batteries are not included.
4. Close the battery compartment cover securely.

ENERGY SAVING BACKLIGHT LARGE SCREEN INTELLIGENT INDUCTION ENVIRONMENT LIGHT

WITH HIGH SENSITIVE PHOTOSENSITIVE SENSOR, DARK ENVIRONMENT SCREEN DIM LIGHT
AUTOMATIC CHECK THE TIME ON THE SOFT DOES NOT HURT THE EYES



DAYTIME AUTOMATIC SCREEN STANDBY



STAY LIT AT NIGHT




Figure 3: Battery Compartment. This image shows the open battery compartment where three AAA batteries are to be inserted.

OPERATING INSTRUCTIONS

1. Setting Time and Date

1. Locate the setting switches on the back of the clock (refer to Figure 2).
2. Slide the main setting switch to the **TIME SET** position.
3. Use the **HOUR** and **MIN/DATE** buttons to adjust the hour and minute.
4. Use the **YEAR** and **MONTH** buttons to set the year and month.
5. After setting, slide the main setting switch back to the **LOCK** position.

2. Setting the Alarm

1. Slide the main setting switch to the **ALARM SET** position.
2. Use the **HOUR** and **MIN/DATE** buttons to adjust the desired alarm time.

3. After setting, slide the main setting switch back to the **LOCK** position.
4. To activate the alarm, slide the **ALARM ON/OFF** switch on the side to the **ON** position. To deactivate, slide it to **OFF**.

3. Snooze Function

- When the alarm sounds, press the large **SNOOZE/LIGHT** button on the top of the clock.
- The alarm will pause and sound again after approximately 5 minutes.
- To turn off the alarm completely, slide the **ALARM ON/OFF** switch to **OFF**.



Figure 4: Snooze/Light Button. This image shows the prominent button on top of the clock used for activating the snooze function or temporarily illuminating the backlight.

4. Backlight and Sensor Function

- **Manual Backlight:** Press the **SNOOZE/LIGHT** button on the top of the clock to temporarily illuminate the display.
- **Automatic Sensor Backlight:** Locate the **SENSOR** switch on the back of the clock (refer to Figure 2).
- Slide the **SENSOR** switch to **ON** to activate the automatic backlight. The display will softly illuminate in dark

environments.

- Slide the **SENSOR** switch to **OFF** to disable the automatic backlight.

SUITABLE FOR DIFFERENT JOB REQUIREMENTS, HELP YOU PLAN YOUR LIFE AND WORK PROPERLY




Figure 5: Automatic Sensor Backlight. This image illustrates how the clock's display automatically adjusts its brightness based on ambient light when the sensor function is enabled.

5. Temperature Display

- The clock displays the ambient temperature.
- To switch between Celsius (°C) and Fahrenheit (°F), locate the **°C/°F** button on the back of the clock (refer to Figure 2) and press it.

6. 12/24 Hour Format

- To switch between 12-hour and 24-hour time formats, locate the **12/24** button on the back of the clock (refer to Figure 2) and press it.

MAINTENANCE

- Clean the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the clock to extreme temperatures, direct sunlight, or high humidity.
- If the clock will not be used for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is blank or dim.	Low or dead batteries; incorrect battery installation.	Replace batteries with new AAA batteries, ensuring correct polarity.
Alarm does not sound.	Alarm is not activated; alarm time is incorrect.	Ensure the ALARM ON/OFF switch is in the ON position. Verify the alarm time is set correctly.
Snooze function not working.	Alarm was turned off instead of snoozed.	Press the SNOOZE/LIGHT button when the alarm sounds, do not slide the ALARM ON/OFF switch to OFF .
Automatic backlight not working.	Sensor switch is off; insufficient darkness.	Ensure the SENSOR switch is in the ON position. The sensor activates in genuinely dark environments.

SPECIFICATIONS

- **Model:** Digital LCD Alarm Clock
- **Brand:** Aikmi
- **Display Type:** Digital LCD
- **Power Source:** 3 x AAA Batteries (not included)
- **Material:** Plastic
- **Functions:** Time, Date, Alarm, Snooze, Backlight (Manual & Sensor), Temperature (°C/°F), 12/24 Hour Format
- **Dimensions:** Approximately 5.3 inches (W) x 1.8 inches (H)

WARRANTY AND SUPPORT

Aikmi is committed to providing high-quality products. If you encounter any issues with your Digital LCD Alarm Clock, please contact our customer support for assistance. We offer a 100% satisfaction guarantee, including options for refund or replacement for product defects.

For support, please refer to the contact information provided with your purchase or visit the official Aikmi website.

