### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Klim /
- > KLIM Pulse Bluetooth 4.1 In-Ear Earphones User Manual

#### Klim KLPB

# KLIM Pulse Bluetooth 4.1 In-Ear Earphones User Manual

Model: KLPB | Brand: Klim

#### **INTRODUCTION**

The KLIM Pulse Bluetooth 4.1 In-Ear Earphones are designed to provide a high-quality audio experience with wireless convenience. Featuring Bluetooth 4.1 connectivity, noise insulation, and a comfortable fit, these earphones are suitable for various activities including sports, music listening, and making calls. The magnetic tips offer easy storage, and the included memory foam ear tips ensure a secure and comfortable fit for extended use.



Image: The KLIM Pulse Bluetooth 4.1 In-Ear Earphones, showcasing their sleek black design and magnetic earbud feature.

# PACKAGE CONTENTS

Upon opening your KLIM Pulse earphone package, you should find the following items:

- KLIM Pulse Bluetooth 4.1 In-Ear Earphones
- USB Charging Cable
- User Manual
- Various sizes and types of ear tips (including memory foam), totaling 12 pieces.



Image: A close-up view of the KLIM Pulse earphones with various ear tip options, highlighting the magnetic tips and different earfoam colors.

# **SETUP**

# 1. Charging the Earphones

Before initial use, fully charge your KLIM Pulse earphones. A full charge typically takes approximately 2 hours and provides up to 6 hours of uninterrupted listening time.

- 1. Connect the micro-USB end of the charging cable to the charging port on the earphone control unit.
- 2. Connect the USB-A end of the charging cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
- 3. The LED indicator on the control unit will illuminate during charging and change color or turn off when charging is complete.



Image: The KLIM Pulse earphones with glowing blue circles, illustrating the charging process and battery life.

# 2. Selecting Ear Tips

The KLIM Pulse earphones come with 12 different ear tips, including memory foam options, to ensure a comfortable and secure fit. Experiment with different sizes and materials to find the best fit for your ears. A proper fit is crucial for optimal sound quality and noise insulation.

- Gently remove the pre-installed ear tips.
- Select a pair of ear tips that feel comfortable and create a good seal in your ear canal.
- Attach the chosen ear tips firmly to the earphone nozzles.

# 3. Bluetooth Pairing

The KLIM Pulse earphones are compatible with all Bluetooth-enabled devices (phones, laptops, tablets, etc.).

- 1. Ensure the earphones are charged and turned off.
- 2. Press and hold the multi-function button (usually the power button) on the control unit until the LED indicator flashes red and blue, indicating pairing mode.
- 3. On your device, enable Bluetooth and search for available devices.

- 4. Select "KLIM Pulse" from the list of found devices.
- 5. Once paired, the LED indicator will typically flash blue slowly or turn solid blue.



Image: The KLIM Pulse earphones alongside icons for a laptop, phone, and tablet, illustrating their broad compatibility with Bluetooth devices.

# **OPERATING INSTRUCTIONS**

# **Basic Controls**

The control unit on your KLIM Pulse earphones allows for easy management of audio playback and calls.

Button/Action	Function
Power Button (Multi-function)	Press and Hold: Power On/Off, Enter Pairing Mode Single Press: Play/Pause Music, Answer/End Call Double Press: Redial last number
Volume Up (+)	Single Press: Increase Volume Press and Hold: Next Track

Button/Action	Function
Volume Down (-)	Single Press: Decrease Volume Press and Hold: Previous Track

# **Making and Receiving Calls**

- Answering a Call: Press the Power Button once.
- Ending a Call: Press the Power Button once during a call.
- Rejecting a Call: Press and hold the Power Button for 2 seconds.
- **Redialing:** Double-press the Power Button to redial the last number.

# **Magnetic Feature**

The KLIM Pulse earphones feature magnetic tips. When not in use, you can snap the earbuds together around your neck to prevent them from falling off and for convenient storage.




Image: A woman wearing KLIM Pulse earphones, demonstrating their comfortable fit and suitability for active use.

# **M**AINTENANCE

To ensure the longevity and optimal performance of your KLIM Pulse earphones, follow these maintenance guidelines:

- Cleaning: Regularly wipe the earphones and ear tips with a soft, dry, lint-free cloth. For ear tips, you can gently clean them with a damp cloth and mild soap, ensuring they are completely dry before reattaching.
- **Storage:** When not in use, store the earphones in a clean, dry place, away from extreme temperatures and direct sunlight. The magnetic tips help keep them tangle-free.
- Avoid Moisture: While the earphones have some water resistance, avoid submerging them in water or exposing them to heavy rain.
- **Handle with Care:** Do not pull on the cable excessively or apply undue force to the earbuds or control unit.

# **TROUBLESHOOTING**

If you encounter issues with your KLIM Pulse earphones, refer to the following common solutions:

Problem	Possible Solution
Earphones do not turn on.	Ensure the earphones are fully charged. Connect them to a power source and check the charging indicator.
Cannot pair with device.	Ensure earphones are in pairing mode (LED flashing red/blue).  Make sure Bluetooth is enabled on your device.  Move the earphones closer to your device.  Turn off and on both the earphones and your device, then try pairing again.  Clear previous Bluetooth connections on your device if necessary.
No sound or poor sound quality.	Check the volume levels on both the earphones and your connected device.  Ensure the earphones are properly paired and connected.  Try different ear tips to ensure a secure and sealed fit in your ear canal.  Move away from sources of strong electromagnetic interference.
Earphones keep disconnecting.	Ensure the earphones are within the Bluetooth range of your device.  Check battery level of the earphones.  Avoid physical obstructions between the earphones and your device.

#### **S**PECIFICATIONS

Feature	Detail
Model Name	KLPB
Brand	Klim
Connectivity Technology	Wireless (Bluetooth 4.1)

Feature	Detail
Form Factor	In Ear
Color	Black
Material	Memory Foam (ear tips)
Item Weight	18.1 g (0.04 Pounds)
Product Dimensions	60 x 1.9 x 2.3 cm
Frequency Range	20 Hz - 20,000 Hz
Battery Life	Up to 6 hours (approx.)
Charging Time	Approx. 2 hours
Compatible Devices	Mobile Phones, Laptops, Tablets, Smart Speakers, TVs, Car Audio Systems, Game Consoles, Music Production Equipment, Motorcycles



Image: An infographic displaying various features of the KLIM Pulse earphones, including Bluetooth dual connectivity, magnetic design, voice calls, Hi-Fi sound quality, and compatibility with multiple operating systems.

# WARRANTY INFORMATION

The KLIM Pulse earphones come with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable performance. Please retain your proof of purchase for warranty claims.

For any warranty-related inquiries or issues, please contact KLIM customer support.

# **CUSTOMER SUPPORT**

If you require further assistance or have questions not covered in this manual, please contact KLIM customer support. Our European team aims to provide a response within 24 hours.

• Email: contact@klimtechs.com

• Website: www.klimtechs.com

#### © 2024 Klim. All rights reserved.

#### **Related Documents - KLPB**



#### KLIM Talk Microphone User Manual and Setup Guide

Comprehensive user manual for the KLIM Talk Microphone. Learn how to install, configure, and use the microphone with PC, Mac, and PS4. Includes troubleshooting tips and guides for voice recordings, speech recognition, and reducing background noise using Audacity.



#### KLIM Discman User Manual: Portable CD Player Guide

Comprehensive user manual for the KLIM Discman portable CD player, covering setup, operation, features, and troubleshooting. Includes safety instructions and technical specifications.



#### KLIM Speaker User Manual: High-Fidelity Portable CD Player with Rechargeable Battery

Comprehensive user manual for the KLIM Speaker, a portable CD player offering high-fidelity sound reproduction. Learn about its features, operation, charging, playback options, and troubleshooting. Includes package contents, technical specifications, and safety guidelines.



#### KLIM Nomad Portable CD Player User Manual

Comprehensive user manual for the KLIM Nomad portable CD player, covering safety instructions, product features, specifications, operation, troubleshooting, and more. Includes multilingual support.



#### KLIM Discover Portable CD Player User Manual

Comprehensive user manual for the KLIM Discover portable CD player, covering setup, playback options, features, FM transmitter, Bluetooth connectivity, and troubleshooting.



#### KLIM Tempest User Manual - Effective Laptop Cooling

Comprehensive user manual for the KLIM Tempest laptop cooler. Learn about its features, assembly, operation, and troubleshooting to keep your laptop cool and performing optimally.

Documents - Klim - KLPB

no relevant documents