

[Manuals.plus](#) /

› [Mattel](#) /

› Mattel Disney and Pixar Cars Florida Speedway Mega 3-Level Garage Playset Instruction Manual

Mattel FGF49

Mattel Disney and Pixar Cars Florida Speedway Mega 3-Level Garage Playset

Model: FGF49

INTRODUCTION

This instruction manual provides important information for the assembly, operation, and maintenance of your Mattel Disney and Pixar Cars Florida Speedway Mega 3-Level Garage Playset. This playset offers a comprehensive story and racecar play experience, featuring five unique play areas and three levels of interactive fun. It includes two plastic vehicles, Lightning McQueen and Cruz Ramirez, to begin your racing adventures.

SAFETY INFORMATION

- **Age Recommendation:** This playset is designed for children aged 4 years and up.
- **Small Parts:** The playset may contain small parts that could pose a choking hazard for younger children. Adult supervision is recommended.
- **Assembly:** Ensure all parts are securely connected before play to prevent detachment and potential hazards.
- **Usage:** Use the playset on a flat, stable surface to prevent tipping.
- **Cleaning:** Refer to the Maintenance section for proper cleaning instructions.

WHAT'S IN THE BOX

The Mattel Disney and Pixar Cars Florida Speedway Mega 3-Level Garage Playset includes the following components:

- 1 x Florida Speedway Mega Garage Playset
- 2 x Plastic Character Vehicles (Lightning McQueen and Cruz Ramirez)

SETUP

This playset is designed for immediate play with no assembly required. Simply remove the components from the packaging, and the Florida Speedway Mega Garage is ready for action.



Image: The fully assembled Florida Speedway Mega Garage Playset, showcasing its three levels and various play areas, including the ramp and elevator. Lightning McQueen and Cruz Ramirez toy cars are visible on the playset.

OPERATING INSTRUCTIONS

The Florida Speedway Mega Garage Playset offers multiple interactive features for imaginative play. Use the included Lightning McQueen and Cruz Ramirez vehicles, or other compatible Cars die-cast vehicles (sold separately), to explore the garage.



Image: A young child is shown actively playing with the Florida Speedway Mega Garage Playset, placing a toy car on the upper level, demonstrating typical interaction with the toy.

Key Features:

- **Working Elevator:** Transport vehicles between the three levels of the garage.
- **Paint Shop:** Customize or prepare your cars for the race.
- **TV Announcer Area:** Features a large screen monitor and camera for race commentary.
- **Car Wash:** Clean your vehicles after a tough race.
- **Tire and Gas Service Area:** Includes a working lift for quick pit stops.
- **Souvenir and Concession Stand:** For race day refreshments.
- **Connectors:** Allows for integration with other Cars playsets (sold separately).

Using the Elevator:

Place a vehicle into the elevator shaft. Manually operate the elevator to raise or lower the car to different levels of the garage. This feature allows for dynamic movement and access to all play areas.





Image: A detailed view of the playset's working elevator, with a toy car positioned inside, illustrating its function to move vehicles vertically between floors.

Racing Down the Ramp:

Position a vehicle at the top of the multi-level ramp. Release the car to send it speeding down to the lower levels, simulating race action and quick exits from the garage.

**RACE
DOWN
THE
RAMP!**



Image: A close-up shot of the playset's racing ramp, showing a red toy car in motion as it descends, highlighting the dynamic play feature.

Car Wash Feature:

Drive your vehicles through the car wash area. The rotating brushes and other details provide an immersive experience for cleaning your racecars after a dusty track day.



Image: A detailed view of the car wash station within the playset, showing a blue toy car being 'cleaned' by the yellow rotating brushes, illustrating this interactive feature.

MAINTENANCE

To ensure the longevity and cleanliness of your Florida Speedway Mega Garage Playset, follow these maintenance guidelines:

- **Cleaning:** Wipe the playset surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the plastic.
- **Storage:** Store the playset in a cool, dry place away from direct sunlight when not in use to prevent material degradation.
- **Inspection:** Periodically check all parts for any signs of wear or damage. Discontinue use if any significant damage is found and contact customer support.

TROUBLESHOOTING

If you encounter any issues with your playset, consider the following common solutions:

- **Parts Not Connecting:** Ensure all pieces are aligned correctly and pushed firmly into place. Refer to any visual guides on the packaging for proper orientation.
- **Vehicles Not Moving Smoothly:** Check for any obstructions on the ramps or in the elevator shaft. Ensure the surfaces are clean and free of debris.
- **Missing Pieces:** Carefully check all packaging materials. If a piece is genuinely missing, contact Mattel customer support.

SPECIFICATIONS

Brand Name	Mattel
Model Name	Disney Pixar Cars 3 Florida Speedway Mega Garage
Model Number	FGF49
Age Range Description	4 years and up
Included Components	Toy
Material Type	Plastic
Item Dimensions (LxWxH)	24.25 x 15 x 5.5 inches
Item Weight	2.7 Pounds
Number of Pieces	1 (Playset)
Power Source	Non-powered
Assembly Required	No

WARRANTY INFORMATION

This product is sold without a manufacturer's warranty. For any concerns regarding product quality or defects upon purchase, please refer to the retailer's return policy or contact Mattel customer support directly.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your Mattel Disney and Pixar Cars Florida Speedway Mega 3-Level Garage Playset, please contact Mattel customer support through their official website or the contact information provided on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question