Travel Blue 065

Travel Blue Foldable Travel Backpack 20L Instruction Manual

Model: Folding Backpack (Model 065)

Introduction

This manual provides essential information for the proper use and care of your Travel Blue Foldable Travel Backpack 20L. Designed for convenience and durability, this lightweight and compact backpack is ideal for various travel scenarios, day trips, and daily use. Please read these instructions carefully to ensure optimal performance and longevity of your product.



Image: Front view of the Travel Blue Foldable Travel Backpack 20L in its unfolded state, showcasing its main compartment and front pocket.

Setup: Unfolding the Backpack

Your Travel Blue backpack is designed to be highly compact when folded. Follow these steps to unfold it for use:

1. **Locate the integrated pouch:** The backpack folds into its own front pocket. Identify the zipper for this pouch.
2. **Unzip the pouch:** Carefully unzip the pouch.
3. **Unfold the main body:** Gently pull the main fabric of the backpack out from the pouch.
4. **Smooth out the fabric:** Once fully unfolded, smooth out any creases in the fabric.
5. **Adjust straps:** Adjust the shoulder straps to your desired length for comfortable carrying.



Image: The Travel Blue Foldable Travel Backpack 20L in its compact, folded state, ready for storage or transport.

Operating Instructions

The Travel Blue Foldable Travel Backpack 20L offers multiple storage options for your belongings:

- **Main Compartment:** The large main compartment provides 20 liters of storage capacity. Use it for larger items such as clothing, books, or travel essentials. The zipper closure ensures contents are secure.
- **Front Zip Pocket:** A convenient front zippered pocket is available for smaller items that require quick access, such as keys, wallets, or travel documents.
- **Mesh Side Pockets:** Two mesh pockets are located on the sides of the backpack. These are suitable for holding water bottles, umbrellas, or other items you need to grab easily.
- **Shoulder Straps:** The adjustable shoulder straps allow you to customize the fit for comfort. Ensure both straps are evenly adjusted to distribute weight across your shoulders.



Image: Side view of the backpack, highlighting the mesh side pocket designed for water bottles or other quick-access items.



Image: Back view of the backpack, showing the adjustable shoulder straps and the overall design for comfortable carrying.

Maintenance and Care

To maintain the quality and extend the lifespan of your backpack, follow these care instructions:

- **Cleaning:** The backpack is made from polyester. It is recommended to**hand wash only**. Use mild soap and cold water. Do not bleach, iron, or tumble dry.
- **Drying:** Air dry the backpack completely in a shaded area. Avoid direct sunlight, which can degrade the fabric over time.
- **Storage:** When not in use, ensure the backpack is clean and dry before folding it into its compact pouch. Store in a cool, dry place away from direct sunlight.
- **Avoid Overloading:** While durable, avoid consistently overloading the backpack beyond its intended capacity to prevent strain on seams and zippers.

Troubleshooting

Here are solutions to common issues you might encounter:

- **Difficulty Folding:** If the backpack is difficult to fold back into its pouch, ensure all compartments are empty and the fabric is laid flat. Start by tucking in the corners evenly.
- **Zipper Snags:** If a zipper snags, do not force it. Gently pull the fabric away from the zipper teeth and try to move the slider slowly. Applying a small amount of zipper lubricant (e.g., beeswax or a graphite pencil) can help.
- **Minor Stains:** For small, localized stains, spot clean immediately with a damp cloth and mild soap.

Specifications

Feature	Detail
Model Name	Folding Backpack
Model Number	065-BK
Storage Volume	20 Litres
Material Type	Polyester
Item Weight	220 Grams
Item Dimensions (D x W x H)	41D x 13W x 31H Centimeters
Water Resistance	Water Resistant
Closure Type	Zipper
Number of Compartments	1 (Main)
Number of Pockets	Multiple (Front zip pocket, Mesh side pockets)
Product Care Instructions	Hand Wash Only
Country of Origin	China

Warranty Information

This Travel Blue Foldable Travel Backpack 20L comes with a **36 Months World Wide Guarantee**. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, abrasion, extreme temperatures, solvents, acids, normal wear and tear, or transport damage (e.g., by airlines). Please retain your proof of purchase for any warranty claims.

Customer Support

For any inquiries, support, or warranty claims regarding your Travel Blue product, please contact:
Travel Blue Product India PVT LTD
102, Rama Gulab Apartment, Subhash Road
Tejpal Scheme Main Road, Vile Parle East,
Mumbai-400057, Maharashtra, India

For international support, please refer to the official Travel Blue website or contact your local distributor.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question