KKT KOLBE BASE604ED

KKT KOLBE BASE604ED Wall-Mounted Cooker Hood

Instruction Manual

1. Introduction and Safety Information

Thank you for choosing the KKT KOLBE BASE604ED wall-mounted cooker hood. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your appliance. Please read these instructions carefully before use and keep them for future reference.

General Safety Guidelines

- Ensure the appliance is installed by a qualified technician in accordance with local regulations.
- Always disconnect the power supply before performing any maintenance or cleaning.
- Do not allow children to operate the appliance without supervision.
- The cooker hood is designed for domestic use only, to extract cooking fumes. Do not use it for other purposes.
- Maintain adequate ventilation in the room when the hood is used simultaneously with gas or other fuel-burning appliances.
- The inclined design of the 60 cm wide BASE604ED hood provides ample headroom, allowing you to move freely and safely over the hob without discomfort.



Image 1.1: Front view of the KKT KOLBE BASE604ED cooker hood in a kitchen setting.



Image 1.2: Side view of the KKT KOLBE BASE604ED cooker hood in a kitchen setting.

2. Setup and Installation

Unpacking and Contents

Carefully remove the cooker hood from its packaging. Check for any damage during transit. The package should include the cooker hood unit and a charcoal filter (if operating in recirculation mode).

Mounting the Hood

The KKT KOLBE BASE604ED is designed for wall mounting. Ensure the wall structure is strong enough to support the weight of the hood. Refer to the technical drawing for precise dimensions and recommended mounting heights above your cooking surface.




Image 2.1: Technical drawing showing the dimensions of the cooker hood for installation planning.

Ventilation Options

This cooker hood supports both exhaust (ducted) and recirculation modes. For exhaust mode, connect the hood to an external ducting system. For recirculation mode, ensure the charcoal filter is correctly installed to purify the air before returning it to the kitchen.

3. Operating Instructions

The KKT KOLBE BASE604ED features intuitive push-button controls for easy operation.

Control Panel

The control panel consists of several push buttons to manage the hood's functions:

- **Power On/Off:** Activates or deactivates the hood.
- **Fan Speed Selection:** Adjusts the ventilation power.
- **Light On/Off:** Controls the LED lighting.



Image 3.1: Detail of the push-button control panel.

Fan Speed Settings

The cooker hood offers 3 ventilation levels to effectively clear your kitchen of steam and cooking odors. Select the appropriate speed based on the intensity of cooking fumes:

- **Speed 1:** For light cooking and minimal odors.
- **Speed 2:** For normal cooking conditions.
- **Speed 3:** For heavy cooking, frying, or strong odors.

LED Lighting

High-quality LED lighting illuminates your cooking surface, providing optimal visibility for cooking and frying. Press the light button to turn the lights on or off.



Image 3.2: Detail of the LED lighting.

4. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your cooker hood.

Cleaning the Hood Surface

Clean the exterior surfaces of the hood regularly with a soft cloth and a mild, non-abrasive detergent. Avoid using harsh chemicals or abrasive materials that could damage the stainless steel or glass finish. Always ensure the power is disconnected before cleaning.

Grease Filter Maintenance (Mesh Filter)

The metal grease filters (mesh type) should be cleaned frequently, approximately every 2-4 weeks depending on usage. They can be washed by hand with hot soapy water or in a dishwasher. Ensure they are completely dry before re-installing.

Charcoal Filter Replacement (Recirculation Mode Only)

If your hood is operating in recirculation mode, the charcoal filter absorbs odors and requires periodic replacement. The frequency of replacement depends on usage, typically every 3-6 months. Follow the instructions provided with the charcoal filter for proper removal and installation. Charcoal filters cannot be washed and reused.

5. Troubleshooting

Before contacting customer service, please check the following common issues and solutions:

- **Hood does not turn on:** Check if the power cord is properly plugged in and if the circuit breaker is tripped.
- **Low suction power:** Ensure the grease filters are clean and not clogged. If in recirculation mode, check if the charcoal filter needs replacement. Verify that there are no obstructions in the ducting system (if applicable).
- **Excessive noise:** Check if the fan blades are clean and free from obstructions. Ensure all mounting screws are tight.
- **Lights not working:** Check if the light switch is on. If the LED lights are not working, they may require professional replacement.

If the problem persists after checking these points, please contact KKT KOLBE customer support.

6. Specifications

Below are the technical specifications for the KKT KOLBE BASE604ED cooker hood:

Specification	Value
Brand	KKT KOLBE
Model Number	BASE604ED
Product Dimensions (D x W x H)	29.6 x 60 x 28.3 cm
Color	Black/Operation (Silver finish)
Special Feature	Recirculation Hood
Finish Type	Stainless Steel, Inox
Airflow Capacity	336 Cubic Meters per Hour
Material	Stainless Steel, Glass
Noise Level	63.5 Decibels
Mounting Type	Wall Mount
Included Components	Charcoal Filter
Control Type	Push Button
Voltage	240 Volts
Number of Speeds	3
Light Source Type	LED
Wattage	68 Watts
Filter Type	Mesh
Ventilation Type	Exhaust

Weight	7.5 Kilograms
Energy Star Certified	Yes
Item Shape	Pyramid
Hood Design	Wall-Mounted Cooker Hood




Image 6.1: Energy efficiency label for the BASE604ED model.

7. Warranty and Support

Warranty Information

Your KKT KOLBE BASE604ED cooker hood comes with a standard manufacturer's warranty. Please refer to the warranty card

included with your purchase for specific terms, conditions, and duration. Keep your proof of purchase for any warranty claims.

Customer Support

For technical assistance, spare parts, or any questions not covered in this manual, please contact KKT KOLBE customer support. Contact details can typically be found on our official website or on the warranty documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question