

Epson WF-7710

Epson WorkForce WF-7710 Wireless Wide-format Color Inkjet Printer Instruction Manual

Model: WF-7710

INTRODUCTION

The Epson WorkForce WF-7710 is a versatile wide-format all-in-one inkjet printer designed for office environments. It offers print-shop-quality borderless prints up to 13" x 19" and scans up to 11" x 17". This device integrates printing, scanning, copying, and faxing functionalities, along with advanced connectivity options.

WHAT'S IN THE BOX

WorkForce® WF-7710



*SCROLL DOWN TO "FROM THE MANUFACTURER" TO LEARN MORE.

Smartphone sold separately.

Image: Contents of the Epson WorkForce WF-7710 box, including the printer, ink cartridges, power cord, and documentation.

- Epson WorkForce WF-7710 All-in-One Printer
- 4x DURABrite Ultra Ink cartridges (1x Black, 1x Cyan, 1x Magenta, 1x Yellow)
- Instruction Manual
- Power Cord

SETUP

1. Unpacking and Placement

Carefully remove the printer from its packaging. Place the printer on a stable, flat surface with adequate space around it for operation and ventilation. Ensure all protective tapes and packing materials are removed from the exterior and interior of the printer.

2. Power Connection

Connect the power cord to the printer and then to a grounded electrical outlet. Do not connect the printer to

your computer yet.

3. Initial Ink Cartridge Installation



Image: Close-up view of the Epson WorkForce WF-7710's ink cartridge bay with four color cartridges inserted.

Follow the on-screen instructions on the printer's 4.3" color touchscreen to install the initial set of DURABrite Ultra Ink cartridges. Ensure each cartridge clicks into place securely.

4. Paper Loading



Image: The Epson WorkForce WF-7710 printer with paper loaded in both the main paper tray and the rear feed, ready for printing.

Load paper into the 250-sheet paper tray. The printer also features a rear feed for specialty paper. Adjust the paper guides to fit the paper size.

5. Network Setup

The WF-7710 supports Wi-Fi, Wi-Fi Direct, and Ethernet connectivity. Follow the instructions on the printer's touchscreen to connect to your network. For Wi-Fi, select your network and enter the password. For Ethernet, connect an Ethernet cable from the printer to your router.

OPERATING THE PRINTER



Image: An infographic highlighting the key features of the Epson WorkForce WF-7710, including Wireless, Wide-format Print, Copy, Scan, Fax, and Ethernet capabilities.

1. Using the Touchscreen

The 4.3" color touchscreen provides intuitive access to all printer functions. Navigate through menus by swiping and tapping. The home screen displays options for Copy, Scan, Fax, and Presets.

2. Printing

To print from a computer, ensure the printer drivers are installed. Select the print option from your application, choose the WF-7710, and adjust settings as needed (paper size, type, color/black & white, 2-sided printing). The printer supports borderless prints up to 13" x 19".



Image: The Epson WorkForce WF-7710 actively printing a colorful document, with the output tray extended.

3. Mobile Printing

In the box

WorkForce® WF-7710



Wide-format All-in-One Printer



252 Series Genuine
Epson® Ink cartridges

*Epson recommends the use of genuine ink
to ensure optimal quality and performance.*



Power cord
(USB cable
not included)



CD and
documentation

Image: A smartphone displaying a document, held near the Epson WorkForce WF-7710, indicating wireless printing capabilities from mobile devices.

The WF-7710 supports wireless printing from iPad, iPhone, Android tablets, and smartphones. Download the appropriate Epson Connect app to enable printing directly from your mobile device.

4. Copying

Place your document on the scanner glass or in the 35-page Auto Document Feeder (ADF). Select 'Copy' from the touchscreen, choose your settings (number of copies, color/black & white, 2-sided), and press Start. The printer supports automatic 2-sided copying.

5. Scanning

Place your document on the scanner glass or in the ADF. Select 'Scan' from the touchscreen. You can scan to a computer, cloud service, or USB drive. The printer scans up to 11" x 17" documents.

6. Faxing

Load your document into the ADF. Select 'Fax' from the touchscreen, enter the recipient's fax number, and press Start. The printer supports automatic 2-sided faxing.

MAINTENANCE

1. Replacing Ink Cartridges

When an ink cartridge runs low or is empty, a message will appear on the touchscreen. Open the ink cartridge cover, press the tab on the cartridge to release it, and remove the old cartridge. Unpack the new Epson DURABrite Ultra Ink cartridge, remove the yellow tape, and insert it into the correct slot until it clicks. Close the cover.

2. Cleaning the Printer

Regularly clean the exterior of the printer with a soft, damp cloth. For print quality issues, use the printer's maintenance utility (accessible via the touchscreen or computer software) to perform print head cleaning or print head alignment.

TROUBLESHOOTING

1. Paper Jams

If a paper jam occurs, the printer's touchscreen will display instructions on how to clear it. Typically, this involves opening access covers and carefully removing the jammed paper. Ensure all paper fragments are removed to prevent further jams.

2. Connectivity Issues

If the printer is not connecting to your network or computer, verify that the Wi-Fi or Ethernet connection is active. Restart your router, computer, and printer. Ensure the printer drivers are up to date on your computer.

3. Print Quality Problems

For faded prints, streaks, or incorrect colors, perform a print head cleaning and nozzle check from the printer's maintenance menu. If the issue persists, perform a print head alignment.

SPECIFICATIONS

Feature	Specification
Brand	Epson
Model Name	WF-7710
Connectivity Technology	Ethernet, NFC, Wi-Fi
Printing Technology	Inkjet
Special Feature	Auto-Duplex

Printer Output	Color
Maximum Print Speed (Color)	10 ppm
Max Printspeed Monochrome	18 ppm
Item Weight	40.8 Pounds
Item Dimensions (D x W x H)	22.3"D x 32.2"W x 13.4"H
Scanner Type	Flatbed
Display Type	LCD (4.3" color touchscreen)
Maximum Copies Per Run	999
Ink Color	Cyan, Magenta, Yellow, Black
Resolution	4800 x 1200 dpi
Number of Trays	2
Maximum Media Size	13 x 19 inch
Maximum Sheet Capacity	250
Power Consumption	19 Watts
Dual-sided printing	Yes (Automatic)

WARRANTY & SUPPORT

Warranty Information

The Epson WorkForce WF-7710 comes with a 1-Year limited warranty. For specific terms and conditions, please refer to the warranty documentation included with your product or visit the official Epson support website.

Customer Support

For further assistance, technical support, or to access updated drivers and manuals, please visit the Epson support website or contact their customer service. Online resources often include FAQs, troubleshooting guides, and software downloads.