Ariete 1301

Ariete 1301 Espresso Machine User Manual

Model: 1301

1. Introduction

Welcome to the user manual for your new Ariete 1301 Espresso Machine. This compact and efficient appliance is designed to bring authentic espresso into your home, offering versatility with both ESE biodegradable pods and ground coffee. Please read these instructions carefully before first use to ensure safe operation and optimal performance.

2. Product Overview and Components

Familiarize yourself with the main parts of your Ariete 1301 Espresso Machine.



Figure 2.1: Overall view of the Ariete 1301 Espresso Machine. This image displays the compact design and main external features of the appliance.



Figure 2.2: Removable water tank. The transparent water tank is located at the back-right of the machine and can be easily detached for refilling.



Figure 2.3: Control Panel. Features a power button and two coffee selection buttons for different cup sizes, along with indicator lights.



Figure 2.4: ESE Pod and Filter Basket. This shows a single ESE coffee pod alongside the removable filter basket designed for both pods and ground coffee.

Key Components:

- **Water Tank:** Removable for easy filling.
- **Control Panel:** Power button, short espresso button, long espresso button.
- **Coffee Dispenser:** Where coffee is brewed.
- **Drip Tray:** Removable and adjustable for various cup sizes.
- **Filter Basket:** Accommodates ESE pods or ground coffee.
- **Portafilter:** Holds the filter basket.

3. Setup

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present.
2. **Initial Cleaning:** Before first use, wash the water tank, drip tray, and filter basket with warm, soapy water. Rinse thoroughly and dry.
3. **Filling the Water Tank:** Remove the water tank (Figure 2.2) and fill it with fresh, cold water up to the MAX level indicator. Reinsert the tank securely.
4. **Priming the Machine:**
    - Place a cup under the coffee dispenser.
    - Press the power button (Figure 2.3). The indicator light will flash while the machine heats up.
    - Once the light is steady, press either coffee button to dispense water without coffee. Repeat this process 2-3 times to flush the system and prime the pump.

4. Operating Instructions

4.1. Making Espresso with ESE Pods

1. Ensure the machine is powered on and heated (indicator light steady).
2. Open the portafilter and insert one ESE biodegradable pod into the filter basket (Figure 2.4). Ensure it is seated correctly.
3. Close the portafilter securely.
4. Place your desired cup on the drip tray. The drip tray is adjustable to accommodate different cup heights.
5. Press the short espresso button for a classic espresso or the long espresso button for a longer coffee (Figure 2.3). The machine will automatically stop dispensing when the selected volume is reached.
6. After brewing, carefully remove the used ESE pod.

4.2. Making Espresso with Ground Coffee

1. Ensure the machine is powered on and heated.
2. Open the portafilter and fill the filter basket with the appropriate amount of fresh ground coffee. Do not overfill.
3. Close the portafilter securely.
4. Place your desired cup on the drip tray.
5. Press the short espresso button for a classic espresso or the long espresso button for a longer coffee.
6. After brewing, open the portafilter and discard the used coffee grounds.



Figure 4.1: Machine in operation. This image shows the Ariete 1301 brewing coffee into a cup, demonstrating its use in a home setting.

5. Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your espresso machine.

- **Daily Cleaning:**
  - Empty and rinse the drip tray after each use.
  - Remove and clean the filter basket and portafilter with warm water.
  - Wipe the exterior of the machine with a damp cloth.
- **Water Tank:** Clean the water tank periodically with warm, soapy water and rinse thoroughly.
- **Descaling:** Over time, mineral deposits can build up. The machine may indicate when descaling is needed. Follow the instructions provided with a suitable descaling solution for espresso machines.
- **Automatic Shut-off:** The machine features an automatic shut-off function, turning off after 30 minutes of inactivity to save energy.

6. Troubleshooting

Problem	Possible Cause	Solution
No coffee dispensed.	Water tank empty, machine not heated, pump not primed.	Fill water tank, wait for indicator light to be steady, prime the pump as per Section 3.
Coffee is too weak.	Insufficient coffee grounds/pod, coffee too coarsely ground, machine needs descaling.	Use more coffee/correct pod, use finer ground coffee, descale the machine.

Problem	Possible Cause	Solution
Water leaking from machine.	Water tank not properly seated, seals worn.	Ensure water tank is securely in place. If problem persists, contact customer support.
Machine not turning on.	Not plugged in, power outlet issue.	Check power connection and outlet.

7. Specifications

Feature	Detail
Brand	Ariete
Model Number	1301 (00M130100AR0)
Color	White
Product Dimensions (L x W x H)	37 x 18.5 x 35 cm
Item Weight	2.85 Kilograms
Power	1100 Watts
Voltage	220.00 V
Material	Stainless Steel
Automatic Shut-off Function	Yes (after 30 minutes)
Special Features	Programmable coffee volume
Coffee Maker Type	Espresso Machine
Compatibility	Ground coffee, E.S.E pods
Pump Pressure	15 Bar

8. Safety Information

Please observe the following safety precautions:

- Always ensure the machine is unplugged before cleaning or maintenance.
- Do not immerse the machine in water or other liquids.
- Keep the appliance out of reach of children.
- Do not operate the machine with a damaged cord or plug.
- Avoid touching hot surfaces during and immediately after operation.
- Use only fresh, cold water in the water tank.

9. Warranty and Support

Your Ariete 1301 Espresso Machine comes with a manufacturer's warranty. Please refer to the warranty card included in

your product packaging for specific terms and conditions. For technical support, spare parts, or further assistance, please contact Ariete customer service through their official website or the retailer where the product was purchased.

© 2023 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question