

Aiwa AW2 Pro

Aiwa AW2 Pro Wireless Headphones User Manual

Model: AW2 Pro

INTRODUCTION

Thank you for choosing the Aiwa AW2 Pro Wireless Headphones. These headphones are designed to provide a high-quality audio experience with the convenience of Bluetooth connectivity, an integrated microphone for calls, and active noise cancellation. Please read this manual carefully before using your headphones to ensure proper operation and to maximize their lifespan.

PACKAGE CONTENTS

- Aiwa AW2 Pro Wireless Headphones
- USB-C Charging Cable
- 3.5mm Audio Cable
- User Manual

PRODUCT OVERVIEW

The Aiwa AW2 Pro headphones offer a comfortable, lightweight design with powerful audio performance. Key features include Bluetooth wireless technology, an integrated microphone for hands-free communication, and active noise cancellation for an immersive listening experience.

Turn on the beat



Audífonos Bluetooth
AW2 Pro

Figure 1: Aiwa AW2 Pro Wireless Headphones (Blue variant).



Figure 2: Aiwa AW2 Pro Wireless Headphones (Black variant).

Familiarize yourself with the headphone controls, typically located on the earcups, which include power, volume, track control, and a button for managing calls and activating noise cancellation.

SETUP

1. Charging the Headphones

1. Connect the USB-C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show the charging status. It typically turns red while charging and blue or off when fully charged.
4. Allow approximately 2-3 hours for a full charge.

2. Powering On/Off

- To power on: Press and hold the Power button for 3-5 seconds until the LED indicator flashes.
- To power off: Press and hold the Power button for 3-5 seconds until the LED indicator turns off.

3. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power button for approximately 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Aiwa AW2 Pro" from the list of found devices.
5. Once paired, the LED indicator will flash blue slowly or remain solid blue.

4. Wired Connection (Optional)

You can use the included 3.5mm audio cable to connect the headphones to devices without Bluetooth or when the battery is depleted. Simply plug one end into the headphone's 3.5mm jack and the other into your audio source's 3.5mm output.

OPERATING INSTRUCTIONS

Music Playback

- **Play/Pause:** Press the Multi-function button (often the Power button) once.
- **Volume Up:** Press the Volume + button.
- **Volume Down:** Press the Volume - button.
- **Next Track:** Press and hold the Volume + button.
- **Previous Track:** Press and hold the Volume - button.

Call Management

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

Active Noise Cancellation (ANC)

To activate or deactivate the Active Noise Cancellation feature, locate the dedicated ANC button (if available) or refer to the specific instructions for your model. Pressing this button will toggle the ANC function on or off,

indicated by an LED light or voice prompt.

Voice Assistant

To activate your device's voice assistant (Siri, Google Assistant, etc.), press the Multi-function button twice quickly. Ensure your device is connected and its voice assistant feature is enabled.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. If provided, use the carrying case to protect them.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in use for extended periods.
- **Water Exposure:** These headphones are not waterproof. Avoid exposure to water or excessive moisture.

TROUBLESHOOTING

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source and try again.
Cannot pair with device.	<ul style="list-style-type: none">• Ensure headphones are in pairing mode (LED flashing red and blue).• Turn off and on Bluetooth on your device.• Forget "Aiwa AW2 Pro" from your device's Bluetooth list and try pairing again.• Move headphones closer to your device.
No sound or low volume.	<ul style="list-style-type: none">• Increase volume on both headphones and your connected device.• Ensure headphones are properly paired.• If using wired connection, ensure the 3.5mm cable is fully inserted.
Poor audio quality.	<ul style="list-style-type: none">• Move closer to your device to avoid interference.• Ensure there are no obstacles between the headphones and your device.• Try playing audio from a different source or file.

SPECIFICATIONS

Feature	Detail
Brand	Aiwa
Model Number	AW2 Pro
Connectivity Technology	Bluetooth
Headphone Connector	3.5 mm Jack

Feature	Detail
Wireless Communication Technology	Bluetooth
Specific Product Uses	Travel, Commute
Compatible Devices	Cell phones, Tablets, Desktops, Car audio systems
Cable Features	Wireless
Control Method	Voice
Special Features	Noise Cancellation, Lightweight
Microphone Form Factor	Integrated
Batteries Included	Yes
Battery Operated	Yes
Connections	Bluetooth
Charging Port	USB Type C
Product Weight	450 g
Package Dimensions	21.6 x 18.6 x 7.2 cm
Battery Type	1 Lithium Polymer battery (included)
Ear Placement	Over-Ear
Headphone Form Factor	Over-Ear
Impedance	32 Ohms
Noise Control	Active Noise Cancellation

WARRANTY INFORMATION

Aiwa products are covered by a limited warranty from the date of purchase. This warranty covers manufacturing defects in materials and workmanship. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, refer to the warranty card included with your product or visit the official Aiwa website.

SUPPORT

If you encounter any issues or have questions regarding your Aiwa AW2 Pro Wireless Headphones that are not addressed in this manual, please contact Aiwa customer support. You can typically find contact information on the official Aiwa website or on the product packaging. Please have your model number (AW2 Pro) and proof of purchase ready when contacting support.

For more information, visit the [Aiwa Store on Amazon](#).

