Fila B077PYYKFT

Fila Womens Sheena Sweatshirt User Manual

Model: B077PYYKFT

Product Overview

The Fila Womens Sheena Sweatshirt is designed for comfort and style, suitable for various casual activities. It features a blend of cotton and polyester for durability and softness.



Figure 1: Front view of the Fila Womens Sheena Sweatshirt, showcasing its design and fabric texture.

Specifications

Feature	Detail
Department	Womens
Fabric Type	75% Cotton, 25% Polyester
Origin	Imported
Neckline	Ribbed crew neckline
Sleeves	Long sleeves with ribbed cuffs
Pockets	Hand pockets at sides
Hem	Crop hem with ribbing
Logo	Reflective logo at chest

Setup

The Fila Womens Sheena Sweatshirt requires no complex setup. It is ready to wear upon receipt.

Unpacking

Carefully remove the sweatshirt from its packaging. Inspect the garment for any signs of damage or manufacturing defects before first use.

Initial Preparation

It is recommended to wash the sweatshirt before its first wear to remove any manufacturing residues and to ensure optimal comfort. Refer to the "Maintenance" section for detailed washing instructions.

Operating (Wearing Instructions)

The Sheena Sweatshirt is designed for casual wear and athletic activities. Follow these guidelines for optimal comfort and fit:

- **Sizing:** Ensure you have selected the correct size based on the provided size guide. A proper fit enhances comfort and appearance.
- **Layering:** This sweatshirt can be worn as a standalone top or layered over a t-shirt or tank top for added warmth.
- **Activity:** Suitable for light to moderate physical activity, lounging, or everyday casual wear.

Size Guide

For accurate sizing, please refer to the table below. Measurements are approximate and may vary slightly.

US REGULAR

Brand Size	USA	Bust (in)	Waist (in)
XS	2	32.5	24
S	4 - 6	33.5 - 34.5	25 - 26
M	8 - 10	35.5 - 36.5	28 - 30
L	12 - 14	38 - 39.5	29.5 - 31
XL	16 - 18	41 - 43	32.5 - 34.5
2XL	20 - 22	44 - 45.5	36.5 - 38

Maintenance

Proper care and maintenance will extend the life and preserve the appearance of your Fila Womens Sheena Sweatshirt.

Washing Instructions

- **Machine Wash Cold:** Use a gentle cycle with cold water to prevent shrinking and fading.
- **Tumble Dry Low:** Dry on a low heat setting. Remove promptly to avoid wrinkles. Air drying is also an option to further preserve fabric integrity.
- **Do Not Bleach:** Avoid using bleach or harsh detergents, as these can damage the fabric and color.
- **Ironing:** If necessary, iron on a low heat setting, inside out, to protect the reflective logo.

- **Storage:** Store in a cool, dry place away from direct sunlight to prevent discoloration.

Troubleshooting

This section addresses common concerns and provides solutions for maintaining the quality of your sweatshirt.

Common Issues and Solutions

Issue	Possible Cause	Solution
Shrinkage after washing	Washing in hot water or high heat drying.	Always machine wash cold and tumble dry low. Air drying is preferred.
Fading of color	Exposure to harsh detergents, bleach, or excessive sunlight.	Use mild detergents, avoid bleach, and store away from direct sunlight.
Damage to reflective logo	Direct high heat ironing or abrasive washing.	Iron inside out on low heat. Avoid scrubbing the logo area.

Warranty and Support

Fila products are manufactured to high-quality standards. For specific warranty information or support inquiries, please refer to the official Fila website or contact their customer service.

- **Official Website:** www.fila.com (Please note: This is a placeholder link as no specific support link was provided in the product data.)
- **Customer Service:** Refer to the contact section on the official Fila website for phone numbers or email support.

© 2024 Fila. All rights reserved.
This manual is for informational purposes only. Fila reserves the right to make changes to products without prior notice.