

[Manuals.plus](#) /

› [Fisher-Price](#) /

› Fisher-Price Thomas & Friends Trackmaster Sky-High Bridge Jump DFM54 Replacement Label Sheet Instruction Manual

Fisher-Price DFM54

Fisher-Price Thomas & Friends Trackmaster Sky-High Bridge Jump DFM54 Replacement Label Sheet Instruction Manual

Model: DFM54

INTRODUCTION

This manual provides instructions for the application of the replacement label sheet for the Fisher-Price Thomas & Friends Trackmaster Sky-High Bridge Jump playset, model DFM54. This product is intended to replace worn or lost labels for your existing playset components.

SAFETY INFORMATION

Please observe the following safety guidelines:

- This product is intended for children aged 3 years and up.
- Adult supervision is recommended during label application.
- Keep labels away from infants and young children to prevent choking hazards.
- Ensure all labels are securely applied to prevent peeling and potential ingestion.
- Do not attempt to modify the labels or playset components.

PACKAGE CONTENTS

Your package contains the following item:

- 1 x Fisher-Price Thomas & Friends Trackmaster Sky-High Bridge Jump DFM54 Replacement Label Sheet




Image: The complete replacement label sheet for the DFM54 playset, showing various stickers for different parts of the bridge and track.


LABEL APPLICATION INSTRUCTIONS

Follow these steps to correctly apply the replacement labels to your Thomas & Friends Trackmaster Sky-High Bridge Jump playset components:

1. **Prepare the Surface:** Ensure the surface of the playset components where labels will be applied is clean, dry, and free of dust or debris.
2. **Identify Labels:** Carefully examine the replacement label sheet and identify which label corresponds to which part of your playset. Refer to the diagrams below for guidance.
3. **Peel and Apply:** Gently peel a label from the sheet. Align it precisely with the designated area on the playset component. Press down firmly from the center outwards to remove any air bubbles and ensure a secure adhesion.
4. **Repeat:** Continue this process for all remaining labels.

LABEL PLACEMENT





Replacement Label Sheet Only

Image: Diagram illustrating the correct placement of various labels on the track and bridge components of the Sky-High Bridge Jump playset. Dotted lines indicate where each label should be applied.




Image: A close-up view showing a label being applied to a building-like component of the playset, with an arrow indicating the attachment point.




Image: An assembly diagram (Step 4) of the playset, highlighting components that would receive labels, such as the bridge structure and track pieces, before final assembly.

CARE AND STORAGE

To ensure the longevity of your labels and playset:

- Avoid exposing the playset to extreme temperatures or direct sunlight for prolonged periods, as this can cause labels to fade or peel.
- Clean labeled surfaces with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the playset in a dry, cool environment when not in use.

SPECIFICATIONS

Brand	Fisher-Price
-------	--------------

Model Number	DFM54
Product Type	Replacement Label Sheet
Recommended Age	3 years and up
Item Weight	2.39 ounces
Package Dimensions	12.9 x 1.7 x 1.4 inches

WARRANTY AND SUPPORT

This replacement label sheet is a genuine Fisher-Price product. For any questions regarding this product, warranty information, or support, please contact Fisher-Price customer service directly or visit their official website. You can find more information about Fisher-Price products at the [Fisher-Price Store on Amazon](#).

