

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Michael Kors](#) /
- › [Michael Kors Lexington Men's Watch MK8602 Instruction Manual](#)

Michael Kors MK8602

Michael Kors Lexington Men's Watch MK8602 Instruction Manual

Model: MK8602

INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Michael Kors Lexington Men's Watch, model MK8602. Please read this guide thoroughly to ensure proper use and care of your timepiece.




Image: Michael Kors Lexington Men's Watch, Silver/Black Dial. This image displays the watch face and bracelet.

SETUP

1. Unboxing

Your Michael Kors Lexington watch comes securely packaged in a branded box. Carefully remove the watch and any protective films.



Image: The white Michael Kors branded watch box, indicating original packaging.

2. Setting the Time

1. Pull the crown (center knob on the right side of the watch case) out to position 2.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Push the crown back into position 0 to start the watch.

3. Setting the Date

1. Pull the crown out to position 1.
2. Turn the crown clockwise or counter-clockwise to adjust the date.
3. Once the correct date is displayed, push the crown back into position 0.

4. Bracelet Adjustment

The stainless steel bracelet may require adjustment to fit your wrist comfortably. It is recommended to have this adjustment performed by a professional jeweler to avoid damage to the links or clasp.

38 MM



40 MM



43 MM



45 MM





Image: A visual guide illustrating various watch case sizes (38mm, 40mm, 43mm, 45mm) on a wrist for reference.

OPERATING INSTRUCTIONS

1. Basic Timekeeping

Your watch operates on a precise quartz movement, providing accurate time display with hour, minute, and second hands.

2. Chronograph Function

The chronograph feature allows for elapsed time measurement. It typically includes three sub-dials for seconds, minutes, and hours, controlled by pushers located above and below the crown.





Image: Side profile of the Michael Kors Lexington watch, highlighting the crown and the two chronograph pushers.

- **Start/Stop:** Press the top pusher to start and stop the chronograph.
- **Reset:** With the chronograph stopped, press the bottom pusher to reset all chronograph hands to zero.

3. Date Display

The date is displayed in a window on the watch dial. Adjust as needed at the end of months with fewer than 31 days.

4. Water Resistance

This watch is water resistant up to 330 feet (10 ATM), suitable for swimming and snorkeling. It is not recommended for diving or prolonged submersion. Ensure the crown is fully pushed in before any contact with water.

MAINTENANCE

1. Cleaning

Wipe the watch case and bracelet with a soft, damp cloth. For stainless steel, a mild soap solution can be used, followed by thorough rinsing and drying. Avoid harsh chemicals or abrasive materials.

2. Battery Replacement

The watch is powered by one Lithium Metal battery. When the watch stops or the second hand skips, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to maintain water resistance and prevent damage.

3. Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box provides excellent protection.

4. Crystal Care

The watch features a durable mineral crystal. While resistant to scratches, avoid impacts that could cause damage. Clean with a soft cloth.

TROUBLESHOOTING

- **Watch Not Running:**
Check if the crown is fully pushed into position 0. If it is, the battery may need replacement.
- **Incorrect Time/Date:**
Refer to the "Setting the Time" and "Setting the Date" sections to re-adjust. Ensure the crown is fully pushed in after setting.
- **Chronograph Not Functioning:**
Ensure the watch is running. If the chronograph hands are misaligned, consult a professional for adjustment.
- **Water Inside Watch:**
If moisture appears inside the watch, immediately take it to a professional watch repair service. This indicates a breach in water resistance.

SPECIFICATIONS

| | |
|-------------------------------|-------------------|
| Model Number | MK8602 |
| Brand | Michael Kors |
| Movement Type | Quartz |
| Display Type | Analog |
| Case Material | Stainless Steel |
| Band Material | Stainless Steel |
| Case Diameter | 44 Millimeters |
| Case Thickness | 13 Millimeters |
| Band Width | 22 Millimeters |
| Water Resistance Depth | 330 Feet (10 ATM) |
| Crystal Type | Mineral |

| | |
|---------------------|--|
| Power Source | Battery Powered (1 Lithium Metal battery included) |
| Item Weight | 40 Grams |
| Closure Type | Push Button Foldover Clasp With Safety |
| Functions | Chronograph, Date |

WARRANTY INFORMATION

This Michael Kors watch comes with a manufacturer's warranty. For specific details regarding coverage, duration, and terms, please refer to the warranty card included with your purchase or visit the official Michael Kors website. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, service, or inquiries regarding your Michael Kors Lexington watch, please contact Michael Kors customer service directly. You can find contact information on their official website or through the documentation provided with your watch.

Official Michael Kors Website: www.michaelkors.com