

[manuals.plus](#) /

› [Lavazza](#) /

› [Lavazza A Modo Mio Milkeasy Electric Milk Frother Instruction Manual](#)

**Lavazza 18200090**

# Lavazza A Modo Mio Milkeasy Electric Milk Frother Instruction Manual

Model: 18200090

## 1. INTRODUCTION

This instruction manual provides essential information for the safe and efficient operation of your Lavazza A Modo Mio Milkeasy Electric Milk Frother. Please read this manual thoroughly before first use and keep it for future reference. This device is designed to prepare hot or cold milk foam for various coffee and beverage creations.

## 2. SAFETY INFORMATION

- Read all instructions before using the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- Do not use outdoors.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use the appliance for anything other than its intended use.

## 3. PACKAGE CONTENTS

Upon unpacking, please ensure all items are present and in good condition:

- Lavazza A Modo Mio Milkeasy Electric Milk Frother Unit
- Lid
- Frothing Whisk (pre-installed or separate)
- Power Base

## 4. PRODUCT OVERVIEW



Figure 1: Lavazza A Modo Mio Milkeasy Electric Milk Frother

This image displays the sleek, black Lavazza A Modo Mio Milkeasy Electric Milk Frother. It features a cylindrical body with a metallic rim at the top and a prominent Lavazza A Modo Mio logo on the front. Below the logo is a circular control button with an illuminated ring. The side of the frother has horizontal ridges for grip.

1. **Frother Unit:** The main body where milk is frothed.
2. **Lid:** Transparent lid to cover the frother unit during operation.
3. **Frothing Whisk:** Detachable whisk for creating foam.
4. **Control Button:** Single button for starting/stopping and selecting frothing modes.
5. **Max Fill Line:** Internal marking indicating the maximum milk level.

6. **Power Base:** Detachable base with power cord connection.

## 5. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wash the frother unit interior, lid, and whisk with warm soapy water. Rinse thoroughly and dry. Do not immerse the exterior of the frother unit or the power base in water.
3. **Assemble:** Place the frothing whisk securely onto the shaft inside the frother unit.
4. **Position:** Place the frother unit onto the power base. Ensure it is seated correctly.
5. **Connect Power:** Plug the power base into a suitable electrical outlet.

## 6. OPERATING INSTRUCTIONS

### 6.1 Preparing Hot Milk Foam

1. Ensure the frothing whisk is correctly installed.
2. Pour cold milk into the frother unit, ensuring it does not exceed the "MAX" fill line for frothing.
3. Place the lid securely on the frother unit.
4. Press the control button once. The indicator light will illuminate, and the frother will begin heating and frothing the milk.
5. The frother will automatically stop when the milk reaches the optimal temperature and consistency.
6. Carefully remove the lid and pour the frothed milk into your cup.

### 6.2 Preparing Cold Milk Foam

1. Ensure the frothing whisk is correctly installed.
2. Pour cold milk into the frother unit, ensuring it does not exceed the "MAX" fill line for frothing.
3. Place the lid securely on the frother unit.
4. Press and hold the control button for approximately 2-3 seconds. The indicator light will illuminate, and the frother will begin frothing the milk without heating.
5. The frother will automatically stop after a few minutes.
6. Carefully remove the lid and pour the frothed milk into your cup.

### 6.3 Preparing Hot Milk (without foam)

To heat milk without frothing, remove the frothing whisk from the unit before adding milk. Pour milk up to the "MAX" fill line for heating (if different from frothing max line, otherwise use frothing max line). Press the control button once. The frother will heat the milk and stop automatically.

## 7. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your milk frother.

1. **Unplug:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Disassemble:** Remove the frother unit from the power base. Remove the lid and the frothing whisk.
3. **Hand Wash Only:** Wash the interior of the frother unit, the lid, and the frothing whisk with warm water and a mild detergent. Use a soft sponge or cloth to avoid scratching the non-stick coating.
4. **Rinse and Dry:** Rinse all washed parts thoroughly under running water. Dry immediately with a soft

cloth.

5. **Exterior Cleaning:** Wipe the exterior of the frother unit and the power base with a damp cloth. Do not use abrasive cleaners or scourers.
6. **Storage:** Store the clean and dry frother in a safe, dry place.

**Important: Do not immerse the frother unit's exterior or the power base in water or any other liquid.**

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Frother does not turn on.	Not plugged in; power outage; frother not correctly seated on base.	Check power connection; ensure frother is properly placed on the power base.
Milk is not frothing or foam is poor.	Insufficient milk; milk type not suitable for frothing; whisk not installed correctly; whisk is dirty.	Ensure milk is above minimum level and below MAX frothing line; use cold, fresh milk (dairy or plant-based suitable for frothing); check whisk installation; clean whisk and frother interior.
Milk is not heating.	Cold foam mode selected; heating element malfunction.	Ensure hot foam mode is selected (single press); if problem persists, contact customer support.
Burning smell or milk sticking to bottom.	Frother not cleaned properly; milk residue.	Thoroughly clean the frother unit after each use, especially the bottom heating plate.

## 9. SPECIFICATIONS

**Brand:** Lavazza

**Model Number:** 18200090

**Color:** Black

**Dimensions (L x W x H):** 9.55 x 9.55 x 17.33 cm (approximately 3.76 x 3.76 x 6.82 inches)

**Capacity:** 120 Milliliters

**Power:** 460 Watts

**Voltage:** 240 Volts

**Material:** Steel Alloy

**Special Feature:** Ergonomic Design

**Item Weight:** 1 Kilogram

**Recommended Use:** Cappuccino

**Care Instructions:** Hand Wash Only

## 10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Lavazza website. Keep your proof of purchase for any warranty claims. If you encounter issues not covered in the troubleshooting section, please contact Lavazza customer

service for assistance.

## Related Documents - 18200090

	<p><a href="#">Lavazza Milk Frother A Modo Mio User Guide: Frothing Instructions</a></p> <p>Comprehensive user guide for the Lavazza Milk Frother (A Modo Mio). Learn how to select whisks, fill milk to the correct levels, operate the frother for hot and cold frothing, and serve perfect coffee drinks.</p>
	<p><a href="#">Lavazza Jolie &amp; Milk Coffee Machine: Operating Instructions and Guide</a></p> <p>Comprehensive operating instructions and user guide for the Lavazza A Modo Mio Jolie &amp; Milk coffee machine, covering setup, usage, maintenance, and troubleshooting for brewing delicious espresso and milk-based drinks.</p>
	<p><a href="#">Lavazza "A Modo Mio" DESEA Quick Start Guide</a></p> <p>A quick start guide for the Lavazza "A Modo Mio" DESEA coffee machine, covering first use, daily operation, cappuccino preparation, milk recipes, and coffee dose programming.</p>
	<p><a href="#">Lavazza Jolie &amp; Milk Coffee Machine Operating Instructions</a></p> <p>This document provides comprehensive operating instructions for the Lavazza Jolie &amp; Milk coffee machine, covering setup, usage, cleaning, and maintenance. It is designed for users to safely and effectively operate the appliance for brewing coffee and frothing milk.</p>
	<p><a href="#">Lavazza A Modo Mio Smeg Coffee Machine Quick Start Guide</a></p> <p>A quick start guide for the Lavazza A Modo Mio coffee machine by Smeg, covering initial setup, daily use, and coffee dose programming.</p>
	<p><a href="#">Macchina per Espresso Lavazza New Tiny Eco: Istruzioni per l'Uso</a></p> <p>Guida completa alle istruzioni operative e di manutenzione per la macchina per espresso Lavazza New Tiny Eco A Modo Mio. Impara come configurare, usare, pulire e decalcificare la tua macchina per caffè per prestazioni ottimali.</p>

## Documents - Lavazza – 18200090



### [Product Catalog: Home Appliances and Outdoor Gear](#)

Explore a diverse catalog featuring a wide range of home appliances, including kitchen essentials like coffee machines, vacuum cleaners, and ovens, alongside outdoor equipment such as tents, scooters, and camping gear. Discover top brands and products for everyday living and recreational activities.

lang:en score:18 filesize: 677.71 K page\_count: 20 document date: 2019-06-25