

[Manuals.plus](#) /

› [ZEBRONICS](#) /

› Zebronic ZEB-KM2100 Multimedia USB Keyboard User Manual

ZEBRONICS KM2100

Zebronic ZEB-KM2100 Multimedia USB Keyboard User Manual

Model: KM2100

1. INTRODUCTION

This manual provides comprehensive instructions for the Zebronic ZEB-KM2100 Multimedia USB Keyboard. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.



Figure 1: Zebronic ZEB-KM2100 Multimedia USB Keyboard

Key Features:

- **114 Keys:** Full-sized keyboard layout for comprehensive input.
- **12 Dedicated Multimedia Keys:** Quick access to media controls and common functions.
- **Rupee Key:** Includes a dedicated key for the Indian Rupee symbol.
- **Superior Build Quality:** Constructed with durable materials for long-lasting performance.
- **Modular Design:** Allows for potential customization and enhances usability.
- **USB Interface:** Ensures broad compatibility with various devices.
- **UV Printed Keycaps:** Keycap inscriptions are designed for durability and resistance to wear.
- **Plug & Play:** Simple connection without the need for additional driver installation.

2. SETUP

Connecting the Keyboard:

1. Locate an available USB port on your computer (desktop or laptop).
2. Insert the USB connector of the Zebronics ZEB-KM2100 keyboard into the USB port.
3. The keyboard is plug-and-play, meaning it should be recognized automatically by your operating system (Windows XP, Vista, 7, 8, 10, 11) without requiring manual driver installation.
4. Once recognized, the keyboard is ready for immediate use.



Figure 2: Plug & Play USB Connectivity

1.2m Cable USB Interface



Figure 3: USB Interface with 1.2m Cable Length

Unboxing and Initial Inspection:

Video 1: Unboxing the Zebronics ZEB-KM2100 Multimedia USB Keyboard. This video demonstrates the unboxing process and initial look at the keyboard.

3. OPERATING INSTRUCTIONS

Standard Key Functions:

The Zebronics ZEB-KM2100 features a standard 114-key layout, including a full numeric keypad, function keys (F1-F12), and navigation keys. All keys operate as standard keyboard keys for typing and general computer use.

Retractable Stand



114 Key




Figure 4: The 114-key layout of the keyboard, also showing the retractable stand.

Dedicated Multimedia Keys:

The keyboard is equipped with 12 dedicated multimedia keys located above the function keys (F1-F12). These keys provide quick access to various media and system functions, enhancing user convenience.

12 Dedicated Hotkeys



Figure 5: Close-up view of the 12 dedicated multimedia hotkeys.

Rupee Key:

A unique feature of this keyboard is the dedicated Rupee key, located near the '4' key. This allows for easy input of the Indian Rupee symbol (₹).

With Rupee Key



Figure 6: Dedicated Rupee Key for easy symbol input.

Retractable Stand:

The keyboard features a retractable stand on its underside. Extend these stands to elevate the keyboard to a more ergonomic typing angle, reducing strain during prolonged use.

Retractable Stand



114 Key




Figure 7: Retractable stand for adjustable typing angle.

Product Overview:

Video 2: Zebronics ZEB-KM2100 Multimedia USB Keyboard Overview. This video provides a detailed look at the keyboard's features and design.

Video 3: Product Overview Video. A concise overview highlighting the main aspects of the keyboard.

4. MAINTENANCE

Cleaning:

- To clean the keyboard, disconnect it from your computer.
- Use a soft, dry cloth to wipe down the surface of the keyboard.
- For dust and debris between keys, use compressed air.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the keycaps and finish.

UV Printed Keycaps:

The keycaps are UV printed, which provides a protective layer against fading and wear. Regular cleaning as described above will help maintain the legibility of the keycap inscriptions over time.

UV Coated keys



Figure 8: UV Coated keys for enhanced durability.

5. TROUBLESHOOTING

Common Issues and Solutions:

- **Keyboard not responding:**
 - Ensure the USB connector is securely plugged into a working USB port.
 - Try plugging the keyboard into a different USB port on your computer.
 - Restart your computer.
 - Check your computer's Device Manager (Windows) to see if the keyboard is listed and if there are any driver issues.

- **Keys not functioning correctly:**

- Clean the affected keys as described in the Maintenance section.
- Ensure no foreign objects are lodged under the keys.
- Test the keyboard on another computer to determine if the issue is with the keyboard or the computer.

- **Multimedia keys not working:**

- Ensure your operating system and media player software are up to date.
- Some multimedia keys may require specific software or settings on your computer to function. Refer to your operating system's documentation for multimedia key configuration.

If you encounter persistent issues not resolved by these steps, please refer to the Warranty and Support section for further assistance.

6. SPECIFICATIONS

Feature	Specification
Model Name	KM2100
Brand	ZEBRONICS
Colour	BLACK
Number of Keys	114
Dedicated Multimedia Keys	12
Interface	USB
Cable Length	1.2 meters
Keystroke Life	8 million times
Dimensions (L x W x H)	42.3 x 14.6 x 2.7 cm
Item Weight	458 g
Compatible Operating Systems	Windows XP, Windows Vista, Windows 7, Windows 8, Windows 10, Windows 11
Included Components	Keyboard

7. WARRANTY AND SUPPORT

Warranty Information:

This product comes with a standard brand warranty. For specific details regarding the warranty period and terms, please refer to the warranty card included with your product or visit the official Zebronics website.

Customer Support:

For any technical assistance, product inquiries, or warranty claims, please contact Zebronics customer support through their official website or the contact information provided in your product packaging.

You can also find more information on EMI options and replacement policies on the product detail page where you purchased the item.

© 2025 Zebronics. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question