

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LG](#) /

› [LG V30 US998 Smartphone User Manual](#)

LG US998

LG V30 US998 Smartphone User Manual

Model: US998



INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your LG V30 US998 smartphone. The LG V30 US998 is a high-performance device featuring a 6.0" OLED FullVision Display, advanced camera capabilities, and an enhanced audio experience. It is designed for compatibility with various GSM and CDMA networks, including AT&T, T-Mobile, Verizon, and Sprint. The device also boasts IP68 dust and water resistance and has passed MIL-STD-810G durability tests, ensuring robust performance in diverse conditions.

PACKAGE CONTENTS

Verify that all items are present in the product packaging:

- LG V30 US998 Device
- USB Cable
- Quick Start Guide (QSG)
- Product Safety and Warranty Information (PSWI)
- SIM-card drawer opener

DEVICE OVERVIEW

Familiarize yourself with the physical components of your LG V30 US998 smartphone.



Image: Front view of the LG V30 US998 smartphone, showcasing its 6.0-inch OLED FullVision Display with minimal bezels. The screen displays a digital clock and date.






Image: Front view of the LG V30 US998 smartphone displaying its home screen with various application icons and a weather widget. The

top status bar shows network, battery, and time information.

The device features a 6.0-inch OLED FullVision Display on the front. The rear of the phone houses the dual camera system, consisting of a 16 MP standard-angle lens and a 13 MP wide-angle lens, along with a fingerprint sensor. The front camera is a 5 MP wide-angle lens. Physical buttons for power and volume are located on the sides.

SETUP

1. Inserting the SIM/SD Card

1. Locate the SIM/SD card tray on the side of the device.
2. Insert the provided SIM-card drawer opener into the small hole next to the tray to eject it.
3. Place your Nano-SIM card and/or microSD card (if applicable) into the tray with the gold contacts facing down.
4. Carefully reinsert the tray into the device until it clicks into place.

2. Powering On Your Device

- Press and hold the Power/Lock button (typically on the right side) until the LG logo appears on the screen.
- Follow the on-screen prompts to complete the initial setup, including selecting your language, connecting to a Wi-Fi network, and setting up your Google account.

3. Charging the Battery

- Connect the USB cable to the charging port on your device and the other end to a power adapter.
- Plug the power adapter into a wall outlet. The device supports fast charging and wireless charging.

OPERATING INSTRUCTIONS

1. Basic Navigation

- **Touchscreen Gestures:** Tap to select, swipe to scroll, pinch to zoom.
- **Home Screen:** Access apps, widgets, and notifications.
- **Navigation Bar:** Use the Back, Home, and Recent Apps buttons at the bottom of the screen.

2. Camera Usage

- Open the Camera app from the home screen or lock screen.
- Switch between the 16 MP standard-angle and 13 MP wide-angle rear cameras for different perspectives.
- Utilize the 5 MP wide-angle front camera for selfies.
- Explore various modes for photos and premium video capture, including manual controls and color-grading presets.

3. Audio Experience

- The LG V30 US998 features a Hi-Fi Quad DAC for enhanced audio playback through the 3.5 mm audio jack.
- Record high-quality audio with advanced microphone capabilities.

4. Connectivity

- **Wi-Fi:** Connect to wireless networks via Settings > Network & internet > Wi-Fi.
- **Bluetooth:** Pair with other Bluetooth devices via Settings > Connected devices > Bluetooth.
- **Cellular:** The device supports GSM and CDMA networks. Ensure your SIM card is properly installed for cellular service.
- **GPS:** Location services are available for navigation and location-based applications.

MAINTENANCE

1. Cleaning Your Device

- Use a soft, lint-free cloth to gently wipe the screen and body of the phone.
- Avoid using harsh chemicals or abrasive materials.

2. Software Updates

- Regularly check for and install software updates to ensure optimal performance and security.
- Navigate to Settings > System > Update center > Software update.

3. Water and Dust Resistance (IP68)

- The LG V30 US998 is rated IP68, meaning it is dust-tight and protected against immersion in water up to 1.5 meters for 30 minutes.
- This resistance is not permanent and may decrease over time with normal wear. Avoid intentional submersion or exposure to high-pressure water.
- Ensure all ports are dry before charging.

TROUBLESHOOTING

If you encounter issues with your device, try the following common solutions:

- **Device Not Responding:** Press and hold the Power/Lock button for approximately 10 seconds to force a restart.
- **Network Issues:** Check if your SIM card is properly inserted. Try toggling Airplane Mode on and off. Verify your carrier's network coverage in your area.
- **Battery Draining Quickly:** Reduce screen brightness, close unused apps, and disable unnecessary features like Bluetooth or GPS when not in use.
- **App Malfunctions:** Clear the app's cache and data (Settings > Apps & notifications > App info > [App Name] > Storage > Clear cache/Clear data) or uninstall and reinstall the app.
- **Storage Full:** Delete unnecessary files, photos, or videos. Move media to a microSD card if installed.

SPECIFICATIONS

Feature	Detail
Model Name	LG V30 US998
Operating System	Android
Display	6.0 Inches OLED FullVision Display, 1440 x 2880 Resolution, 60 Hz Refresh Rate
Processor	Snapdragon CPU, 2.45 GHz CPU Speed
RAM	4 GB
Internal Storage	64 GB (expandable via microSD)
Rear Cameras	16 MP Standard-Angle, 13 MP Wide-Angle
Front Camera	5 MP Wide-Angle

Feature	Detail
Battery Capacity	3300 mAh
Phone Talk Time	14 Hours
Charging Time	Approximately 2 Hours
Connectivity	Wi-Fi, Cellular (GSM & CDMA), Bluetooth, GPS
Special Features	Wireless Charging, IP68 Dust and Water Resistance, 3.5 mm Audio Jack
Dimensions	5.97 x 2.97 x 0.3 inches
Item Weight	14.1 ounces (0.88 Pounds)
Color	Silver

WARRANTY AND SUPPORT

LG offers a limited warranty for your device. For extended coverage, you may be eligible for the LG Second Year Promise.

- **LG Second Year Promise:** Register your device to potentially receive a free second year of limited warranty coverage. Terms and conditions apply.
- For details and registration, visit: LGV30Promise.com
- For further assistance, refer to the Quick Start Guide (QSG) or the Product Safety and Warranty Information (PSWI) included in your package.

© 2024 LG Electronics. All rights reserved.