Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yaheetech YT-00069499

Yaheetech 41-Inch Portable Hanging Flight Bird Cage User Manual

Model: YT-00069499

Introduction

Thank you for choosing the Yaheetech 41-Inch Portable Hanging Flight Bird Cage. This manual provides essential information for the proper assembly, operation, maintenance, and care of your new bird cage. Please read these instructions carefully before assembly and retain them for future reference. This cage is designed to provide a safe and comfortable environment for small parrots, cockatiels, parakeets, conures, finches, canaries, budgies, and lovebirds.

Safety Information

- Ensure all parts are securely fastened during assembly to prevent instability.
- Regularly inspect the cage for any damaged or loose components that could harm your bird.
- Keep small children and pets away from the assembly area.
- Do not hang the cage from unstable structures or in areas prone to strong winds.
- Position the cage in a safe location, away from direct sunlight, drafts, and hazardous materials.
- This cage is intended for indoor and outdoor use, but always ensure adequate protection from extreme weather conditions.

Package Contents

Please verify that all components are present before beginning assembly:

- Cage Panels (various sizes for sides, front, back, top, bottom)
- Plastic Base
- Slide-out Tray
- Wire Grate
- Wooden Perches (multiple)
- Plastic Feeders/Water Bowls (multiple)
- Cage Clips (red)
- Bird Swing
- Assembly Instructions

Refer to the assembly video for a visual guide to all included parts.

Setup and Assembly

Follow these steps for hassle-free assembly. All necessary hardware and parts are included.

Step 1: Prepare the Base

Place the plastic base on a flat, stable surface. Insert the slide-out tray into the designated slot at the bottom of the base. Place the wire grate on top of the tray, inside the base.



Image: The easy-to-clean slide-out tray for convenient waste removal.

Step 2: Assemble the Cage Walls

Carefully unfold the wire cage panels. Connect the side, front, and back panels using the integrated hooks and loops. Ensure all connections are secure to form the main body of the cage.

Your browser does not support the video tag.

Video: Detailed installation guide for the Yaheetech 36-inch White Flight Cage, demonstrating panel assembly.

Step 3: Attach the Cage Body to the Base

Carefully lower the assembled wire cage body onto the plastic base. Secure the cage body to the base using the red clips provided, ensuring a snug fit on all sides.



Image: Red clips provide additional security, locking the cage to its base.

Step 4: Install Perches, Feeders, and Swing

Insert the wooden perches through the designated holes in the cage wires. Attach the plastic feeders/water bowls to the cage at desired heights. Hang the bird swing from the top of the cage using its hook.





The open-top design includes a perch that keeps the top doors open for your birds to stand on, top doors can be opened or closed at will.

Image: A cockatiel enjoying the open-top perch, demonstrating the cage's versatility.



Image: Two lovebirds on the included swing, providing entertainment for your pets.

Step 5: Secure the Top Panel

Place the top panel onto the cage, ensuring it aligns with the side panels. Secure it using the integrated hooks or clips.

The top features an open-top design for bird interaction.



Image: The open-top design includes a perch that keeps the top doors open for your birds to stand on.

Operating Instructions

Open Top Feature

The cage features an open-top design to allow your birds to stand on the roof perch for interaction outside the cage. To activate this feature, simply unlatch the top doors and position the included perch to hold them open. To close, remove the perch and secure the latches.





The open-top design includes a perch that keeps the top doors open for your birds to stand on, top doors can be opened or closed at will.

Image: The open-top design provides an additional perching area for your bird.

Access Doors

The cage is equipped with multiple access doors for easy interaction with your birds, as well as for placing and removing feeders. Ensure all doors are securely latched when not in use to prevent escapes.



Image: Secure cage door for safe bird containment and easy access.

Feeders and Perches

The plastic feeders can be easily removed and reinserted from outside the cage for convenient refilling and cleaning. The sanded wooden perches provide comfortable resting spots for your birds.



Image: A bird utilizing the feeder, which is designed for easy access and refilling.

Maintenance and Care

Daily Cleaning

- Empty and clean the slide-out tray daily. Wash with mild soap and water, then rinse thoroughly and dry before reinserting.
- Refill food and water bowls daily. Clean bowls with mild soap and water regularly to prevent bacterial growth.



Image: The pull-out tray simplifies daily cleaning and waste removal.

Weekly Cleaning

- Wipe down all cage surfaces, including bars and perches, with a bird-safe disinfectant or mild soap and water. Rinse thoroughly to remove any residue.
- Inspect perches for wear and tear. Replace if necessary to ensure your bird's comfort and foot health.

General Care

- The cage is crafted from premium metal wires with rust-resistant paint, ensuring durability.
- The sanded wooden perches are safe for your bird's claws.

Troubleshooting

Cage Instability

- **Issue:** The cage feels wobbly or unstable after assembly.
- **Solution:** Recheck all connection points between the wire panels and ensure they are fully engaged. Verify that the

red clips securing the cage to the base are properly installed and tightened. Ensure the cage is placed on a flat, level surface.

Difficulty with Slide-Out Tray

- **Issue:** The slide-out tray is difficult to remove or insert.
- **Solution:** Ensure the tray is aligned correctly with the runners. Check for any debris or obstructions in the tray's path. The wire grate should be properly seated and not interfering with the tray's movement.

Doors Not Latching Securely

- **Issue:** Cage doors do not close or latch properly.
- **Solution:** Inspect the latch mechanisms for any bends or damage. Gently adjust the wire if necessary to ensure the latch engages fully. Make sure the cage panels are not warped or misaligned.

Specifications

Model Number	YT-00069499 (Item Model Number: 591824)
Color	White
Material	Painted Iron, Plastic
Overall Dimensions (with top opened)	18"L x 14"W x 41"H (45.7 cm L x 35.6 cm W x 104.1 cm H)
Bar Spacing	0.4 inches (1 cm)
Item Weight	9.7 pounds (4.4 kg)
Number of Doors	4
Number of Levels	2
Target Species	Bird (Small Breeds)



Image: Detailed dimensions of the bird cage for reference.

Warranty and Support

For warranty information, technical support, or to inquire about replacement parts, please contact Yaheetech customer service. Refer to the contact information provided with your purchase or visit the official Yaheetech website.
Website: Yaheetech Official Store

© 2023 Yaheetech. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B077VLN17B

More documents and user manuals: **https://manuals.plus/**