

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BLAUPUNKT](#) /
- › [Blaupunkt Symphony Daytona Beach 450 Car Media Player User Manual](#)

BLAUPUNKT DT450

Blaupunkt Symphony Daytona Beach 450 Car Media Player User Manual

Model: DT450

1. INTRODUCTION

This manual provides essential instructions for the installation, operation, and maintenance of your Blaupunkt Symphony Daytona Beach 450 Car Media Player. This device features a 6.2-inch touchscreen, Bluetooth connectivity, PhoneLINK, navigation readiness, and a comprehensive audio system. Please read this manual thoroughly before using the product to ensure proper function and safety.



Figure 1: Front view of the Blaupunkt Symphony Daytona Beach 450 Car Media Player. This image displays the 6.2-inch touchscreen interface.

2. SAFETY INFORMATION

- **Professional Installation Recommended:** Due to the complexity of car audio systems, professional installation by a qualified technician is strongly recommended to prevent damage to the unit or vehicle.
- **Power Supply:** Connect the unit only to a 12V DC power supply with a negative ground.
- **Wiring:** Ensure all wiring is correctly connected according to the wiring diagram. Incorrect wiring can cause damage or fire.
- **Driving Safety:** Do not operate the unit in a way that distracts you from driving. Always prioritize road safety.
- **Temperature:** Avoid exposing the unit to extreme temperatures or direct sunlight for prolonged periods.
- **Moisture:** Keep the unit away from water and excessive moisture.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Player Unit
- SD card with Map
- Wiring Harness
- Screws for installation
- Warranty Certificate
- User Manual (this document)
- Microphone
- Remote Control

4. SETUP AND INSTALLATION

4.1. Installation Guidelines

It is highly recommended to have this unit installed by a certified professional. Improper installation can lead to vehicle damage or malfunction of the media player. Refer to the detailed wiring diagram provided with the unit for specific connections.

4.2. Initial Power On

1. After installation, ensure all connections are secure.
2. Turn on your vehicle's ignition.
3. The unit should power on automatically. If not, press the power button (if available) or check the wiring.
4. Follow any on-screen prompts for initial setup, such as language selection or time zone.

4.3. SD Card Insertion

Locate the mSD slots on the unit. Insert the provided SD card with map data into the designated navigation slot. An additional mSD slot is available for media files.

5. OPERATING INSTRUCTIONS

5.1. Touchscreen Interface

The unit features a 6.2-inch touchscreen for primary control. Tap icons to select functions, swipe to navigate menus, and use pinch-to-zoom gestures where applicable (e.g., navigation maps).

5.2. Audio Playback

- **USB/mSD:** Connect USB devices to the front or rear USB ports, or insert mSD cards into the media slot. Select the corresponding source from the main menu to browse and play audio files (MP3, FLAC) or video files (MP4).
- **Bluetooth Audio Streaming:** Pair your smartphone via Bluetooth to stream music wirelessly.
- **DVD Player:** Insert a DVD into the disc slot to play video content.
- **Radio Tuner:** Access the high-end tuner for AM/FM radio stations.

5.3. Bluetooth Connectivity

To pair your smartphone:

1. Go to the Bluetooth menu on the media player.
2. Enable Bluetooth on your smartphone and search for available devices.
3. Select "Blaupunkt DT450" (or similar) from your phone's list.
4. Confirm the pairing code on both devices.

Once paired, you can make/receive hands-free calls using the internal or external microphone, and stream audio.

5.4. PhoneLINK / Mirrorlink

Connect your smartphone via USB to enable PhoneLINK (also known as Mirrorlink). This feature allows you to mirror your phone's screen onto the media player's display, enabling control of compatible apps directly from the touchscreen.

5.5. Navigation

With the navigation SD card inserted, select the Navigation icon from the main menu. Follow the on-screen instructions to set destinations and receive turn-by-turn guidance.

5.6. Push to Talk (PTT)

Utilize the Push to Talk feature for voice commands or communication, typically integrated with connected smartphone applications. Refer to your smartphone's voice assistant settings for configuration.

5.7. Equalizer Settings

Access the 10-band equalizer from the audio settings menu to customize sound output. Adjust frequency bands to tailor the audio to your preference.

5.8. Rear Camera Input

When a compatible rear camera is connected, the display will automatically switch to the camera view when the vehicle is put into reverse gear.

5.9. Steering Wheel Control

If your vehicle supports steering wheel controls, the unit can be configured to integrate with them. Access the steering wheel control settings in the system menu to map functions like volume, track skip, and mode selection.

6. MAINTENANCE

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the touchscreen. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Do not use abrasive cleaners or solvents.
- **General Cleaning:** Keep the unit free from dust and debris. Use a soft brush or compressed air to clean

vents and button areas.

- **Software Updates:** Periodically check the official Blaupunkt website for any available software or firmware updates for your model. Follow the provided instructions carefully for any update procedures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not power on.	Incorrect wiring; blown fuse; vehicle ignition off.	Check power and ground connections. Inspect vehicle fuses. Ensure ignition is on.
No sound output.	Volume too low; mute activated; speaker wiring issue.	Increase volume. Deactivate mute. Check speaker connections.
Bluetooth connection fails.	Device not in pairing mode; incorrect pairing code; interference.	Ensure both devices are in pairing mode. Re-enter pairing code. Move closer to the unit.
Navigation not working.	SD card missing or corrupted; GPS signal weak.	Ensure navigation SD card is correctly inserted. Move to an open area for better GPS reception.
Touchscreen unresponsive.	Temporary software glitch; screen dirty.	Restart the unit (turn vehicle ignition off and on). Clean the screen.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Brand	BLAUPUNKT
Model Number	DT450
Screen Size	6.2 inches
Control Method	Touch
Connectivity Technology	Bluetooth, USB
Special Features	Touchscreen, Navigation Ready, PhoneLINK, Push to Talk, 10 Band Equalizer, Rear Camera Input
Compatible Devices	Smartphone
Audio Output Mode	AUX, Stereo
Output Power	4 x 50 Watts (Max)
Wattage	200 Watts
Number of Channels	4
Supported Media Formats	MP3, FLAC, MP4
D/A Converter	192 kHz - 24 Bit
Pre-out	3V (Front, Rear & Sub-out)

Item Weight	3.5 Kilograms
-------------	---------------

9. WARRANTY AND SUPPORT

9.1. Warranty Information

This product comes with a warranty. Please refer to the included Warranty Certificate for detailed terms, conditions, and duration of the warranty period. Keep your purchase receipt as proof of purchase.

9.2. Customer Support

For technical assistance, service, or inquiries, please contact Blaupunkt customer support:

- **Importer:** Blaupunkt India P Ltd
- **Address:** # 47 Atlanta Society, 4th. Floor, Nariman Point, Mumbai 400021, Maharashtra, India.
- **Phone:** [+91.22.67675959](tel:+912267675959)
- **Email:** info@blaupunktcar.in
- **Toll Free Contact:** 1 800 209 6820

10. PRODUCT VIDEOS

No official product videos from the seller are available for embedding at this time.