

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Pfister](#) /

› [Pfister LG61TFY Traditional Tub Filler Instruction Manual](#)

Pfister LG61TFY

Pfister LG61TFY Traditional Tub Filler Instruction Manual

Model: LG61TFY | Brand: Pfister

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Pfister LG61TFY Traditional Tub Filler with 1.8 gpm Handshower. Please read this manual thoroughly before beginning installation or use to ensure proper function and longevity of your product. Keep this manual for future reference.

SAFETY INFORMATION

- Always turn off the main water supply before installing or servicing the tub filler.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Ensure all connections are secure to prevent leaks.
- Do not use harsh chemicals or abrasive cleaners on the finish, as this may damage the product.

PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- Pfister LG61TFY Traditional Tub Filler Trim
- Matching Telephone Handshower
- Installation Guide (this document)
- Mounting Hardware
- *Note: Two ¾" supply lines are required for installation and are sold separately.*







Figure 1: Pfister LG61TFY Traditional Tub Filler with Handshower in Tuscan Bronze finish. This image displays the complete unit, including the main spout, hot and cold handles, diverter, and the attached handshower with its hose.

SETUP AND INSTALLATION

This tub filler requires a 5-hole installation and is designed for floor mounting. Professional installation is recommended.

- 1. Prepare the Installation Area:** Ensure the floor is properly prepared for a freestanding, floor-mounted fixture. Verify that the necessary plumbing rough-ins for hot and cold water supply lines are correctly positioned.
- 2. Water Supply Lines:** Connect two $\frac{3}{4}$ " supply lines (sold separately) to the designated hot and cold water inlets on the tub filler base. Ensure these connections are tight and leak-free.
- 3. Mounting:** Secure the tub filler to the floor using the provided superior mounting posts and hardware. Refer to the detailed dimension diagram for precise hole placement and spacing.
- 4. Handshower Connection:** Connect the handshower hose to the diverter outlet on the main body of the tub filler.
- 5. Test for Leaks:** Once all connections are made and the unit is securely mounted, slowly turn on the main water supply and check for any leaks at all connection points.

Dimensions (inches)




Figure 2: Detailed dimensions diagram for the Pfister LG61TFY tub filler, showing measurements in inches and millimeters for installation planning. This includes overall height, spout reach, handle spacing, and handshower dimensions.

OPERATING INSTRUCTIONS





Figure 3: Pfister LG61TFY tub filler with labels indicating the hot water handle, cold water handle, and handshower diverter lever.

1. **Turning On/Off:** Rotate the hot (left) and cold (right) handles to control water flow and temperature. Turning them clockwise typically reduces flow or turns off, while counter-clockwise increases flow.
2. **Adjusting Temperature:** Mix hot and cold water by adjusting both handles until the desired temperature is achieved.
3. **Using the Handshower:** To divert water from the main spout to the handshower, lift or pull the handshower lever (as indicated in Figure 3). Push or lower the lever to return water flow to the main spout.
4. **Flow Rate:** The main tub filler spout provides a flow rate of 9 Gallons Per Minute (GPM), while the handshower provides 1.8 GPM.

MAINTENANCE

- **Cleaning the Finish:** Clean the Tuscan Bronze finish with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or polishes that could damage the surface. Mild soap and water are generally sufficient.
- **Aerator Maintenance:** If water flow from the spout or handshower decreases, the aerator may be clogged. Unscrew the aerator, rinse it under running water to remove debris, and reattach.
- **Leak Prevention:** Periodically check all connections for tightness to prevent leaks. Do not overtighten.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed supply valve.	Clean aerator; ensure supply valves are fully open.
Leaks at Connections	Loose connections; damaged O-rings/gaskets.	Tighten connections (do not overtighten); replace O-rings/gaskets if damaged.
Water Not Diverting to Handshower	Divertor lever not fully engaged; debris in diverter mechanism.	Ensure lever is fully actuated; inspect diverter for obstructions.

If problems persist after attempting these solutions, please contact Pfister customer support.

SPECIFICATIONS

- **Model Number:** LG61TFY (also referred to as LG6-1TFY)
- **Finish:** Tuscan Bronze
- **Material:** All Metal Construction
- **Mounting Type:** Freestanding, Floor Mounted

- **Number of Handles:** 3
- **Tub Filler Flow Rate:** 9 Gallons Per Minute (GPM)
- **Handshower Flow Rate:** 1.8 Gallons Per Minute (GPM)
- **Required Supply Lines:** Two 3/4" (sold separately)
- **Installation:** 5-hole installation required
- **Product Dimensions:** Approximately 32.27 x 16.67 x 7.86 inches (refer to Figure 2 for detailed measurements)
- **Item Weight:** 16.37 pounds

WARRANTY INFORMATION

Pfister products are backed by a Limited Lifetime Warranty. This warranty covers defects in material and manufacturing workmanship for as long as the original purchaser owns their home. For complete warranty terms, conditions, and claim procedures, please visit the official Pfister website or contact customer support.


CUSTOMER SUPPORT


For further assistance, technical support, or to inquire about replacement parts, please contact Pfister Customer Service:

- **Website:** www.pfisterfaucets.com
- **Phone:** Refer to the Pfister website for current contact numbers.

© 2023 Pfister. All rights reserved.

Related Documents - LG61TFY

	<p><u>Pfister R89-1WR / LG89-XWR Tub & Shower Trim Quick Installation Guide</u></p> <p>Concise, SEO-optimized installation guide for Pfister R89-1WR and LG89-XWR Tub & Shower Trim kits. Features step-by-step instructions, required tools, parts list, safety warnings, and multilingual support.</p>
	<p><u>Pfister Bronson Toilet Paper Holder Installation Guide BPH-BS1</u></p> <p>Installation guide for the Pfister Bronson™ Toilet Paper Holder (Model BPH-BS1). Provides step-by-step instructions for mounting brackets and attaching the holder, including required tools, parts list, safety warnings, cleaning advice, and warranty information.</p>

	<p>Pfister Park Avenue 016-FEO Diverter Trim Quick Installation Guide</p> <p>This guide provides essential instructions for installing the Pfister Park Avenue 016-FEO Diverter Trim. It includes safety warnings, required tools, parts list, and step-by-step assembly instructions.</p>
	<p>Pfister Vie™ 016-VI Handheld Shower Installation Guide</p> <p>Official installation guide for the Pfister Vie™ 016-VI Handheld Shower. Provides step-by-step instructions, tool requirements, cleaning tips, and warranty details for proper installation and maintenance.</p>
	<p>Pfister Mystique GT529-MD Single Control Kitchen Faucet Installation and Care Guide</p> <p>Comprehensive guide for the Pfister Mystique GT529-MD single control kitchen faucet, covering installation, operation, maintenance, and warranty information in English, Spanish, and French.</p>
	<p>Pfister Stellen LG529-ESA Pull-Down Kitchen Faucet Quick Installation Guide</p> <p>This guide provides step-by-step instructions for installing the Pfister Stellen LG529-ESA pull-down kitchen faucet. It includes a parts list, required tools, installation options, functional descriptions, and sensor operation details.</p>