

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Aiibe](#) /

> [Aiibe 5 Pack 32 GB Flash Drive 32GB USB Flash Drive USB 2.0 Memory Stick Thumb Drive 32GB Multi Pack USB Drives \(32G, 5 Mixed Colors: Black Red Yellow White Purple\) User Manual](#)

## Aiibe U305-Color5-32G

# Aiibe 32GB USB 2.0 Flash Drive User Manual

MODEL: U305-COLOR5-32G

## 1. INTRODUCTION

Thank you for choosing the Aiibe 5 Pack 32GB USB 2.0 Flash Drives. These versatile memory sticks are designed for reliable data storage, backup, and transfer across various devices. With their convenient swivel design and multiple colors, they offer both functionality and ease of organization. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your flash drives.

### Key Features:

- **Multifunction 32GB Flash Drive:** Ideal for storing music, photos, movies, designs, programs, handouts, and other files.
- **Easy to use:** Plug and play functionality, no software installation required.
- **Wide Compatibility:** Supports Windows 7/8/10/Vista/XP/2000/ME, Unix, Linux, and Mac OS 10.3 and above. Compatible with USB 2.0 and 1.1 ports.
- **Unique Design:** 360-degree metal swivel cover protects the USB connector. Multicolor body with LED indicators for stylish appearance.
- **Portable:** Compact size easily fits into pockets. Loop at the end for attaching to keychains or lanyards to prevent loss and for easy carrying.

## 2. PRODUCT OVERVIEW



Image: A set of five Aiibe 32GB USB flash drives in black,

white, orange, yellow, and purple, showcasing their mixed colors and swivel design.



Image: A close-up view of a black Aiiibe USB flash drive with its metal swivel cover partially open, resting on a laptop surface.




Image: A diagram illustrating the dimensions of the Aiiibe USB flash drive, showing its length (2.16 inches), width (0.74 inches), and height (0.39 inches).



Image: An illustration demonstrating the 360-degree rotation feature of the Aiiibe USB flash drive, showing the

metal cover swiveling around the main body.



Image: A graphic displaying various devices and operating systems compatible with the Aiiibe USB flash drive, including Desktop PCs, Car Studio systems, Laptops, Speakers, Video Projectors, Windows (8, 10, XP, Vista, 7), Linux, and Mac OS X.



Image: A visual showing the Aiiibe USB flash drives in their cardboard packaging and an example of a drive attached to a keychain, highlighting its portability.

### 3. SETUP

#### Connecting the USB Flash Drive:

1. Locate an available USB port on your computer, laptop, car stereo, or other compatible device.
2. Gently swivel the metal cover of the flash drive to expose the USB connector.
3. Insert the USB connector firmly into the USB port. Ensure it is inserted correctly; do not force it.
4. The LED indicator on the flash drive will light up, indicating a successful connection.

#### Initial Recognition:

Upon first connection, your operating system should automatically detect and install the necessary drivers. This is a plug-and-play device, so no manual driver installation is typically required. Once recognized, the drive will appear as a removable disk in 'My Computer' (Windows) or 'Finder' (Mac).

## 4. OPERATING INSTRUCTIONS

### Transferring Files:

1. Open 'My Computer' (Windows) or 'Finder' (Mac) and locate the newly recognized flash drive.
2. Navigate to the files or folders you wish to transfer on your computer.
3. **To copy files:** Select the desired files/folders, right-click (or Ctrl-click on Mac), and choose 'Copy'. Then, open the flash drive's folder, right-click, and select 'Paste'. Alternatively, drag and drop the files/folders directly into the flash drive's window.
4. **To move files:** Select the desired files/folders, right-click, and choose 'Cut'. Then, open the flash drive's folder, right-click, and select 'Paste'.
5. Wait for the transfer process to complete. Do not remove the drive during transfer.

### Safe Removal:

To prevent data corruption and ensure the longevity of your flash drive, always safely remove it before physical disconnection:

- **Windows:** Click the 'Safely Remove Hardware and Eject Media' icon in the system tray (bottom-right corner of the taskbar), then select your flash drive. Wait for the 'Safe to Remove Hardware' message.
- **Mac:** Drag the flash drive icon from your desktop to the Trash, or right-click (Ctrl-click) the drive icon and select 'Eject'.
- Once the confirmation message appears (or the icon disappears), you can safely remove the flash drive from the USB port.

## 5. MAINTENANCE

### Care and Storage:

- **Physical Protection:** Always swivel the metal cover over the USB connector when not in use to protect it from dust, dirt, and physical damage.
- **Environmental Conditions:** Store the flash drives in a cool, dry place. Avoid extreme temperatures, direct sunlight, and high humidity.
- **Water Exposure:** *Do not put it into water.* Liquid damage can permanently damage the drive and lead to data loss.
- **Cleaning:** If necessary, gently wipe the exterior of the drive with a soft, dry, lint-free cloth. Do not use liquid cleaners or solvents.
- **Data Backup:** Regularly back up important data stored on the flash drive to another storage medium (e.g., computer hard drive, cloud storage) to prevent data loss in case of drive malfunction or damage.

## 6. TROUBLESHOOTING

### Drive Not Recognized:

- **Check Connection:** Ensure the flash drive is fully inserted into the USB port. Try a different USB port on your device.
- **Restart Device:** Sometimes, a simple restart of your computer or device can resolve recognition

issues.

- **Test on Another Device:** Connect the flash drive to another computer or compatible device to determine if the issue is with the drive or your original device.
- **Check Device Manager (Windows):** Open Device Manager, look for 'Disk drives' or 'Universal Serial Bus controllers'. If you see an exclamation mark or unknown device, try updating or reinstalling the driver.
- **Disk Management (Windows):** In Disk Management, check if the drive appears but is unallocated or has no drive letter. You may need to format it (which will erase all data) or assign a drive letter.

### Slow Transfer Speeds:

- **USB Port Type:** Ensure you are using a USB 2.0 port for optimal performance. While compatible with USB 1.1, speeds will be significantly slower.
- **File Size/Type:** Transferring many small files can be slower than transferring a few large files of the same total size.
- **Background Processes:** Close any unnecessary applications or background processes that might be consuming system resources.
- **Drive Fragmentation:** Over time, flash drives can become fragmented, which might affect performance. Consider backing up data and reformatting the drive if necessary.

### Data Corruption:

- **Safe Removal:** Always use the safe removal procedure before disconnecting the drive. Abrupt removal can lead to data corruption.
- **Scan for Errors:** Use your operating system's built-in disk error checking tools (e.g., 'Error checking' in Windows drive properties).
- **Reformat:** If data is consistently corrupted and you have backed up important files, reformatting the drive can often resolve underlying file system issues.

## 7. SPECIFICATIONS

Feature	Detail
Brand	Aiibe
Model Number	U305-Color5-32G
Memory Storage Capacity	32 GB (per drive)
Connectivity Technology	USB 2.0
Hardware Interface	USB Type A
Color	5 Mixed Colors (Black, Red, Yellow, White, Purple)
Write Speed	5MB/S-8MB/S
Read Speed	12MB/S-20MB/S
Durability	50,000 times read and write
Item Weight	0.353 ounces (approx. per drive)
Product Dimensions (LxWxH)	2.16" x 0.74" x 0.39" (approx.)

## 8. WARRANTY AND SUPPORT

Aiibe products are manufactured to high quality standards. For specific warranty information regarding your 32GB USB 2.0 Flash Drives, please refer to the product packaging or contact Aiibe customer support directly. Keep your purchase receipt as proof of purchase for any warranty claims.

For technical assistance or further inquiries, please visit the official Aiibe website or contact their customer service department through the contact information provided with your product or on their brand store page.

*Note: This manual is for informational purposes only. Product specifications and features may be subject to change without prior notice.*