

Primus P-741080

Primus Campfire Table User Manual

Model: P-741080

1. PRODUCT OVERVIEW

The Primus Campfire Table is a robust and portable solution designed for outdoor cooking and dining. Its intelligent foldable construction, featuring a durable 7075 aluminum frame and a reinforced polycotton surface, makes it ideal for camping, picnics, and other outdoor activities. The table offers a stable and optimal surface for meal preparation and can be easily folded for compact storage and transport.



Figure 1: The Primus Campfire Table in its fully assembled state, ready for use. This image shows the sturdy aluminum

frame and the flat black tabletop surface.



Figure 2: The Primus Campfire Table folded into its compact form, secured with straps for easy transport and storage. This demonstrates its portability.

2. SETUP INSTRUCTIONS

Follow these steps to correctly set up your Primus Campfire Table:

1. **Unpack the Table:** Remove the table from its carrying case or packaging. It will be in a compact, folded state.
2. **Unfold the Frame:** Gently unfold the aluminum frame legs. The legs are designed to cross and lock into place, forming a stable base. Ensure all four legs are fully extended and locked.
3. **Attach the Tabletop:** The tabletop surface is typically integrated or attaches easily to the frame. Lay the tabletop flat and secure it to the frame's attachment points. Ensure it is taut and evenly spread across the frame.
4. **Verify Stability:** Before placing any items on the table, gently press down on the surface and check for stability. All legs should be firmly on the ground, and the tabletop should not wobble.

3. OPERATING INSTRUCTIONS

The Primus Campfire Table is designed for versatile use in outdoor environments:

- **Surface for Meal Preparation:** Use the table as a clean and stable surface for preparing food, holding cooking utensils, or serving meals.
- **Dining Area:** The table can comfortably accommodate multiple individuals for outdoor dining.
- **Weight Capacity:** Do not exceed the maximum load capacity of **30 kg (66 lbs)**. Overloading the table can cause damage or instability.
- **Placement:** Place the table on a flat, stable surface to ensure maximum stability and prevent tipping. Avoid placing it on uneven ground or slopes.

4. MAINTENANCE AND CARE

Proper maintenance will extend the life of your Primus Campfire Table:

- **Cleaning the Tabletop:** The polycotton tabletop cover is machine washable. For general cleaning, wipe

the surface with a damp cloth and mild soap. For deeper cleaning, remove the cover if detachable and machine wash according to fabric care instructions.

- **Cleaning the Frame:** Wipe the aluminum frame with a damp cloth to remove dirt and debris. Avoid abrasive cleaners that could damage the finish.
- **Drying:** Ensure all parts of the table are completely dry before folding and storing to prevent mold, mildew, or corrosion.
- **Storage:** Fold the table into its compact form and store it in a dry, cool place, ideally in its original carrying case if available, to protect it from dust and damage.

5. TROUBLESHOOTING

If you encounter issues with your Primus Campfire Table, consider the following:

- **Table is Unstable:**
 - Ensure all legs are fully extended and locked into their proper positions.
 - Verify the table is placed on a flat, level surface. Adjust its position if necessary.
 - Check that the tabletop is securely attached and taut.
- **Difficulty Folding/Unfolding:**
 - Ensure no debris is obstructing the folding mechanisms.
 - Apply gentle, even pressure. Do not force components.

6. SPECIFICATIONS

Feature	Detail
Model Number	P-741080
Dimensions (L x W x H)	58 x 58 x 75 cm (22.8 x 22.8 x 29.5 inches)
Weight	Approximately 1.7 kg (3.7 lbs)
Maximum Load Capacity	30 kg (66 lbs)
Frame Material	7075 Aluminum
Tabletop Material	65% Polyester, 35% Cotton (Polycotton)
Color	Black
Features	Foldable, Compact, Washable Tabletop

7. WARRANTY AND SUPPORT

Primus products are manufactured to high standards. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Primus website. Keep your proof of purchase for any warranty claims.

For technical support, spare parts, or further assistance, please contact Primus customer service through their official website or the contact details provided in your product packaging. When contacting support, please have your model number (P-741080) and purchase date ready.

Note: This manual provides general guidelines. Specific product features and instructions may vary slightly. Always refer to the latest information from the manufacturer.