

Edifier SS02

Edifier SS02 Speaker Stands Instruction Manual

Model: SS02

1. INTRODUCTION

The Edifier SS02 speaker stands are designed to elevate your Edifier S1000DB, S2000PRO, S1000MKII, and other compatible bookshelf speakers to an optimal listening height. These stands feature a wood grain finish and a hollowed design, allowing for optional sand filling to enhance stability and reduce unwanted resonance. Proper placement and assembly of these stands contribute to an improved audio experience.




Image 1.1: Edifier SS02 speaker stands elevating speakers in a home theater environment.

2. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- 2 x Main Column (Wood Grain)
- 2 x Top Plate (Black)
- 2 x Bottom Plate (Black)
- Screws for assembly
- 8 x Foot Pads

3. SAFETY INFORMATION

- Ensure all screws are securely tightened during assembly to prevent instability.
- Place the assembled stands on a flat, stable, and level surface.
- Do not exceed the maximum load capacity of 15.02 kg per stand.
- Keep small parts, such as screws, out of reach of children.
- Avoid placing stands in high-traffic areas where they could be accidentally knocked over.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Edifier SS02 speaker stands:

1. **Unpack Components:** Carefully remove all parts from the packaging and identify each component as listed in Section 2.
2. **Attach Top Plate:** Align one top plate with the pre-drilled holes on the top end of a main column. Secure it using the provided screws. Tighten the screws firmly but do not overtighten.



Image 4.1: Securing the top plate to the main column with screws.

3. **Attach Bottom Plate:** Align one bottom plate with the pre-drilled holes on the bottom end of the same main column. Secure it using the provided screws. Ensure the Edifier logo on the bottom plate faces forward if desired.
4. **Optional Sand Filling:** The main column is hollow. For increased stability and acoustic damping, you may fill the column with dry sand or other suitable inert granular material before attaching the bottom plate. This helps eliminate resonance.



Image 4.2: View of the hollow column for optional sand filling.

5. **Attach Foot Pads:** Apply the adhesive foot pads to the underside of the bottom plate. These pads help protect your floor and provide additional stability.



Image 4.3: Applying foot pads to the bottom plate.

6. **Repeat for Second Stand:** Follow steps 2-5 to assemble the second speaker stand.

7. **Position Stands:** Place the assembled stands in your desired listening area, ensuring they are on a stable and level surface.
8. **Place Speakers:** Carefully place your speakers onto the top plates of the stands. Ensure the speakers are centered and stable.



Image 4.4: A pair of fully assembled Edifier SS02 speaker stands.

5. OPERATING INSTRUCTIONS

Once assembled and positioned, the Edifier SS02 speaker stands require no further operational steps. Their primary function is to provide a stable and acoustically optimized platform for your bookshelf speakers. Ensure your speakers are securely placed on the top plates and that the stands are not subjected to excessive force or movement.

6. MAINTENANCE

- **Cleaning:** Wipe the stands with a soft, dry cloth. Avoid using abrasive cleaners or solvents that may damage the finish.
- **Stability Check:** Periodically check all screws to ensure they remain tight. Verify that the stands are still on a level surface and that the foot pads are intact.
- **Speaker Placement:** Always ensure speakers are centered and stable on the top plates to prevent accidental falls.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Stand instability or wobbling	Loose screws, uneven floor, improper assembly.	Ensure all screws are tightened. Place stands on a level surface. Re-check assembly steps.
Unwanted resonance or vibration	Hollow column not filled, speaker vibration.	Fill the main column with dry sand or other damping material. Ensure speakers are placed firmly on the top plate.
Scratches on floor	Foot pads not installed or worn out.	Ensure all foot pads are correctly installed. Replace worn foot pads if necessary.

8. SPECIFICATIONS

Feature	Detail
Model Number	SS02
Product Dimensions (L x W x H)	65L x 29W x 65H centimetres (25.6 inches height)
Material	Engineered Wood (MDF, Wood finish)
Color	Brown
Item Weight (per pair)	15.02 kg
Load Capacity (per stand)	15.02 kg
UPC	875674003653
Manufacturer	Edifier
Country of Origin	China

9. WARRANTY AND SUPPORT

The Edifier SS02 speaker stands are backed by a **2-year warranty** within the US and Canada. This warranty covers manufacturing defects and ensures product quality.

For technical support, warranty claims, or any inquiries regarding your Edifier SS02 speaker stands, please contact

Edifier customer service through their official website or the retailer where the product was purchased. Please have your model number (SS02) and proof of purchase available when contacting support.

© 2026 Edifier. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question