

[Manuals.plus](#) /

> [Ivation](#) /

> Ivation Electric Wine Gift Set: User Instruction Manual (Model IVAWINESET05)

## Ivation IVAWINESET05

# Ivation Electric Wine Gift Set: User Instruction Manual (Model IVAWINESET05)

## 1. INTRODUCTION

Thank you for purchasing the Ivation Electric Wine Gift Set. This comprehensive set is designed to enhance your wine experience by providing tools for effortless bottle opening, aeration, and preservation. Please read this manual thoroughly before first use to ensure proper operation and maintenance.



*Figure 1: Ivation Electric Wine Gift Set*

The Ivation Electric Wine Gift Set includes an electric corkscrew, a vacuum preserver, two wine stoppers, a wine aerator/pourer, a foil cutter, and a blue LED charging base. Each component is crafted for ease of use and durability.

## 2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Electric Wine Bottle Opener
- 1 x Electric Wine Vacuum Preserver
- 2 x Date-Stamped Wine Stoppers
- 1 x Wine Aerator/Pourer
- 1 x Foil Cutter
- 1 x Blue LED Charging Base
- 1 x USB Charging Cable
- 1 x User Manual



Figure 2: Labeled components of the Ivation Electric Wine Gift Set

## 3. SETUP AND CHARGING

Before initial use, ensure both the Electric Wine Bottle Opener and the Electric Wine Vacuum Preserver are fully charged.

### 3.1 Charging the Devices

1. Place the Electric Wine Bottle Opener and the Electric Wine Vacuum Preserver into their designated slots on the Blue LED Charging Base.
2. Connect the USB Charging Cable to the charging base and plug the other end into a compatible USB power source (e.g., wall adapter, computer USB port).
3. The blue LED lights on the charging base will illuminate, indicating that the devices are charging. The lights will turn off once charging is complete.

A full charge typically takes several hours. Once charged, the devices are ready for use.

Your browser does not support the video tag.

*Video 1: Demonstration of the WineWhiz Electric Wine Opener and Charging Base. This video shows the components of a similar electric wine opener set, including the charging process and the blue LED indicator.*

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Using the Foil Cutter

1. Place the foil cutter on top of the wine bottle, gripping it firmly.
2. Twist the foil cutter around the bottle neck a few times to cleanly cut the foil.
3. Remove the foil and discard it.



## EASY GRIP CUTTER

Effortlessly Removes Foil



*Figure 3: Using the Foil Cutter*

### 4.2 Using the Electric Wine Bottle Opener

1. After removing the foil, place the electric wine bottle opener vertically on top of the cork.
2. Hold the bottle firmly with one hand and the opener with the other.
3. Press and hold the lower button (down arrow). The corkscrew will automatically penetrate the cork and pull it out of the bottle. The blue LED light will illuminate during operation.
4. Once the cork is fully removed from the bottle, lift the opener away.
5. To release the cork from the opener, press and hold the upper button (up arrow). The cork will be ejected. The red LED light will illuminate during this process.



— —

— —

## ONE-TOUCH CORKSCREW EXTRACTOR

Opens 30 Bottles on a  
Single Charge

*Figure 4: Operating the Electric Wine Bottle Opener*


Your browser does not support the video tag.

*Video 2: Demonstration of the Ivation Electric Wine Opener in action, showing the cork removal process.*

### 4.3 Using the Wine Aerator/Pourer

The wine aerator is designed to enhance the flavor and aroma of your wine by introducing oxygen as it's poured.

1. Insert the aerator firmly into the neck of the opened wine bottle.
2. Pour the wine slowly through the aerator into your glass. The design helps prevent drips.



— — — — —  
✿  
**AERATES AS YOU POUR**  
EXPERIENCE THE TRUE NATURE  
AND BOUQUET OF ANY WINE  
Curved Spout Prevents Dripping

*Figure 5: Wine Aerator in Use*

#### **4.4 Using the Electric Wine Vacuum Preserver and Stoppers**

To preserve the freshness of an opened wine bottle, use the vacuum preserver and stoppers.

1. Place one of the provided date-stamped wine stoppers firmly into the neck of the opened wine bottle.
2. Place the Electric Wine Vacuum Preserver directly over the stopper.
3. Press and hold the button on the preserver. It will automatically remove air from the bottle, creating a vacuum seal. The device will stop automatically once the vacuum is achieved.
4. To help track freshness, rotate the dial on the stopper to the date the wine was sealed.



## ELECTRIC WINE PRESERVER

Vacuum Pump Removes Air to  
Preserve the Integrity of Your Wine



Two Included Stoppers for  
Resealing Bottles

*Figure 6: Electric Wine Vacuum Preserver and Stoppers*

### 5. MAINTENANCE

To ensure the longevity and optimal performance of your Ivation Electric Wine Gift Set, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior of the electric opener, preserver, and charging base with a soft, damp cloth. Do not immerse any electronic components in water. The foil cutter, aerator, and wine stoppers can be hand-washed with mild soap and water, then thoroughly dried.
- **Storage:** Store all components in their designated slots on the charging base when not in use to keep them organized and charged.
- **Battery Care:** For best battery life, fully charge the devices before first use and recharge them regularly, even if not used frequently. Avoid completely draining the battery before recharging.

### 6. TROUBLESHOOTING

If you encounter any issues with your Ivation Electric Wine Gift Set, refer to the following common

solutions:

- **Device not turning on/working:** Ensure the device is fully charged. Place it on the charging base and check if the blue LED illuminates. If not, check the USB cable and power source.
- **Electric opener not removing cork:** Ensure the opener is placed vertically and firmly on the bottle. The corkscrew may not engage properly if it's at an angle. Check if the cork is synthetic or natural; some very dense synthetic corks might require more pressure.
- **Vacuum preserver not creating a seal:** Ensure the wine stopper is inserted tightly into the bottle neck. The preserver must be placed firmly over the stopper. Check for any damage to the stopper or preserver that might prevent an airtight seal.
- **Aerator leaking:** Ensure the aerator is inserted snugly and straight into the bottle neck.

If problems persist after attempting these solutions, please contact customer support.

## 7. SPECIFICATIONS

Feature	Detail
Product Dimensions	5 x 5 x 0.04 inches
Item Weight	2.2 pounds
Manufacturer	Ivation
Item Model Number	IVAWINESET05
Batteries	2 AA batteries required (for initial use, likely internal rechargeable)
Date First Available	November 6, 2017

## 8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included in your package or visit the official Ivation website. Keep your purchase receipt as proof of purchase for any warranty claims.