

[Manuals.plus](#) /

> [vidaXL](#) /

> vidaXL Corona Range Mexican Pine Wood 3-Door Wardrobe Instruction Manual

vidaXL 243733

vidaXL Corona Range Mexican Pine Wood 3-Door Wardrobe

Model: 243733 | Brand: vidaXL

INTRODUCTION

Thank you for choosing the vidaXL Corona Range Mexican Pine Wood 3-Door Wardrobe. This high-quality wardrobe, crafted from solid waxed pine with distinctive black metal details, brings a rustic Mexican charm to any bedroom or dressing area. This manual provides essential information for safe assembly, proper use, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: Front view of the vidaXL Corona Range Mexican Pine Wood 3-Door Wardrobe.

SAFETY INFORMATION

Important: To prevent tipping, this product **must** be securely fixed to the wall using the supplied wall-fixing device. Failure to do so can result in serious injury or death from furniture tip-over. Always ensure the wardrobe is stable and level before use. Keep small parts and packaging materials away from children.



Image: Rear view of the wardrobe, indicating areas for wall attachment.

PACKAGE CONTENTS

Before assembly, carefully unpack all components and verify that all parts are present and undamaged. If any parts are missing or damaged, please contact vidaXL customer support immediately. The package typically includes:

- Wardrobe panels (side panels, top panel, base panel, back panels)
- 3 doors with domed top design
- Internal shelves (one upper shelf for the left compartment, four shelves for the right compartment)
- Hanging rail for the left compartment
- Hardware pack (screws, dowels, hinges, door handles, wall-fixing device)
- Assembly instructions (this manual)

ASSEMBLY INSTRUCTIONS

Assembly of this wardrobe requires careful attention and is best performed by two people. Some users have reported challenges with unclear diagrams or unmarked parts. Take your time and refer to the diagrams provided in the physical manual (if applicable) or online resources.

1. **Prepare the Area:** Clear a spacious, clean, and level area for assembly. Lay down a blanket or cardboard to protect the furniture parts and your floor.
2. **Identify Parts:** Carefully identify all panels and hardware. Although some parts may not be explicitly labeled, compare them with the diagrams in your physical instruction booklet.
3. **Assemble the Base:** Connect the base panel to the side panels according to the diagrams. Ensure all connections are secure.
4. **Construct the Frame:** Attach the remaining side panels and the top panel to form the main frame of the wardrobe. Use the appropriate screws and dowels.
5. **Install Back Panels:** Slide or nail the back panels into place. Ensure they are flush and contribute to the structural integrity.
6. **Insert Internal Components:** Install the upper shelf and hanging rail in the left compartment. Install the four shelves in the right compartment.
7. **Attach Doors:** Mount the hinges to the doors and then attach the doors to the wardrobe frame. Adjust hinges as needed to ensure proper alignment and smooth opening/closing.
8. **Install Handles:** Attach the black metal ring handles to the doors.
9. **Secure to Wall:** This is a critical safety step. Using the provided wall-fixing device, securely attach the wardrobe to a solid wall. Follow the specific instructions for your wall type (e.g., drywall, concrete).




Image: Detail of the black metal ring handles and hinges.

OPERATING THE WARDROBE

The vidaXL Corona Range wardrobe is designed for storing clothing and personal items. It features three doors, with a large compartment on the left and a smaller compartment with shelves on the right.

- **Opening/Closing Doors:** Use the black metal ring handles to open and close the doors. Ensure doors close completely to protect contents from dust.
- **Left Compartment:** This section includes an upper shelf and a hanging rail, ideal for hanging shirts, jackets, dresses, and other garments.
- **Right Compartment:** This section contains four shelves, perfect for folded clothes, underwear, socks, accessories, or other smaller items.
- **Weight Distribution:** Distribute weight evenly across shelves and the hanging rail to maintain stability and prevent warping.

CARE AND MAINTENANCE

To ensure the longevity and appearance of your pine wood wardrobe, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, which can damage the waxed pine finish.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent buildup.
- **Waxing:** The pine wood is waxed. Periodically re-waxing with a suitable furniture wax can help maintain its luster and protect the wood. Follow the wax product's instructions.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or drying of the wood.
- **Humidity Control:** Maintain a stable room temperature and humidity level to prevent wood from expanding, contracting, or cracking.
- **Check Fasteners:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.

TROUBLESHOOTING

If you encounter issues with your wardrobe, refer to the following common problems and solutions:

- **Difficulty During Assembly:**

Problem: Parts do not fit, or instructions are unclear.

Solution: Double-check all part orientations against the diagrams. Ensure you are using the correct hardware for each step. Assembly often requires two people. If still stuck, contact customer support.

- **Missing or Damaged Parts:**

Problem: Components are missing from the package or arrived damaged.

Solution: Do not proceed with assembly. Contact vidaXL customer support immediately with your purchase details and a list of affected parts for replacements.

- **Doors Not Aligning or Closing Properly:**

Problem: Doors are crooked, rub against the frame, or do not close flush.

Solution: Adjust the hinges. Most hinges have adjustment screws that allow for vertical, horizontal, and depth alignment. Refer to hinge-specific adjustment guides if needed.

- **Wardrobe Feels Unstable:**

Problem: The assembled wardrobe wobbles or feels insecure.

Solution: Ensure all assembly screws are fully tightened. Most importantly, verify that the wall-fixing device is correctly installed and securely anchored to a solid wall. This step is crucial for stability and safety.

SPECIFICATIONS

Brand	vidaXL
Model	243733
Color	Brown
Material	Solid Pine Wood
Overall Dimensions (L x W x H)	150.5 cm x 52 cm x 170 cm
Weight	Approximately 73 kg
Number of Doors	3
Internal Configuration	Left compartment: 1 upper shelf, 1 hanging rail. Right compartment: 4 shelves.



Image: Diagram illustrating the wardrobe's dimensions.

WARRANTY AND SUPPORT

vidaXL products are manufactured to high-quality standards. For information regarding warranty coverage, returns, or technical support, please refer to the purchase documentation or contact vidaXL customer service directly. Have your model number (243733) and purchase date ready when contacting support.

You can typically find support contact information on the vidaXL official website or through the retailer where you purchased the product.

