

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BLACK+DECKER](#) /
- › [BLACK+DECKER 3-in-1 Grass Trimmer and Lawn Mower User Manual](#)

BLACK+DECKER BESTA530CM

BLACK+DECKER 3-in-1 Grass Trimmer and Lawn Mower User Manual

Model: BESTA530CM-QS

INTRODUCTION

Thank you for choosing the BLACK+DECKER 3-in-1 Grass Trimmer and Lawn Mower. This versatile tool is designed to simplify your lawn care tasks, functioning as a grass trimmer, a lawn mower, and an edger. Please read this manual carefully before operating the product to ensure safe and efficient use. Keep this manual for future reference.

SAFETY INFORMATION

Always observe basic safety precautions to reduce the risk of fire, electric shock, and personal injury. Failure to follow these warnings may result in serious injury.

- **Read All Instructions:** Familiarize yourself with the controls and proper use of the product.
- **Wear Personal Protective Equipment (PPE):** Always wear safety glasses or goggles, long pants, sturdy footwear, and hearing protection when operating the tool.
- **Keep Area Clear:** Ensure no bystanders, children, or pets are in the operating area.
- **Disconnect Power:** Always disconnect the tool from the power supply before cleaning, performing maintenance, or if the cutting line becomes tangled.
- **Inspect Before Use:** Check for damaged parts, loose connections, or any other condition that may affect operation.
- **Avoid Wet Conditions:** Do not operate the tool in wet grass or damp conditions.

SETUP

Follow these steps to assemble your BLACK+DECKER 3-in-1 tool:

1. **Attach the Guard:** Secure the safety guard to the trimmer head using the provided fasteners. Ensure it is firmly in place before operation.
2. **Install the Auxiliary Handle:** Slide the auxiliary handle onto the shaft and adjust it to a comfortable working position. Tighten securely.
3. **Adjust the Telescopic Shaft:** Extend or retract the telescopic shaft to your preferred height for comfortable operation in both trimming and mowing modes. Lock it in place.

4. **Assemble for Mowing (if applicable):** To use as a lawn mower, securely insert the trimmer unit into the wheeled base. Ensure it clicks into place, indicating a secure connection.





Image: The BLACK+DECKER 3-in-1 Grass Trimmer and Lawn Mower fully assembled, ready for use.



Image: A man operating the BLACK+DECKER 3-in-1 tool in lawn mower mode, demonstrating its ease of use on a grassy area.

OPERATING

Trimmer Mode

For trimming grass and weeds in hard-to-reach areas:

- Hold the trimmer firmly with both hands.
- Swing the trimmer from side to side, keeping the cutting head parallel to the ground.
- The automatic line feed system will advance the cutting line as needed during operation.



Image: A man demonstrating the use of the BLACK+DECKER 3-in-1 tool in its grass trimmer configuration.

Mower Mode

To convert to a lawn mower:

- Ensure the trimmer unit is securely locked into the wheeled base.
- Adjust the cutting height using the mechanism on the base. Two cutting heights are available: 40mm and 60mm.
- Push the unit across your lawn in overlapping passes for an even cut.



Image: A user operating the BLACK+DECKER 3-in-1 tool as a lawn mower, showcasing its maneuverability.

Edger Mode

For neat and precise lawn edges:

- Rotate the trimmer head to the edging position.
- Utilize the integrated edging wheel to guide the tool along paths, driveways, and flowerbeds, ensuring a straight and clean edge.



Image: A man using the BLACK+DECKER 3-in-1 tool to create clean edges along a garden bed, highlighting the edging wheel feature.



Image: A close-up view of the trimmer head in action, precisely cutting grass around delicate flowers and garden features.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your tool:

- **Cleaning:** After each use, disconnect the power and clean the tool thoroughly. Remove all grass clippings and debris from the cutting head, guard, and motor housing. Use a damp cloth; do not use abrasive cleaners or immerse the tool in water.
- **Line Replacement:** When the cutting line needs replacement, use only genuine BLACK+DECKER replacement spools. This model is compatible with spool A6481-XJ. Refer to the diagram in the original packaging for detailed instructions on replacing the line.
- **Storage:** Store the tool in a dry, secure place, out of reach of children. The unit can be disassembled for compact storage.



Image: The BLACK+DECKER 3-in-1 tool and its wheeled base stored neatly on a wall, demonstrating its compact storage capability.

TROUBLESHOOTING

If you encounter issues with your tool, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Tool does not start	No power supply Damaged power cord Safety switch not engaged	Check power outlet and connections Inspect cord for damage; replace if necessary Ensure all safety switches are fully engaged
Cutting line does not advance	Line tangled or jammed Spool empty Incorrect line type	Disconnect power, clear obstruction Replace spool with new line Use only recommended BLACK+DECKER line (A6481-XJ)
Poor cutting performance	Dull or short cutting line Excessively tall or wet grass Motor overloaded	Advance or replace cutting line Cut in smaller sections; avoid wet grass Reduce load, allow motor to cool

If the problem persists after attempting these solutions, please contact BLACK+DECKER customer support.

SPECIFICATIONS

Feature	Specification
Model Number	BESTA530CM
Power	550 W
Cutting Width	30 cm
Cutting Heights	40-60 mm (2 positions)
Line Diameter	1.5 mm (single line)
Voltage	230 Volt
Speed	7500 RPM
Weight	4.8 kg
Dimensions (L x W x H)	89.6 x 36 x 16 cm
Material	PVC, Metal
Compatible Spool	A6481-XJ

WARRANTY AND SUPPORT

Your BLACK+DECKER product comes with a comprehensive product warranty, ensuring your peace of mind. For detailed warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official BLACK+DECKER website.

For technical assistance, spare parts, or further support, please contact BLACK+DECKER customer service through their official channels. Always provide your product model number (BESTA530CM-QS) when seeking support.