

## WOLF Garten URM3

# WOLF-Garten URM3 Multi-Change Roller Moss Removal Rake User Manual

Model: URM3

## 1. PRODUCT OVERVIEW

The WOLF-Garten URM3 Multi-Change Roller Moss Removal Rake is a high-quality tool head designed for effective lawn care. It is part of the WOLF-Garten multi-change system, allowing it to be used with various compatible handles (sold separately). This tool is specifically engineered to clear moss and thatch from your lawn, promoting healthier grass growth.

- **Purpose:** Clears moss and thatch from the lawn.
- **Design:** Features smooth-running wheels for ease of use.
- **Compatibility:** Designed for use with WOLF-Garten multi-change handles.



**Image 1.1:** The WOLF-Garten URM3 Multi-Change Roller Moss Removal Rake tool head, featuring its red frame, metal blades, and yellow-centered wheels.

## 2. SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using the WOLF-Garten URM3 Roller Moss Removal Rake. Failure to follow these instructions may result in injury or damage to the product.

- **Sharp Blades:** The blades on this tool are extremely sharp. Handle with care to prevent cuts. Always wear appropriate protective gloves when assembling, using, or cleaning the rake.
- **Footwear:** Wear sturdy, closed-toe footwear to protect your feet during operation.
- **Clear Area:** Ensure the area you are working in is clear of people, pets, and obstacles before beginning.
- **Proper Posture:** Pay attention to back-friendly work. Use a handle of appropriate length to maintain a comfortable and upright posture, reducing strain on your back.
- **Storage:** Store the tool in a safe, dry place, out of reach of children and unauthorized users.
- **Inspection:** Before each use, inspect the tool for any damage or loose parts. Do not use if damaged.

## 3. SETUP


The URM3 Roller Moss Removal Rake is a multi-change tool head and requires a compatible WOLF-Garten multi-change handle (not included) for operation.

1. **Select Handle:** Choose a WOLF-Garten multi-change handle that is appropriate for your height and the task. A longer handle is generally recommended for back-friendly operation.
2. **Attach Tool Head:** Align the connector on the URM3 tool head with the multi-change handle.
3. **Secure Connection:** Push the tool head onto the handle until it clicks securely into place. Ensure the connection is firm and there is no wobble before use.
4. **Verify Attachment:** Gently pull on the tool head to confirm it is properly locked onto the handle.

## 4. OPERATING INSTRUCTIONS

The WOLF-Garten URM3 Roller Moss Removal Rake is designed for efficient moss and thatch removal from your lawn. For best results, use on a dry lawn.

1. **Preparation:** Ensure your lawn is relatively dry. Wet moss can be more difficult to remove and can clog the blades.
2. **Positioning:** Place the roller rake on the lawn with the blades facing downwards.
3. **Operation:**
  - **Forward Motion:** Push the rake forward across the lawn. The wheels will roll, and the blades will lightly engage the surface.
  - **Backward Motion (Raking):** Pull the rake backwards towards you. During this motion, the sharp blades will effectively lift and remove moss, thatch, and loose debris from the grass.
4. **Pattern:** Work in systematic rows across your lawn, overlapping slightly to ensure complete coverage.
5. **Collection:** As moss and thatch are removed, they will accumulate in piles. Periodically stop and collect these piles using a standard rake or by hand (wearing gloves).



**Image 4.1:** The URM3 Roller Moss Removal Rake attached to a handle, being used on a lawn to remove moss.



**Image 4.2:** A close-up view of the rake's blades effectively engaging and lifting moss from the lawn surface.



**Image 4.3:** The URM3 Roller Moss Removal Rake in action, showing the accumulation of removed moss behind the tool.



Image 4.4: A pile of moss and thatch collected by the URM3 Roller Moss Removal Rake, demonstrating its effectiveness.

## 5. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your WOLF-Garten URM3 Roller Moss Removal Rake.

- **Cleaning Blades:** After each use, especially when working with damp moss, clean the blades thoroughly. Use a bamboo cane, a piece of stick, or a strong blast from a hose pipe to remove any trapped debris. **WARNING: The blades are extremely sharp. Always wear protective gloves during cleaning.**
- **Drying:** Ensure the tool is completely dry before storing to prevent rust on metal components.
- **Storage:** Store the rake in a dry, covered area, away from direct sunlight and moisture.
- **Blade Sharpening:** Over time, the blades may become dull. If performance decreases, consider professional sharpening or replacement of the blade unit if available.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Ineffective moss removal	<ul style="list-style-type: none"><li>• Lawn is too wet</li><li>• Blades are dull or clogged</li><li>• Insufficient pressure applied</li></ul>	<ul style="list-style-type: none"><li>• Wait for the lawn to dry</li><li>• Clean blades; consider sharpening or replacement</li><li>• Apply more consistent pressure during the pulling motion</li></ul>

Problem	Possible Cause	Solution
Tool feels wobbly on handle	<ul style="list-style-type: none"> <li>• Tool head not securely attached</li> <li>• Handle or tool head connector is damaged</li> </ul>	<ul style="list-style-type: none"> <li>• Ensure the tool head is fully clicked and locked onto the handle</li> <li>• Inspect for damage; replace if necessary</li> </ul>
Difficulty pushing/pulling	<ul style="list-style-type: none"> <li>• Blades are clogged with debris</li> <li>• Wheels are obstructed</li> </ul>	<ul style="list-style-type: none"> <li>• Clean blades thoroughly</li> <li>• Check wheels for debris and clear any obstructions</li> </ul>

## 7. SPECIFICATIONS

<b>Brand</b>	WOLF Garten
<b>Model Number</b>	URM3
<b>Item Type Name</b>	Multi-Change Roller Moss Removal Rake Lawn Care Tool Head
<b>Product Dimensions (W x H)</b>	6.17"W x 23.82"H (Tool Head Only)
<b>Item Weight</b>	2.2 Pounds
<b>Color</b>	Red
<b>Head Material</b>	Metal
<b>Included Components</b>	WOLF-Garten multi-star® UR-M 71AAA036650 Scarifier Roller 3 Inch Red 30 x 60 x 16 cm (Tool Head Only)
<b>Manufacturer Part Number</b>	URM3

## 8. WARRANTY AND SUPPORT

Specific warranty information for the WOLF-Garten URM3 Multi-Change Roller Moss Removal Rake is not provided in this document. Please refer to the product packaging or the official WOLF-Garten website for detailed warranty terms and conditions.

For technical support, spare parts, or further assistance, please contact WOLF-Garten customer service through their official website or authorized retailers.

- **Official Website:** [www.wolfgarten.com](http://www.wolfgarten.com) (Please note: This is a generic placeholder URL. Refer to actual product documentation for the correct website.)
- **Customer Service:** Contact information can typically be found on the manufacturer's website or product packaging.

