

[Manuals.plus](#) /

› [Keurig](#) /

› Keurig K-Elite Coffee Maker User Manual

Keurig K-Elite

Keurig K-Elite Single Serve K-Cup Pod Coffee Maker

Model: K-Elite | Brand: Keurig

INTRODUCTION

The Keurig K-Elite brewer offers a premium Brushed Silver finish and advanced programmable features, providing both modern design and extensive beverage customization. This single-serve coffee maker is designed for convenience and quality, allowing users to brew a variety of hot and iced beverages with ease.



WHAT'S IN THE BOX

Your Keurig K-Elite Coffee Maker package includes the following components:

- Keurig K-Elite Coffee Maker
- One Water Filter Handle
- One Water Filter

SETUP

1. **Unpack and Place:** Remove all packaging materials. Place the brewer on a stable, flat surface.
2. **Clean Water Reservoir:** Remove the 75oz removable water reservoir from the side of the brewer. Wash it with warm, soapy water and rinse thoroughly.
3. **Insert Water Filter:** If desired, insert the water filter into the water filter handle and place it into the reservoir.
4. **Fill Water Reservoir:** Fill the reservoir with fresh water up to the "MAX" fill line. Place it back onto the brewer.
5. **Plug In:** Plug the brewer into a grounded outlet. The brewer will automatically turn on.
6. **Initial Brew (Cleansing Brew):** Place a large mug on the drip tray. Lift and lower the brewer handle without inserting a K-Cup pod. Press the brew button for a cleansing brew. This will prime the brewer and prepare it for use. Discard the hot water.

 **75oz**
Removable
water reservoir



Figure 2: The large 75oz removable water reservoir allows for multiple brews between refills.

OPERATING INSTRUCTIONS

Basic Brewing

1. **Power On:** Press the power button to turn on the brewer. The display will show the current time.
2. **Insert K-Cup Pod:** Lift the brewer handle. Place a K-Cup pod into the K-Cup pod holder. Lower the handle completely to close the lid.
3. **Select Brew Size:** The brew size buttons (4, 6, 8, 10, 12oz) will illuminate. Select your desired brew size.
4. **Brew:** The brewer will begin brewing. Coffee will be ready in minutes.



Figure 3: Control panel showing brew size options and other functions.

Strong Brew

For a bolder, more intense cup of coffee, press the **STRONG** button before selecting your brew size. This will increase the brew time slightly.

Iced Coffee

To brew delicious, full-flavored iced coffee:

- Fill a large, ice-filled tumbler (do not use glass) with ice.
- Insert your desired K-Cup pod.
- Press the **ICED** button. The brewer will automatically select the optimal size and strength for an iced beverage.



EASY ICED COFFEE

full-flavored and delicious

Brew delicious iced beverages easier than ever with the **ICED button**

Fill your cup to the top with ice

Press the **ICED button** - the K-Elite™ Coffee Maker selects the optimal size and strength for a perfectly brewed iced beverage



FILL
WITH ICE
do not use glass



BREW
HOT



ENJOY
COLD



Figure 4: Visual guide for preparing iced coffee.

Hot Water on Demand

For instant soups, oatmeal, or other hot beverages, simply place a mug on the drip tray and press the **HOT WATER** button. No K-Cup pod is needed for this function.



HOT WATER ON DEMAND

Press the HOT
WATER button
for instant soups
and oatmeal



Figure 5: Using the hot water on demand feature.

Programmable Features

The K-Elite offers several programmable settings for enhanced convenience:

- **Auto On/Off:** Program the brewer to automatically turn on or off at specific times to conserve energy.
- **Temperature Control:** Adjust the brewing temperature between 187°F and 192°F to suit your preference.
- **High Altitude Setting:** Activate this setting if you live at altitudes above 5,000 feet to ensure optimal brewing performance.



PROGRAMMABLE SETTINGS

- ✓ Temperature Control
- ✓ Auto On/Off
- ✓ High Altitude Setting



Figure 6: Programmable settings for customized brewing.

Removable Drip Tray

The drip tray can be removed to accommodate larger travel mugs (up to 7.2 inches tall) or for easy cleanup of accidental spills.



Figure 7: The removable drip tray allows for taller mugs.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Keurig K-Elite brewer.

Descaling

The brewer features a **BREWER MAINTENANCE REMINDER** that will alert you when it's time to descale. Descaling removes built-up calcium deposits, which can affect brew quality and brewer lifespan. Follow the instructions in the full user guide for the descaling process.

Cleaning

- Regularly clean the exterior of the brewer with a damp cloth.
- Wash the drip tray and water reservoir with warm, soapy water.
- Replace the water filter every two months or as indicated by the brewer.

TROUBLESHOOTING

If you encounter issues with your Keurig K-Elite, consider the following common solutions:

- **Brewer Not Turning On:** Ensure the power cord is securely plugged into a grounded outlet.
- **"ADD WATER" Indicator:** Refill the water reservoir to the MAX fill line.

- **Coffee Not Brewing:** Ensure the brewer handle is fully lowered and a K-Cup pod is properly inserted. Check if the water reservoir is correctly seated.
- **Slow Brewing or Reduced Flow:** This often indicates a need for descaling. Follow the maintenance instructions.
- **Coffee Not Hot Enough:** Check the temperature control setting and adjust if necessary. Ensure the brewer has completed its heating cycle.

For more detailed troubleshooting, refer to the full user guide.

SPECIFICATIONS

Feature	Detail
Brand	Keurig
Model Name	K-Elite Coffee Maker
Color	Brushed Silver
Product Dimensions	9.9"D x 12.7"W x 13.1"H
Item Weight	8 pounds
Water Reservoir Capacity	75 oz
Brew Sizes	4, 6, 8, 10, 12 oz
Temperature Control	187°F – 192°F
Special Features	Programmable, Strong Brew, Iced Setting, Hot Water on Demand, High Altitude Setting, Brewer Maintenance Reminder
Filter Type	Reusable (for K-Cup pods)
Coffee Input Type	K-Cup Pods and Ground Coffee (with Universal My K-Cup Reusable Coffee Filter, sold separately)
Voltage	110 Volts
Country of Origin	China

↑ ↓ PRODUCT DIMENSIONS

13.1" High
(16.5" High when open)

9.9" Wide

12.7" Deep

Weighs 8.0lbs



Figure 8: Key product dimensions for placement.

WARRANTY AND SUPPORT

For warranty information, technical support, or to access the complete user guide, please visit the official Keurig website or refer to the documentation included with your product. A digital version of the user guide is available at: [Keurig K-Elite User Guide \(PDF\)](#).