

[Manuals.plus](#) /

› [LKPower](#) /

› LKPower AC Adapter Instruction Manual for Sony ICF-7600 Series Radios

LKPower 171103209

LKPower AC Adapter Instruction Manual for Sony ICF-7600 Series Radios

Model: 171103209

1. INTRODUCTION

This instruction manual provides essential information for the safe and efficient use of your LKPower AC Adapter. This adapter is designed to provide reliable power to compatible Sony radio models, including ICF-7600, ICF-7600A, ICF-7600D, and ICF-7600DS. It converts standard AC wall power into the DC power required by your device, enabling operation and battery charging.

2. SAFETY INFORMATION

- Ensure the adapter is used with compatible devices only. Refer to the specifications section for compatible models.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to disassemble or modify the adapter. This may void the warranty and pose safety risks.
- Unplug the adapter from the wall outlet when not in use for extended periods.
- Keep out of reach of children.
- If the adapter appears damaged, discontinue use immediately and contact support.

3. PACKAGE CONTENTS

Your LKPower AC Adapter package should contain the following item:

- 1 x LKPower AC Adapter (Model: 171103209)

4. SETUP

1. **Identify the Adapter:** Confirm you have the correct LKPower AC Adapter (Model: 171103209) for your Sony ICF-7600 series radio.

2. **Connect to Device:** Insert the barrel connector end of the AC adapter cable into the DC input jack on your Sony radio. Ensure a secure connection.
3. **Connect to Power Outlet:** Plug the AC adapter's prongs into a standard wall power outlet (100-240V AC).



Image: The LKPower AC Adapter connected to a power strip, ready to power a device. This illustrates a typical setup scenario.

Once connected, your radio should receive power, allowing it to operate or charge its internal battery (if applicable).

5. OPERATING INSTRUCTIONS

The LKPower AC Adapter is designed for simple plug-and-play operation:

- After completing the setup steps, your Sony radio will automatically draw power from the adapter.
- No additional settings or configurations are required for the adapter itself.
- To disconnect, first unplug the adapter from the wall outlet, then disconnect the barrel connector from your radio.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the adapter. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid wrapping the cable too tightly around the adapter to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use.

7. TROUBLESHOOTING

If you encounter issues with your LKPower AC Adapter, consider the following:

- **No Power to Device:**
 - Ensure the adapter is securely plugged into a working wall outlet. Test the outlet with another device.
 - Verify the barrel connector is fully inserted into your radio's DC input jack.
 - Check the adapter cable for any visible damage.
 - Confirm your radio is compatible with this adapter model.

- **Adapter Feels Hot:**
 - It is normal for AC adapters to feel warm during operation. However, if it becomes excessively hot to the touch or emits a burning smell, unplug it immediately and discontinue use.
 - Ensure adequate ventilation around the adapter.

If troubleshooting steps do not resolve the issue, please contact LKPower customer support.

8. SPECIFICATIONS



Image: Front and side view of the LKPower AC Adapter, highlighting its compact design and input specifications.




Image: Detailed view of the LKPower AC Adapter with its physical dimensions and cable length clearly indicated.

Feature	Detail
Brand	LKPower
Model Number	171103209
Compatible Devices	Sony ICF-7600, ICF-7600A, ICF-7600D, ICF-7600DS Radios

Feature	Detail
Input Voltage	AC 100-240V, 50/60Hz, 0.3A (Worldwide AC Input)
Output Power	Provides DC power suitable for compatible Sony radios
Wattage	45 Watts (Max)
Connector Type	Barrel Connector
Cable Length	76 inches (approx. 1.93 meters)
Dimensions (Adapter Body)	2.6 inches (Length) x 1.6 inches (Width) x 1.2 inches (Height)
Special Features	Over Voltage Protection, Over Heat Protection, Travel-friendly design
Mounting Type	Wall Mount

9. WARRANTY AND SUPPORT

LKPower products are manufactured to high-quality standards. For warranty information or technical support, please refer to the documentation provided with your purchase or contact your retailer. You may also visit the official LKPower website for further assistance.

Please have your product model number (171103209) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B078CK4NN3>

More documents and user manuals: <https://manuals.plus/>